
**User's
Manual**

**AQ7292A, AQ7293A, AQ7294A,
AQ7293F, AQ7293H, AQ7294H
OTDR**

Thank you for purchasing the AQ7290 OTDR series AQ7292A, AQ7293A, AQ7294A, AQ7293F, AQ7293H, AQ7294H OTDR (Optical Time Domain Reflectometer).

This user's manual explains the features, operating procedures, and handling precautions of the instrument. To ensure correct use, please read this manual thoroughly before beginning operation. Keep this manual in a safe place for quick reference.

The manuals for this instrument are listed on page iii. Please read all manuals.

Contact information of Yokogawa offices worldwide is provided on the following sheet.

Document No.	Description
PIM 113-01Z2	List of worldwide contacts

Notes

- The contents of this manual are subject to change without prior notice as a result of improvements to the product's performance and functionality. Refer to our website to view our latest manuals.
- The figures given in this manual may differ from those that actually appear on your screen.
- Every effort has been made in the preparation of this manual to ensure the accuracy of its contents. However, should you have any questions or find any errors, please contact your nearest YOKOGAWA dealer.
- Copying or reproducing all or any part of the contents of this manual without the permission of YOKOGAWA is strictly prohibited.

Trademarks

- Microsoft, Windows, Windows 10, Windows 11, MS-DOS, and Microsoft Edge are registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- App Store is a service mark of Apple Inc.
- Android and Google Chrome are registered trademarks or trademarks of Google LLC in the United States and/or other countries.
- Adobe, Acrobat, and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated.
- iOS is the name of an operating system of Apple Inc. IOS is a registered trademark or trademark of Cisco Systems, Inc. in the United States and/or other countries and is used under license.
- Bluetooth is a registered trademark or trademark of Bluetooth SIG inc.
- LTE is a registered trademark or trademark of European Telecommunications Standards Institute (ETSI).
- In this manual, the ® and TM symbols do not accompany their respective registered trademark or trademark names.
- Other company and product names are registered trademarks or trademarks of their respective holders.

Revisions

1st Edition: April 2025

Manuals

The following manuals, including this one, are provided as manuals for this instrument. Please read all manuals.

Manuals included with the product

Manual Title	Manual No.	Description
AQ7292A, AQ7293A, AQ7294A, AQ7293F, IM AQ7290-02EN AQ7293H, AQ7294H OTDR Getting Started Guide		Explains the handling precautions, basic operations, and specifications of this instrument.
AQ7292A, AQ7293A, AQ7294A, AQ7293F, IM AQ7290-92Z1 AQ7293H, AQ7294H OTDR		Document for China
Model 739883 Battery Pack Handling Precautions	IM 739883-01EN	Explains the handling precautions of the battery pack.
739883 Battery Pack	IM 739883-92Z1	Document for China
Safety Instruction Manual	IM 00C01C01-01Z1	Safety manual (European languages)

Manuals included in the internal memory of this instrument

The following manuals are included in the internal memory of this instrument. Download them to your PC for use. For how to download them, see “How to View the User’s Manual” in the Getting Started Guide (IM AQ7290-02EN). You can also download them from the YOKOGAWA website. Sign in to Customer Portal at the following website.

<https://myportal.yokogawa.com/>

A printed manual can also be purchased separately. Contact your nearest YOKOGAWA dealer.

Manual Title	Manual No.	Description
AQ7292A, AQ7293A, AQ7294A, AQ7293F, IM AQ7290-01EN AQ7293H, AQ7294H OTDR User’s Manual		This document. Explains all the available features, except for the communication interface features, and how to use them.
AQ7292A, AQ7293A, AQ7294A, AQ7293F, IM AQ7290-17EN AQ7293H, AQ7294H OTDR Communication Interface User’s Manual		Explains the communication interface features and instructions on how to use them.

The “EN and “Z1” in the manual numbers are the language codes.

Conventions Used in This Manual

Prefixes k and K

Prefixes k and K used before units are distinguished as follows:

k	Denotes 1000. Example: 100 kS/s (sample rate)
K	Denotes 1024. Example: 720 KB (file size)

Displayed characters

Bold characters in procedural explanations are used to indicate panel keys and soft keys that are used in the procedure and menu items that appear on the screen.

Notes and cautions

The notes and cautions in this manual are categorized using the following symbols.



Improper handling or use can lead to injury to the user or damage to the instrument. This symbol appears on the instrument to indicate that the user must refer to the user's manual for special instructions. The same symbol appears in the corresponding place in the user's manual to identify those instructions. In the manual, the symbol is used in conjunction with the word "WARNING" or "CAUTION."

WARNING

Calls attention to actions or conditions that could cause serious or fatal injury to the user, and precautions that can be taken to prevent such occurrences.

CAUTION

Calls attention to actions or conditions that could cause light injury to the user or cause damage to the instrument or user's data, and precautions that can be taken to prevent such occurrences.

French

AVERTISSEMENT

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures graves (voire mortelles), et sur les précautions de sécurité pouvant prévenir de tels accidents.

ATTENTION

Attire l'attention sur des gestes ou des conditions susceptibles de provoquer des blessures légères ou d'endommager l'instrument ou les données de l'utilisateur, et sur les précautions de sécurité susceptibles de prévenir de tels accidents.

Note

Calls attention to information that is important for proper operation of the instrument.

Symbols and conventions used in procedural explanations

The contents of the procedural explanations are indicated using the following symbols.

Procedure

Carry out the procedure according to the step numbers. All procedures are written under the assumption that you are starting operation at the beginning of the procedure, so you may not need to carry out all the steps in a procedure when you are changing the settings.

Explanation

This section describes the setup items and the limitations regarding the procedures. It may not give a detailed explanation of the feature. For a detailed explanation of the feature, see chapter 1.

Contents

Manuals	iii
Conventions Used in This Manual	iv

Chapter 1 Features

1.1 Overview	1-1
1.2 Optical Pulse Measurement (OTDR)	1-7
1.3 Optical Pulse Waveform Display (OTDR)	1-9
1.4 Optical Pulse Analysis (OTDR)	1-13
1.5 Pass/Fail Judgment (OTDR)	1-18
1.6 Utilities	1-20
1.7 Application	1-22
1.8 Optical Switch Control	1-31
1.9 File Features	1-32
1.10 System Features	1-35
1.11 Analysis Using the Emulation Software	1-38




Chapter 2 Common Operations

2.1 Theme Selection Screen, Menu Screen, and Operation Screen	2-1
2.2 Using the Rotary Knob and Arrow Keys	2-5
2.3 Using the Touch Panel	2-6
2.4 Setting the Date and Time	2-8
2.5 Entering Text	2-10

Chapter 3 Setting Up the OTDR Feature

3.1 Setting Measurement Conditions (Measure)	3-1
3.2 Setting the Analysis Conditions (Analysis)	3-10
3.3 Setting Display Conditions (OTDR)	3-22
3.4 Setting File Conditions (File)	3-35

Chapter 4 Optical Pulse Measurement (OTDR)

 4.1 Performing Averaged Measurements	4-1
 4.2 Performing Real-time Measurement	4-8
 4.3 Performing High Resolution Measurement	4-19



Chapter 5 Optical Pulse Waveform Display (OTDR)










5.1 Zooming and Moving Displayed Waveforms	5-1
5.2 Displaying a Reference Trace	5-7

Chapter 6 Optical Pulse Analysis (OTDR)

6.1 Analyzing Waveforms	6-1
6.2 Analyzing Events	6-17

Chapter 7 Utility Feature


7.1 Using the Utility Menu	7-1
 7.2 Using the Light Source	7-3
 7.3 Using the Visible Light Source (/VLS option)	7-6
7.4 Using the Optical Power Meter (/SPM, /HPM option)	7-9
7.5 Using the Power Checker (/PC option)	7-21

7.6	Using the Fiber Inspection Probe.....	7-24
 7.7	Controlling the Optical Switch Box.....	7-32
Chapter 8 Using the Application Feature		
 8.1	Displaying a Map of the Line Configuration and Events (OTDR Smart Mapper).....	8-1
 8.2	Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project).....	8-11
 8.3	Monitoring Optical Fiber Cables (Schedule Measurement, /MNT option).....	8-33
 8.4	Performing an Auto Loss Test (Auto Loss Test).....	8-41
 8.5	Performing a Multi Fiber Loss Test (Multi Fiber Loss Test).....	8-52
 8.6	Performing Advanced Analysis (Advanced Analysis).....	8-60
Chapter 9 Managing Data		
9.1	Connecting USB Storage Devices to the USB Ports.....	9-1
9.2	Connecting a microSD Memory Card.....	9-2
9.3	Using the Instrument as a Mass Storage Device.....	9-3
9.4	Saving and Loading Data.....	9-4
9.5	Creating Report Files.....	9-13
9.6	File Operations.....	9-17
Chapter 10 System Setup		
10.1	Displaying the System Setup Screen.....	10-1
10.2	Using the Power Save Mode.....	10-4
10.3	Setting the Expiration Date.....	10-6
10.4	Using the Network (LAN).....	10-11
10.5	Using the Web Server.....	10-15
10.6	Using the WLAN Application.....	10-18
10.7	Using the LTE Dongle.....	10-29
Chapter 11 Troubleshooting, Updating, and Storage		
11.1	Troubleshooting.....	11-1
11.2	Error Message Display.....	11-2
11.3	Viewing the Product Information.....	11-7
11.4	Viewing the Battery Information.....	11-9
11.5	Executing a Self-Test.....	11-11
11.6	Updating the Firmware.....	11-15
11.7	Initializing the Instrument to Its Factory Default Condition.....	11-17
11.8	Adding Options.....	11-19
11.9	Checking the Optical Fiber End Face for Stains.....	11-20
 11.10	Mechanical Inspection and Operation Check.....	11-21
 11.11	Routine Maintenance.....	11-22
11.12	Storage Precautions.....	11-24
Appendix		
Appendix	Using Open Source Software.....	App-1

Index

1.1 Overview

This instrument is an OTDR (Optical Time Domain Reflectometer) with the features listed below. It is used in the optical fiber and line installation and maintenance servicing of access networks, which link telephone exchanges and service providers with subscribers, and user networks, which enable communication within a corporation or building.



OTDR features

OTDR stands for optical time domain reflectometer. The instrument displays waveforms (TRACE mode) or icons (MAP mode) that you can use to detect fault locations in optical fiber cables and monitor fault conditions (transmission loss, splice loss, etc.). It is mainly used in the following optical fiber cable installation and maintenance situations.

- Access network connecting telecom carriers and subscribers, including service providers (SM* optical fiber cable)
 - Network between telecom carriers
- * SM: Single mode

Optical pulse measurement

- **Averaged measurement (TRACE mode)**

A measurement in which measurements are taken several times and the measured values are averaged to display the waveform.

- **Averaged measurement (MAP mode)**

After averaged measurement is performed, the OTDR waveform is automatically analyzed, and the analysis results are displayed using icons for each event type.

- **Real-time measurement (TRACE mode)**


While optical pulse measurement is in progress, measured values are updated and displayed as a waveform in real time.

1.1 Overview


Optical pulse waveform display (TRACE mode)

The results of optical pulse measurement is displayed as a waveform. The displayed waveform can be zoomed and moved.

Analysis results are displayed on the waveform as events.




Zoom the waveform at the cursor position



Event icon display (MAP mode)

The instrument can perform an averaged measurement and then automatically display the measured result events as icons on the screen. In addition, if pass/fail judgment conditions are specified, judgment results are displayed. For details on the pass/fail judgment function, see section 1.5.

Analysis results are displayed as icons.



Optical pulse analysis

• Waveform analysis

The following events can be analyzed using cursors and markers.

- Distance
- Splice loss
- Return loss

- **Event analysis**

Events are automatically detected. In addition, you can edit events. Adjustments can be made when certain events cannot be detected or when noise is detected as events.

USB features

Connecting USB storage devices, communication dongles, and fiber inspection probes (Type -A)

USB storage devices complying with USB1.0/1.1/2.0 can be used. Up to two devices can be connected. You can save waveform data and measurement conditions to USB memory devices. By using a communication dongle (LAN, WLAN, LTE), you can remotely control the instrument over a network and transfer measured waveform data to an external server. You can also connect a probe that is used in Fiber Inspect Probe, which is an application of this instrument. For the recommended communication dongles that can be used with this instrument, contact your nearest YOKOGAWA dealer.

Connecting to a PC (Type-C)

The instrument can be accessed as a mass storage device from a PC, and the files and folders in the internal memory can be displayed and manipulated. You can also connect a PC to the instrument and control it using communication commands. For details, see the communication interface user's manual, IM AQ7290-17EN.

Ethernet features (/LAN option)

You can connect a PC to the instrument and control it using communication commands. For details, see the communication interface user's manual, IM AQ7290-17EN.

microSD memory card

You can use microSD memory cards. Only one card can be inserted at any given time. You can save waveform data and measurement conditions to them. Note that microSD memory cards are not included with this instrument. Please use your own microSD memory cards. The instrument supports SDC, SDHC, and SDXC. For information about compatible microSD memory cards, contact your nearest YOKOGAWA dealer.

Utility features (simultaneous use of multiple functions)

On the OTDR screen, you can call up optical power meter, visible light source, and other features and measure optical power and the like simultaneously with the OTDR measurement. In a measurement that takes a certain time to complete such as in an OTDR averaged measurement, measurement of other fibers can be executed simultaneously to effectively use the measurement wait time and improve work efficiency.

Light source feature (utility)

Stabilized light source

This is used as a light source for measuring optical loss or as a light source for optical fiber identification. The measurement light (CW, CHOP) is emitted from the OTDR port. The wavelength of the measurement light is the same as that of the optical pulse of the OTDR.

Visible light source (/VLS option)

This is used to view the fault locations or check the cores of multi-fiber optical cables. The VLS port transmits a visible light (CW, CHOP (2 Hz)) with an emission wavelength of 650 nm.

Fiber in use alarm (utility)

Power checker (/PC option)

This feature enables you to check the presence of communication light (fiber in use) within the optical fiber cable under measurement and view its power value.

Optical power meter feature (utility)

Standard optical power meter (/SPM option)

This feature measures the optical power for loss measurement or the optical power of a communication device. This is also used as an optical power meter for the Auto Loss Test, which is an application of this instrument.

High power optical power meter (/HPM option)

This feature measures the high power (+27 dBm max.) optical power for loss measurement. This is also used as an optical power meter for the Auto Loss Test, which is an application of this instrument.

Smart mapper feature (application)

This feature performs multiple measurements automatically with a single operation, combines the measured results, and maps the events that occurred on the optical fiber cable as icons. Because a map display is used in place of a waveform display, complex line configurations can be easily understood even by inexperienced workers. You can also automatically judge measured results by setting thresholds. Furthermore, you can view the multiple measured waveforms which are the bases of the map display.

Events can also be displayed as icons on the map display of the OTDR feature, but the map display of the OTDR feature converts the analysis results of averaged measurements. If multiple measured waveforms, which form the bases, are required, the smart mapper feature is convenient.

Multi-fiber measurement feature (application)

Multi-fiber measurement takes time and effort. This feature makes it possible to efficiently measure multi-fiber optical cables through a dedicated menu.

Projects

Items required to make multi-fiber optical cable measurements such as measurement conditions, analysis conditions, and core information are managed as projects. By creating a project before a measurement, you can measure cores under the same conditions. You can save projects to files. You can load a previously saved project and make measurements under the same conditions. In addition, the AQ7933 Emulation Software can be used to create projects, and the project files can be loaded into this instrument.

List

Cores are listed on the screen. You can identify cores that have been measured, cores that have not been measured, and cores that are not to be measured. For each core in the list, you can perform average measurement, real-time measurement, optical power management, and fiber inspection probe operations. This prevents unintended omission in core measurements and allows measurements to be performed efficiently.

Saving measured results

Measurement results of each core are automatically saved to a folder that is automatically created in the folder that the project file is saved in. The folder will have the same name as the project file.

Fiber inspec probe (application)

A YOKOGAWA-specified fiber inspection probe can be used to view stains on the optical fiber cable end face on the instrument screen. Wireless LAN-compatible fiber inspection probes can also be used.

Furthermore, with the /FST option, a pass/fail judgment can also be made on the dirty end face of optical fiber cables.

The fiber inspection probe is not included with the instrument. Please purchase your own fiber inspection probe. For information about compatible fiber inspection probes, contact your nearest YOKOGAWA dealer.

Auto loss test/multi-fiber loss test (application)

By using two instruments, one as a light source and another as an optical power meter, the optical fiber loss can be measured. In a multi-fiber loss test, the loss of a multi fiber can be measured.

As a light source, the instrument automatically switches between two wavelengths (1310 nm and 1550 nm) and outputs them.


As an optical power meter, the instrument automatically detects the wavelength of the input light, switches its wavelength setting, and measures the optical power.

Optical switch feature**Optical switch box connection (Type A)**

You can use this feature to change the route of the measurement light during optical pulse measurement. Selecting a test target switch number from the menu on the optical pulse measurement screen causes the route of the measurement light (optical fiber cable under test) to change. During multi-fiber measurement, selecting a route of the measurement light (core under test) causes the target switch number on the optical switch box to change automatically.


During schedule measurement, several measurement light routes can be monitored periodically. Further, by combining the light source feature and optical power meter feature, you can observe the fluctuations in the optical power and loss by switching between multiple measurement light routes (optical fiber cables under test).

System configuration



1.2 Optical Pulse Measurement (OTDR)

The instrument applies an incident optical pulse to the connected optical fiber cable and measures the power level of the reflected light from the different sections of the optical fiber cable such as its connections, bent sections, and the open end of the fiber. The instrument uses the measured power level to determine the distance to the different points (splices, breaks, etc.) of the optical fiber cable and the loss and other phenomena that occur at those points. For details on how to view optical pulse waveforms, see section 1.3.



Measurement mode

Simple mode (simple OTDR)

In optical pulse measurement, there are measurement conditions related to measurement resolution—such as distance range and pulse width—and analysis conditions related to the optical fiber cable—such as index of refraction and backscatter. These conditions must be set according to the item being measured or analyzed. In this mode, an optical pulse measurement is performed immediately before the measurement to calculate the distance, connection loss, and so on. Based on the results, the optimal range can be automatically determined and measured.

Expert mode (OTDR)

If the distance to the measurement target or the optical fiber cable characteristics are known or if you want to measure or analyze a specific event in detail, you can set the values individually as necessary. If you set the measurement conditions—such as the distance range and pulse width—to Auto, the instrument will determine the suitable range and perform the measurement like in Simple Mode, described above.

Real-time measurement

Real-time measurement is a feature that measures optical pulses while updating and displaying the measured values. You can monitor in real time events, such as splice loss and return loss, while installing optical fiber cables. You can also view the changes in the waveform as you change the measurement conditions, such as the wavelength, distance range, and pulse width (the measurement conditions that you can change vary depending on the measurement mode). For details on the measurement conditions, see section 4.2. Real-time measurement is not possible in MAP mode (the mode is automatically switched to TRACE mode before making a measurement).

Averaged measurement

Averaged measurement is effective when you want to detect reflections, splice loss, and other faint events that are generated from connections or splice points but are buried in noise. The instrument derives the measured data by averaging the specified number of optical pulse measurements or by averaging optical pulse measurements over the specified duration. During averaged measurement, you cannot change the measurement conditions. You can stop an averaged measurement before it completes.

Auto check before measurement

Fiber-in-use alarm

The instrument uses the same wavelength that is used in real communication to measure optical pulses. If communication light is present in the optical fiber cable that you want to measure, the communication will be affected. When this communication light is present, we say that the fiber is in use. The fiber-in-use alarm is a feature that checks if communication light is being transmitted along the optical fiber cable that you are trying to measure. If the fiber is in use, a warning message is displayed asking whether you want to continue the measurement.


Connection check

The connection check is a feature that checks the state of the connection between the instrument and an optical fiber cable. When this feature is set to on, you can prevent light from being transmitted from the instrument OTDR port if an optical fiber cable is not connected to the instrument or if the cable is not connected correctly.

1.3 Optical Pulse Waveform Display (OTDR)


How to view optical pulse waveforms (TRACE mode)

The optical pulse applied to an optical fiber cable is reflected at different points of the optical fiber such as its connections, bent sections, and the open end of the fiber. These sections generate loss. The measured result is displayed as a waveform that has distance represented in the horizontal direction and loss level represented in the vertical direction. On the waveform, detected losses or reflections are known as events.



How to view the icon display (MAP mode)

Losses and reflections that occur at connections, bent sections, and open ends are displayed using icons. Events in the section from the measurement start point to the open end are displayed in order from the start point.




Near-end reflection

This is the reflection that occurs at the point where the instrument and the optical fiber cable are connected. This also includes the instrument's internal reflection. In the section where this near-end reflection is detected, even if there are other connections, the loss and reflections that occur at these points cannot be detected. This section is the near-end dead zone.

When you are measuring a short distance, connect a launch fiber cable to reduce the effect of the near-end reflection.

Backscatter

When light travels through an optical fiber cable, Rayleigh scattering caused by changes in the density of materials that are smaller than the light's wavelength and inconsistencies in the fiber's composition generates loss in the optical fiber itself. The portion of the scattered light that travels in the direction opposite to the direction of propagation is known as backscatter.




Splice loss

Because spliced sections of optical fiber cables have a great number of changes in the material's density and inconsistencies in the cable's composition, loss due to Rayleigh scattering becomes large, and splice loss occurs in these sections.


Reflection at the connection point of connectors

Using a connector to connect two optical fibers is different from splicing them together in that a small gap remains between the two fibers. Because this gap has a different index of refraction, reflection occurs.




Fresnel reflection at the open end of the fiber

This is the reflection that occurs at locations where the index of refraction changes (glass to air) such as where there are tears in the optical fiber cable or at the end of the optical fiber cable. When the end face of the optical fiber cable is vertical, approximately 3 % of the incident optical power (−14.7 dB) is reflected.



Dynamic range

Dynamic range refers to the range of optical power levels that can be measured. The larger the dynamic range, the greater the distance that optical pulses can be measured over.



Dead zone


An area where the influence of a large event such as a connector's connection point makes it impossible to recognize other events that exist in that area is a dead zone. The following types of input modules are available.

Event dead zone

An area where adjacent reflections cannot be separated. This is the area represented by the pulse width between the two points on the waveform at the level that is 1.5 dB below the peak value.

Attenuation dead zone


An area where, because there is a large reflection, the surrounding splice losses cannot be measured.



1.3 Optical Pulse Waveform Display (OTDR)

- **Near-end dead zone prevention**

In sections where near-end reflection is detected, loss and reflections that occur at connections cannot be detected. If you are measuring a short distance, connect a launch fiber cable to move events that are hidden in the near-end reflection the distance of the launch fiber cable.




1.4 Optical Pulse Analysis (OTDR)

Marker analysis (TRACE mode)

You can manually use cursors and markers to measure values such as the distance, splice loss, and return loss between two points.


Distance between two points

The distance from the start point to the cursor position is displayed.



Splice loss

When you place four markers as shown in the following figure, the splice loss from the measurement start position to the measurement end position is calculated, and the value is displayed.




Note

In addition to the above method, the splice loss can be measured by using six markers or by using line markers. For details, see section 6.1.

1.4 Optical Pulse Analysis (OTDR)


Return loss

When you place two markers as shown in the following figure, the return loss is calculated, and the value is displayed.



Splice loss at two locations (2-location Marker)

Splice losses at two locations can be measured simultaneously using four markers.




Event analysis

All events are automatically detected from the waveform of optical pulse measurement, and the types of each event and analysis results (splice loss, return loss, etc.) are displayed on the screen.

Event display


In TRACE mode, detected events are displayed on the measured waveform. In MAP mode, the types of events are displayed using icons along with the distances of each from the measurement start position.

TRACE mode



MAP mode

Distance between events




1.4 Optical Pulse Analysis (OTDR)

Event information display

The distance, splice loss, return loss, and the like of each event are displayed. This is a feature common to TRACE mode and MAP mode.

- List display


All detected events are listed.



Event number

- Individual event information


The analysis data of the selected event number is displayed.



Event number

- Measurement total of events

The total values of detected events are displayed.



Event analysis conditions

You can set event search conditions.

- **Splice loss (splice/connection)**

The instrument recognizes that an event has occurred when it detects a measured result that is greater than the specified value.

- **Return loss**

The instrument recognizes that an event has occurred when it detects a measured result that is less than the specified value.

- **End of optical fiber**

The instrument recognizes that an end-of-fiber (E) event has occurred when it detects a measured result that is greater than the specified value.

- **Bending loss**

You can select whether to detect bending losses. When detecting bending loss, an event is detected when the difference in the losses of matching events at the two measured wavelengths is greater than the threshold.


- **Near-end dead zone prevention (Launch Fiber Setting)**

To prevent near-end reflections, if a launch fiber is connected to the measurement start point, the length of the launch fiber is automatically corrected in the calculations.

For details on near-end dead zone prevention, see “Dead Zone” in section 1.3.

- **Splitter loss**

You can set the threshold for each of the number of splitter splits. When a measured result greater than the specified threshold is detected, it is identified as a splitter event and displayed along with the number of splits.



The number of
splitter splits

1.5 Pass/Fail Judgment (OTDR)


In pass/fail judgment, the instrument automatically determines whether preset conditions are met based on the event analysis data or marker values and displays the results on the screen.

Judgment conditions

Set a pass/fail judgment threshold on each measurement item (splice loss, return loss, dB/km, total loss). When the measurement value does not exceed the threshold, the corresponding event is indicated as pass. When the measurement value is greater than the threshold, the corresponding event or marker value is indicated as fail.

Pass/fail judgment of events


TRACE mode



The pass judgment result and value of each event are displayed.


When all events are judged as Pass, the bar turns green.

MAP mode



Pass/fail judgment of marker values

TRACE mode



When all marker values are judged as Pass, the bar turns green.

The pass judgment result and value of each marker value are displayed. When the judgment result is Fail, the indicator turns red.

1.6 Utilities

Light source

The light source is used to make loss measurements. The following measurement light wavelengths can be generated.

Model	Measurement light wavelength
AQ7292A	1310 nm, 1550 nm
AQ7293A	1310 nm, 1550 nm
AQ7294A	1310 nm, 1550 nm
AQ7293F	1310 nm, 1550 nm, 1650 nm
AQ7293H	1310 nm, 1550 nm, 1625 nm
AQ7294H	1310 nm, 1550 nm, 1625 nm

You can produce continuous light or light that has been modulated at the selected frequency (modulation mode).

Visible light source

The features listed for the visible light source are available on models with the /VLS option.

A visible light source can be used for the following purposes.

- Determine visually breaks in the optical fiber cable under test
- Check the cores of multi-fiber optical cables

Model	Measurement light wavelength
AQ7292A	650 nm
AQ7293A	
AQ7294A	
AQ7293F	
AQ7293H	
AQ7294H	

Optical power meter

The optical power meter feature can be applied to models with the /SPM (standard) or /HPM (high power) option. An optical power meter can be used for the following purposes.

- Measure the loss in an optical line that uses optical fibers
- Measure the optical signal power of an optical communication device

The following measurement lights can be measured.

Model	Measurement wavelength	
	/SPM option	/HPM option
AQ7292A	800 nm to 1700 nm	800 nm to 1700 nm
AQ7293A		
AQ7294A		
AQ7293F		
AQ7293H		
AQ7294H		

Logging

You can measure short-term optical power stability. The optical power value during logging can be displayed on a graph, and you can calculate the maximum, minimum, and average. In addition, you can use cursors to calculate the optical signal power at a specified location or the maximum, minimum, and average within a specified area. The logging results can be saved to a file in CSV format.

Power checker (/PC option)

The power checker feature is used to check the power of the loss-measurement light source in a simplified manner.


The following measurement lights can be measured.

Model	Measurement wavelength
AQ7292A	1310 nm, 1490 nm, 1550 nm, 1625 nm, 1650 nm
AQ7293A	
AQ7294A	
AQ7293F	
AQ7293H	
AQ7294H	

Fiber end face inspection (/FST option)

You can use a fiber inspection probe recommended by YOKOGAWA to take a photograph that shows the state of a optical fiber cable end face. You can display this photograph on the instrument screen and save it. You can also perform a pass/fail judgment on the state of the cable end face shown on the photograph.

Example of an end face image of an optical fiber cable



Pass/fail judgments can be performed separately on each of the contact areas, clad areas, and core areas.

1.7 Application


Smart Mapper

The Smart Mapper feature repeats the averaged measurements of the OTDR feature on the same wavelength using different pulse widths, and then when measurements are completed, automatically executes the event analysis of the OTDR feature.

Like the OTDR feature, when measurements are completed, you can select between MAP mode and TRACE mode.


Event analysis using MAP mode

When you select MAP mode, various events on the optical fiber cable path can be detected and displayed as icons on the screen.



Adapt trace using trace mode (waveform editing)

When you select TRACE mode, waveforms measured at different pulse widths can be displayed. In an optical fiber cable measurement, reducing the pulse width of optical pulse measurement increases the measurement resolution of the waveform in the near-end section but causes the optical pulse to attenuate in the far-end section, preventing correct measurement. Conversely, increasing the pulse width of optical pulse measurement allows correct measurement in the far-end section but decreases the measurement resolution of the waveform in the near-end section. The Adapt Trace feature compensates for these measurement accuracy degradations by performing optical pulse measurement using multiple different pulse widths for the same wavelength and combining the multiple waveforms on the screen. The instrument automatically determines the pulse widths depending on the specified distance range and wavelength.



Optical pulse measurement of multi-fiber optical cables


Projects

Projects are group of items for measuring multi fibers. The default project name is "NewProject." In the instrument internal memory, core information, measurement conditions, analysis conditions, measured results, and the like are linked with the project name and saved. You can set up to 15 characters for the project name. For the types of strings and characters that you can use, see section 3.4.


- **Project file structure**

When you create a new project name, a new project file (.MPJ extension) and a new folder for saving measurement result files (.SOR extension) are created. At this point, you can select whether to inherit the fiber information, measurement conditions, and analysis conditions from an existing project file or reset them to default values.

Example of when the project file name is “ABCDE”



If the number of fibers exceeds 100, the folder for saving the project file and that for saving measurement result files will be divided. The folder is automatically divided every 100 fibers. The divided folder names will be the project name followed by the start core number and end number set in the project.




Number of fibers, number of fibers in each division, tape number

The core number indications and settings vary depending on the type of multi-fiber optical cable.

Normal core cable (example with eight cores)

Eight cores are bundled into one.




Ribbon slotted core cable (example of 300 fiber type 4-fiber ribbon)

This is an example of a 300 fiber type with 15 slots (20 fibers) containing five 4-fiber tapes.

The following settings need to be entered to set the information of this core cable in a project of this instrument.

- Num of Fibers (per slot): 20
- Tape No.: a-d(4)




Multi-fiber measurement

The following four measurements can be performed in multi-fiber measurement.

- OTDR measurement (Realtime)
- OTDR measurement (Average)
- Optical power measurement
- Fiber Inspec Probe

The four measurement features use the same features as the OTDR feature for measuring a single fiber explained in section 1.1, the optical power meter (excluding the logging feature) explained in section 1.6, and the fiber end face inspection explained in section 1.6. You can run and use these four measuring features from the main view screen of multi-fiber measurement.



Example of measuring core number 44

Saving measurement result data

You can save the results of multi-fiber measurement for each fiber. The data is saved in the folder explained in "Project File Structure" on page 1-24. For details on the data format, see section 9.4.

- **OTDR feature (realtime, average)**

For each fiber, waveform data is saved in SOR format in a single file.

- **Fiber Inspec Probe**

For each fiber, screen capture data is saved in BMP format in a single file.

- **Optical power meter**

For each project, data is saved in tab-separated CSV format in a single file.

Optical fiber cable monitoring (/MNT option)

This feature performs optical pulse measurement at regular intervals so that you can monitor for errors in the optical fiber cable. Results measured at regular intervals are saved to memory in CSV or SOR format (waveform data). Data and folders saved in memory are automatically assigned names with timestamps. During monitoring (while schedule measurement is in progress), measurement items, such as the loss between two points, of the logged optical pulses are shown on the instrument screen. Because the changes in the measurement items, such as the loss between two points, can be seen on the time axis, if an interruption occurs in the optical pulse input, you can determine when the optical power level fell on the instrument screen. After determining the time, you can view the measured results in the file with the corresponding timestamp. Up to four measurement items can be monitored.

Auto loss test (combination of light source and optical power meter)


Using the instrument as a light source and optical power meter, you can easily measure optical fiber cable and line optical loss. You can also use an AQ1100A, AQ1100B, AQ1100C, AQ1210A, AQ1215A, AQ1210D, AQ1210E, AQ1215E, or AQ1215F in the multi-field tester series instead of this instrument as the light source or optical power meter.

Light source feature

You can set up to two measurement light wavelengths and produce them in order. You can produce a constant level of light if you use the optical power adjustment feature.


Optical power meter feature

The instrument automatically identifies the measurement light from the opposing instrument or an AQ1100A, AQ1100B, AQ1100C, AQ1210A, AQ1215A, AQ1210D, AQ1210E, AQ1215E, or AQ1215F that it is connected to and measures the optical power.



Loopback feature

You can use the light source and optical power meter features on a single instrument to perform a loop-back loss test on an optical fiber cable or line. To perform loss testing, connect one end of the optical fiber cable that you want to perform loss testing on to the the instrument's OTDR port and the other end to the OPM port on the same instrument.



Multi-fiber loss test

You can efficiently measure the optical loss of multi-fiber optical cables and optical lines degradation.

Projects

Projects are group of items for measuring multi fibers.

- **Number of fibers, number of fibers in each division, tape number**

The core number indications and settings vary depending on the type of multi-fiber optical cable. These features are the same as those explained in "Optical Pulse Measurement of Multi-Fiber Optical Cables" on page 1-23.

Master and slave


Connect two instruments and specify the optical power meter as the master and the light source as the slave. You can also use an AQ1100A, AQ1100B, AQ1100C, AQ1210A, AQ1215A, AQ1210D, AQ1210E, AQ1215E, or AQ1215F in the multi-field tester series instead of this instrument as the master or slave. The preparation involves the following steps.

- **Connecting an optical fiber cable for signal transmission (step 1)**

To transmit, between the master and slave, project setup information and information about the fiber under loss test, you must specify a fiber cable from the multi-fiber optical cable to use for the signal transmission. Connect one end of the optical fiber cable for signal transmission to the OTDR port of the instrument specified as the master (optical power meter side) and the other end to the OPM port of the instrument specified as the slave (light source side).

- **Transferring object information from the master to the slave (step 2)**

On the master instrument, create a project. Transfer the project information to the slave instrument through the optical fiber cable for signal transmission.



- **Connecting the optical fiber cable to perform multi-fiber loss test on (step 3)**


Multi-fiber loss test is performed on all optical fiber cables other than the optical fiber cable for signal transmission. Connect one end of the optical fiber cable to be tested to the OPM port of the master instrument and the other end to the OTDR port of the slave instrument.

Executing the multi-fiber loss test

First, start the multi-fiber loss test on the master instrument. The core number information of the cores to be tested is transmitted from the master side through the optical fiber cable for signal transmission. When the core numbers to be measured are received through the OPM port, the slave instrument will be ready to execute a multi-fiber loss test.

Execute the multi-fiber loss test on the slave side. The light to be measured is output from the OTDR port on the slave side. This light enters the OPM port on the master side, and the loss in the optical fiber cable with the target core number is measured.

The measurement results are sent from the master to the slave instrument through the optical fiber cable for signal transmission.




If you cancel an ongoing multi-fiber loss test, the completed portion of the measurement results are held, so you can resume the test from the optical fiber cable with the next target core number.

Advanced analysis

Multi trace analysis

You can load up to four waveforms that have been measured on the instrument and display them simultaneously for comparison. You can adjust the vertical display position of each loaded waveform.




You can move a waveform over another waveform to compare the two.

2 way analysis

Waveform events that have been measured from optical fiber cable end A to end B and those measured from end B to end A can be combined. Splice loss between optical fiber cables with different backscatter levels can also be accurately measured.

In the figure below, the event that is in the dead zone of the near-end reflection point (point S) when measured from end A is detected as event number 5 when measured from end B. In the 2 way trace analysis display, it is displayed as event number 1.



An event of the other waveform that exists within 6% of the position of an event of the current trace will be considered part of the current trace event.

If multiple events of the other waveform that exists within 6% of the position of an event of the current trace, the closest event will be considered part of the current trace event.

Waveforms that meet the following conditions can be combined.

- Both have the same wavelength.
- Both have the same pulse width.
- Their end position offset is within 6%.
- Both have event lists.

Differential trace


You can load two waveforms that have been measured on the instrument and display their difference as a waveform.

The screen can display the loaded waveforms and the differential trace simultaneously.

The differential trace is the result of subtracting the values of the current trace from those of the other trace.

You can use markers to read the following values of the differential trace.


- Loss between markers (dB)
Loss between ① and ② and between ③ and ④
- Distance to each marker
Distance between ① and ② and between ③ and ④



You can perform marker analysis on the differential trace.

Section analysis

You can set two markers, start point S and end point E, to measure the return loss and total loss in the section that you have specified. By setting reference point B, you can calculate the return loss using the backscatter level you specify.



1.8 Optical Switch Control


Optical switch box

You will need an optical switch box that is compatible with this instrument's optical switch control.

Name	Model	Notes
Optical switch box	AQ3550	Port configuration: 1 × 12


Instrument connection

The following figure shows how this instrument and an optical switch box can be connected.



Optical switch structure

The input port (SC) route can be connected to any of the 12 output port (MPO) channels through switching.



1.9 File Features

Measured results (waveform data), measurement and analysis conditions, system settings, and the like can be saved as files to internal memory or external memory (USB memory or microSD memory card). By saving the measurement/analysis conditions and system setup file for one AQ7290 to external memory, you can efficiently set the same conditions for multiple AQ7290s. In addition, the instrument can save measured waveform data as PDF data in report format.

Saving and loading files

File types

The following types of files can be saved.

- **.SOR**

A file for saving optical pulse measurement results. Measurement and analysis conditions, waveform data, event list data (when event analysis is executed) are stored in this file. When an SOR file is loaded, the measurement and analysis data is loaded into the instrument, the waveform data is displayed on the instrument screen. If event list data is stored, event analysis results are also displayed. This file is useful when you want to save an SOR file at a site where optical fiber cables are being installed and perform analysis at a different site.

- **.SET**

A file for saving the optical pulse measurement and analysis conditions. This file does not include waveform data or event list data. Loading this file into the instrument causes the saved measurement and analysis conditions to be applied to it. It can be used when setting the same measurement/analysis conditions for multiple instruments or when measuring/analyzing under the same conditions as in the past.

- **.PDF**

A file for saving the current waveform displayed on the instrument screen or waveform data of an already saved file in a PDF report format.

- **.CFG**

A file for saving the instrument system settings (device, connection, etc.). It can be used when setting the same system settings for multiple instruments or when using the same system settings as in the past.

- **.CSV**

A file for saving the results of optical pulse measurement or optical power meter measurement in ASCII format.

Measurement and analysis conditions are stored at the front of the file, and then data is stored in a comma-separated format.

This file is useful when you want to analyze the data using a spreadsheet application on the PC.

- **.BMP, JPG**

A file for saving a screen image of the instrument. This file is useful when you want to view the screen content on the PC screen. BMP and JPG files cannot be loaded into the instrument.

- **.SOZ**
A file for saving multiple waveforms measured simultaneously.
- **.SMP**
A file for saving waveforms measured with a feature equivalent to Smart Mapper.


Selecting Drives

You can set the save destination to the following internal and external memories.

- **Internal memory**
The memory inside the instrument. The size is about 1 GB. It cannot be removed.
- **USB memory**
USB storage device.
- **microSD memory**
microSD storage device.

Creating reports

You can save the current optical pulse measurement and analysis conditions, waveforms, and events as a report on a single sheet in a PDF file. You can choose which items to include in the report.




File reporting

You can specify several saved SOR files and save the content of the files one at a time as a report on a single sheet in a PDF file. You can choose which items to include in the report.

1.9 File Features

- Example where two waveforms are arranged on a single sheet



File operations

Copying and deleting files

You can copy or delete all the files and folders in the internal memory or external memory. You can also copy or delete selected files or folders.

Renaming files

You can rename existing files and folders.

Creating folders

You can create a folder with a name of your choice in which optical pulse measurement results are saved automatically. In the settings for automatically saving measure data explained in section 3.1, you can set the name of the folder in which to save the results automatically. When you select a folder that you created with a name of your choice, measurement results can be saved automatically to this folder.

1.10 System Features

Power-save mode

To suppress battery consumption, you can set the screen brightness and a screen saver. You can set different screen brightness levels for battery operation and USB-AC adapter operation.

LCD brightness

You can select from four brightness levels (including OFF). You can choose the appropriate level depending on the ambient light, such as during outdoor use. You can turn off the display except when viewing the measured data to suppress battery consumption.

Auto sleep

If the instrument is turned on and is not accessed for a certain time, the instrument automatically switches to sleep mode to suppress battery consumption.

Factory default settings

Setup

The following setup conditions are reset to their factory defaults. Note that files in the internal memory are not deleted.

- OTDR feature setup (chapter 3)
- Utility feature (chapter 7)
- Application feature (chapter 8)
- System settings (chapter 10, except the date and time)

All

All the above setup conditions are reset to their factory defaults. All the files in the USER folder of the internal memory are also deleted. The files in the following folders are not deleted.

- **USERS_MANUAL** (contains the user's manuals)

Configuring network settings

You can use Ethernet or a communication dongle (wireless LAN adapter) to remotely control the instrument from a PC (OTDR Remote Controller) and transfer measured results in the instrument's internal memory to a network server (File Transfer@OTDR Data Transporter).

User name and password

Set user names and passwords for authenticating connections from PCs to the instrument.

Ethernet

Ethernet can be used on models with the /LAN option.

- **Enabling and disabling network connection**

Remote control can be disabled. When disabled, a PC cannot connect to the instrument.

- **Timeout period**

If a communication command is not sent from a PC or measured results are not downloaded within the timeout period, the instrument releases the network connection.

- **TCP/IP**

Set network address information.

WLAN application (wireless LAN)

You can use a communication dongle (wireless LAN adapter) to remotely control the instrument from a PC (OTDR Remote Controller) and transfer measured results and other types of data from the instrument to a network server (OTDR Data Transporter).

- **Access point mode**

You can set network information for running the instrument as an access point. This is used to connect the instrument and terminals directly without connecting a wireless router or other network device.

- **Station mode**

This is used to connect the instrument to an access point.

LTE dongle

You can use an LTE dongle to connect to a PC, smartphone, and other terminals via mobile communication. This is useful when communicating over longer distances than WLAN.

Other features

Language selection

You can change the language used on the instrument screen. The available languages vary depending on the instrument's suffix code.

Start screen

You can select the screen that is displayed when the instrument starts.

- **Top Menu**

The MENU screen is displayed.

- **Start Menu to Last Function**

The screen of the feature that was executed immediately before the power was turned off is displayed.

Screen color

You can set the screen color (color 1 or color 2).

Alarm

The instrument can generate sound when the rotary knob is turned or when an operation error message is displayed.

UTIL key selection

You can assign one of the following features to the UTIL key. You can execute a feature that you use often with a single button.

- Save (see section 9.4)
- Report (see section 9.5)
- Utility menu screen (see section 7.1)
- Power meter (see section 7.4)
- Power checker (see section 7.5)
- Light source (see section 7.2)
- Visible light source (see section 7.3)
- Fiber inspection probe (see section 7.6)
- File name assignment (see section 9.4)

USB feature (Type-C)

You can use USB port type C to send communication commands from a PC to the instrument or download measured results and other types of data from the instrument internal memory or microSD memory card to a PC.

Operation lock

You can set a PIN to restrict the following operations. This feature prevents settings from being changed or laser light to be emitted by mistake.

- **Laser light output**

When an operation to emit the following laser light is performed

Optical pulse (OTDR), light source (measurement light), VLS

Expiration date

This feature displays a message at startup or locks the instrument when the specified expiration date arrives. You can display a message that urges you to calibrate the instrument or the like when the recommended calibration period elapses.

Version update

You can update the firmware by storing a new firmware in a USB memory device and connecting it to USB port type A.

Installing options


You can install additional option licenses (sold separately) for the AQ7290.

For details on the available option licenses, see Getting Started Guide, IM AQ7290-02EN.

1.11 Analysis Using the Emulation Software


Waveform data measured with the instrument can be analyzed on a PC by using the AQ7933 OTDR Emulation Software. This software also has a PDF report creation feature, which is convenient for creating construction reports.

Waveform data saved in SOR format using the instrument can be displayed on the PC using the emulation software.



Analysis results (displays at list of events)

Create a PDF construction report using the report creation feature of the emulation software.




2.1 Theme Selection Screen, Menu Screen, and Operation Screen

Theme selection screen

When you turn the instrument on and it starts, the theme selection screen appears.

Set the instrument's screen color to dark or light, and tap **Commit**.

This screen is displayed when the instrument is used for the first time after purchase or when the power is turned on after initializing the settings. This is the same setting as the background color setting in system setup.




MENU screen

When you turn on the instrument or press MENU, the menu screen appears.

First select a feature from the menu screen, and then configure the feature or carry out the measurement that corresponds to the feature you have selected.

Select it in the following manner.


- Select an icon with arrow keys or rotary knob, and press ENTER.
- Select a feature with the soft keys.
- Tap an icon on the screen.




Simple mode operation screen

This section explains the Simple OTDR operation screen.


Simple OTDR setting list



TRACE screen




MAP screen



Expert mode operation screen

This section explains the Expert OTDR operation screen.

TRACE screen



Soft key menu

There are three types of soft key menus depending on the function.

▶ OTDR

Set Start Marker

Set End Marker

To be set by Marker

◀ More

Approx. Method TPA

Pressing a soft key confirms the selected item or executes its corresponding action.

Pressing a soft key of a menu item with a ◀ mark displays a setup menu.


Pressing a soft key of a menu item with options switches the selected option.

MAP screen

Laser on indication

Auto save indicator (see section 3.1)

Color theme

Power supply icon display
When the power supply to the Type-C USB port, the power supply icon  blinks.

Switches to the TRACE screen.

Event information (marker/event)
(See section 1.4.)

Data display screen

Utility menu
Shows the light source, optical power meter, and other screens (see chap. 7)

Shows/hides the utility menu

Saves the displayed waveform (see section 9.4)

2025/01/27 14:14 Average 00:10

Total distance : 1.43325km

0km 0.500km 1km

1 402m 470.22m

2 872.69m

3 260m 1.133km

29

Press [AVG] to start the measurement.


Meas

No.	Distance (km)	Section (km)	Loss (dB)	Return Loss (dB)	Cum-Loss	dB/km	Type	Section IOR
1	0.47022	0.47022	0.178		0.104	0.237	↘	1.46000
2	0.87268	0.40246	0.113	61.417	0.355	0.181	↘	1.46000
3	1.13346	0.26078	0.198		0.515	0.178	↘	1.46000
E	1.43325	0.29979		11.225	0.755	0.140	↘	1.46000

2.2 Using the Rotary Knob and Arrow Keys

We will use the dialog box that appears when you press the OPM Setup soft key as an example to explain the rotary knob and arrow key operations.

Move the cursor to the item that you want to set using the arrow keys or the rotary knob.




The following setup operation patterns are available depending on the display button shape.




Press Enter to display following setup item.

Items set from a list of options



- Move the cursor to the item that you want to select using the arrow keys or the rotary knob.
- Press ENTER to confirm the selected item.

Items that require a value to be entered



A numeric keypad appears. Press ENTER to confirm the entered value.



→ Items toggle between on and off
Each time you press the key, the setting toggles between ON and OFF.



→ Press Enter to display the detailed setup screen.



→ Press Enter to confirm the selected item or execute its corresponding action.

2.3 Using the Touch Panel

Touch panel operations

The basic touch panel operations are described below.

Tap

Tap refers to the act of gently hitting the screen with your finger.


Tapping is used on the instrument screen to select areas with a mark, close a setup menu, and so on.



Drag

Drag refers to the act of pressing your finger against the screen and sliding your finger.

Dragging is used to display the setup menu, change the ratio of the waveform display area to the measurement condition display area, and so on.




Pinch out and pinch in


Pinch out refers to the act of pressing two fingers against the screen and spreading them apart. Pinch in refers to the act of pressing two fingers against the screen and drawing them together.

On a screen displaying waveforms, you can pinch out to zoom in and pinch in to zoom out.

Pinch out




Pinch in



Flick


Flick refers to the act of pressing your finger against the screen and moving your finger abruptly.

This is used to scroll on a menu display and the like.



Areas that you can use the touch panel to operate

Touch panel operations can be used in the following areas.



Switching the menu display

You can switch the menu display format as follows.


: The menu is displayed in a tabular form.

: The menu is displayed in a scrollable form.

Scrollable form



Tabular form





2.4 Setting the Date and Time

Selecting the language to display

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. The system setup screen appears.
3. Tap **Language**. A language setting menu appears.

System screen





Language setup menu
The languages that appear vary depending on the suffix code.

Selecting the date and time to display

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. The system setup screen appears.
3. Tap **Date & Time Set**. The following screen appears.

System screen



Set the year, month, and day.

Set the hour, minute, and second.

Confirms the settings
The set date and time are displayed in the upper left of the screen.

Set the date and time display format
(Off, Year/Month/Day Time, Day/Month/Year Time, Year, Month (name), Day Time).

Year, Month, and Date

The year is displayed in Western calendar year. The instrument supports leap years.


Hour, Minute, and Second

The hour can be set to a value from 0 to 23.

2.5 Entering Text

When you select a setting, a character input dialog box appears if necessary. This section explains the operation after a character input dialog box is displayed.

Entering alphanumeric characters



Switches the keyboard language

The languages that appear vary depending on the language setting.

Switches between uppercase and lowercase

3.1 Setting Measurement Conditions (Measure)


Procedure

Setting simple mode (Simple OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.



Simple OTDR setting list




3. Tap **Setup**, or press **SETUP**. A setup screen appears.

3.1 Setting Measurement Conditions (Measure)

4. Tap the **Measure Setup** tab. The following screen appears.

Measurement setup tab




Measure Setup | Analysis Setup | File Setup | System Setup | X

- Wavelength: SM 1310nm — Set the wavelength.
- Distance Range: AUTO — Set the distance range.
- Pulse Width: Auto — Set the pulse width.
- Average Duration: AUTO — Set the average duration.
- Fiber-In-Use Alarm: ON — Turns the fiber-in-use alarm on or off
- Auto Save: ON — Set auto save.
- Connection Check: OFF — Turns connection check on or off
- Default — Executes initialization
Press to reset the settings to their factory defaults.

Configuring Auto Save (when averaged measurement is complete)

Tap **Auto Save**. An auto save screen appears.

When the mode is set to Date




Auto Save X

- Auto Save: ON — Turns auto saving on or off
- Mode: Date — Set the mode (Date, UserDefine).
Select how to specify the save destination folder. You can set this when auto save is ON.
- File Type: [Icon] — Set the file type.
(SOR, SOR + PDF, SOR + BMP, SOR + JPG)
- File Name Setup: > — Set the file name.
See section 3.4.
- Drive: Int. Memory

Set the save destination drive (Int.Memory, SD Card, USB Memory 1, USB Memory 2).
This is displayed when the mode is set to Date, in which case you can set it.

When the mode is set to UserDefine



Auto Save X

- Auto Save: ON
- Mode: UserDefine
- File Type: [Icon]
- File Name Setup: >
- Save Folder: [List Box] — Displays the file list of the folder displayed in the current file path.
For details on file operations, see section 9.6.


Save destination folder
The current file path is displayed. This is displayed when the mode is set to UserDefine.

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.



3. Press **SETUP**. A setup menu appears.



3.1 Setting Measurement Conditions (Measure)

4. Press the **Measure Setup** soft key. The following screen appears.


Set the sample interval (Normal, Hi Resolution).

Set the distance range.

Set wavelength 1.

Set wavelength 2.

Set the pulse width.



The Measure Setup screen displays various configuration options. Annotations point to specific settings: Wavelength 1 (SM 1310nm), Distance Range (AUTO), Sample Interval (Normal), Average Unit (Duration), Average Method (Hi-Reflection), Fiber-In-Use Alarm (ON), Event Search (ON), OSW control Setup, Wavelength 2 (OFF), Pulse Width (Auto), Average Duration (AUTO), Attenuation (Auto), Connection Check (OFF), Auto Save (ON), Linkage of Realtime Sample Interval (OFF), and a Default button.

Set the average count or the duration to average over.

Set the attenuation.

Turns connection check on or off

Set auto save.
See page 3-2.*

Turns linkage of realtime sample interval on or off

Executes initialization
Press to reset the settings to their factory defaults.

Set up OSW control

Turns event search on or off

Turns the fiber-in-use alarm on or off

Set the average method (Hi-Speed, Hi-Reflection).


Set the average unit (Duration, Times).

* The screen displays slightly differently in expert mode and simple mode, but the items that can be operated are the same. See the simple mode instructions.

Setting up OSW control

Tap **OSW control setup**. An OSW control screen appears.

Set up OSW (AQ3550) control.



The OSW control Setup screen shows a 'Linkage OSW control' section with radio buttons for channels CH1 through CH12. CH1 is selected. A text box at the bottom indicates 'Select measurement target channels.'

Explanation

Wavelength

You can enter the following wavelengths.

Model	Optical Pulse Wavelength
AQ7292A	1310 nm, 1550 nm, 1310 nm/1550 nm (multi wavelength measurement)
AQ7293A	1310 nm, 1550 nm, 1310 nm/1550 nm (multi wavelength measurement)
AQ7294A	1310 nm, 1550 nm, 1310 nm/1550 nm (multi wavelength measurement)
AQ7293F	1310 nm, 1550 nm, 1650 nm, 1310 nm/1550 nm (multi wavelength measurement)
AQ7293H	1310 nm, 1550 nm, 1625 nm, 1310 nm/1550 nm/1625 nm (multi wavelength measurement)
AQ7294H	1310 nm, 1550 nm, 1625 nm, 1310 nm/1550 nm/1625 nm (multi wavelength measurement)

Multi Wavelength Measurement

Once the measurement is started, averaged measurement is taken at 1310 nm and 1550 nm or 1310 nm and 1550 nm and 1625 nm one wavelength at a time. The available wavelengths vary depending on the model. The order in which the wavelengths are measured can be changed.

Distance range

Set the distance range according to the length of the optical fiber cable. The distance range that you can select varies depending on the wavelength. Specify a distance range value that is greater than the length of the optical fiber cable that you will measure. If you specify a shorter value, the instrument will not be able to perform measurements properly. The longer the distance that you specify, the more time measurements will take. When you specify the distance range, the optimum pulse width and attenuation values are set automatically.

Cable Length	Distance Range
Unknown	AUTO
0 m to 160 m	200 m
160 m to 400 m	500 m
400 m to 800 m	1 km
800 m to 1.6 km	2 km
1.6 km to 4 km	5 km
4 km to 8 km	10 km
8 km to 16 km	20 km
16 km to 24 km	30 km
24 km to 40 km	50 km
40 km to 80 km	100 km
80 km to 160 km	200 km
160 km to 240 km	300 km
240 km to 320 km	400 km
320 km to 400 km	512 km

Pulse width

The pulse width has the following characteristics.

- A short pulse width enables you to measure with a high resolution, but you cannot measure long distances.
- A long pulse width enables you to measure long distances, but you cannot measure with a high resolution. Also, dead zones are larger with long pulse widths.

The pulse widths that you can select vary depending on the distance range, as shown in the following table.

Distance Range	Selectable Pulse Widths
100 m to 500 m	3 ns, 10 ns, 20 ns, 30 ns
1 km to 5 km	3 ns, 10 ns, 20 ns, 30 ns, 50 ns, 100 ns, 200 ns, 300 ns, 500 ns
10 km to 50 km	50 ns, 100 ns, 200 ns, 300 ns, 500 ns, 1 μ s, 2 μ s, 5 μ s
100 km to 512 km	50 ns, 100 ns, 200 ns, 300 ns, 500 ns, 1 μ s, 2 μ s, 5 μ s, 10 μ s, 20 μ s

Sample interval

The maximum number of sample data points is 256000. The sample interval is determined by the distance range.

Normal: The instrument uses the optimum sample interval for the measurement conditions to perform measurements.

Hi Resolution: The instrument uses a sample interval that would result in the greatest number of data points.

If you use a short sample interval, you can measure for finer changes. However, the data size of the measured result becomes large.

Attenuation

If large reflections are caused by connectors or by breaks in the optical fiber cable, the waveform may be saturated. Specify attenuation to prevent the waveform from being saturated. The attenuations that you can select vary depending on the pulse width, as shown in the following table.


Pulse Width (Example)	Selectable Attenuations
3 ns to 30 ns	0.00 dB, 2.50 dB, 5.00 dB, 7.50 dB, 10.00 dB, 12.50 dB
50 ns to 500 ns	0.00 dB, 2.50 dB, 5.00 dB, 7.50 dB, 10.00 dB, 12.50 dB, 15.00 dB, 17.50 dB, 20.00 dB
1 μ s to 5 μ s	0.00 dB, 2.50 dB, 5.00 dB, 7.50 dB, 10.00 dB, 12.50 dB, 15.00 dB, 17.50 dB, 20.00 dB, 22.50 dB
10 μ s to 20 μ s	0.00 dB, 2.50 dB, 5.00 dB, 7.50 dB, 10.00 dB, 12.50 dB, 15.00 dB, 17.50 dB, 20.00 dB, 22.50 dB, 25.00 dB, 27.50 dB, 30.00 dB

The attenuation is fixed to AUTO when the average method is Hi-Reflection.

Average method

Hi-Speed

In Hi-Speed mode, all sections are measured according to the specified attenuation. If the specified attenuation value is not appropriate and a large reflection occurs, the waveform for that section may be saturated.



Hi-Reflection

In Hi-Reflection mode, the instrument can perform measurements correctly even if large reflections (excluding extremely large reflections caused by sections of the fiber such as the open end of the fiber) occur. In Hi-Reflection mode, the instrument sets the optimum attenuation according to the backscatter level for each section, and performs the measurement. Therefore, the measurement time is longer than in Hi-Speed mode.

The partitioning of the optical fiber into sections and the specifying of the optimum attenuation are done automatically.

Note

Except when the optical fiber cable is short and there are no reflections, we recommend that you measure with the average method be set to Hi-Reflection.

Average unit

Time: Measurements are performed only over the specified duration. If you specify a short duration, depending on the measurement conditions, measurements may not have finished when the specified time elapses.

Count: Measurements are performed only the specified number of times.

Average times/average duration

You can select the following values.

Duration: 5s, 10s, 20s, 30s, 1 min, 3 min, 5 min, 10 min, 20 min, 30 min

S is seconds, and min is minutes.

Times: 2^{10} (1024 times), 2^{11} (2048 times), 2^{12} (4096 times), 2^{13} (8192 times), 2^{14} (16384 times), 2^{15} (32768 times), 2^{16} (65536 times), 2^{17} (131072 times), 2^{18} (262144 times), 2^{19} (524288 times), 2^{20} (1048576 times)
 2^{10} is 2 to the power of 10 (1024 times).

3.1 Setting Measurement Conditions (Measure)

- The maximum average count is 2^{20} . If you specify a duration to average over that causes this number of times to be exceeded, the measurement will finish before the duration to average over elapses.
- Due to the influence of other measurement conditions, a measurement may take less time than the duration you have specified or it may not complete when the specified duration elapses.
- If you specify a large value for the number of times or the duration, you can perform highly precise measurements, but the measurement time becomes longer. Keep the instrument's dynamic range and the loss of the optical fiber cable under measurement in mind when you specify these values.
- The display of the duration or the number of times is determined by the specified average unit.
- If AUTO is selected, one of the options above is used.

Event search

Event search is a feature that automatically searches for losses and reflections in the data that is acquired during averaged measurements. Losses and reflections detected in waveform data are known as events. See chapter 6 for the analysis of the detected events.

ON: After averaged measurements complete, events are automatically searched for and listed, and the event screen and event analysis menu are displayed.

OFF: After averaged measurements complete, the waveform is displayed, but events are not searched for.

Fiber-in-use alarm

The instrument uses the same wavelength that is used in real communication to measure optical pulses. If communication light is present in the optical fiber cable that you want to measure, the communication will be affected. When this communication light is present, we say that the fiber is in use. The fiber-in-use alarm is a feature that checks if communication light is being transmitted along the optical fiber cable that you are trying to measure. If the fiber is in use, a warning message is displayed asking whether you want to continue the measurement.

Connection check

The connection check is a feature that checks the state of the connection between the instrument and an optical fiber cable. When this feature is set to on, you can prevent light from being transmitted from the instrument OTDR port or light source port if an optical fiber cable is not connected to the instrument or if the cable is not connected correctly.

OFF: Connections are not checked.

ON: Connections are checked.

Auto save

After an averaged measurement of the optical pulse is complete, the measurement waveform is automatically saved.

Set the mode.

Select how to specify the save destination folder.

Date: Folders that are named with dates are automatically created in the selected drive.

UserDefine: Specify the save location folder.

Save location folder

Create a folder of your choice in advance in the selected drive, and select this folder as the save destination folder.

File type

Set the extension according to the type of data to be automatically saved.

Extension	Description
SOR	Waveform data measured from an optical pulse (including the measurement conditions) is saved in an SOR file format that conforms to Telcordia SR-4731.
SOR+PDF	Waveform data is saved as waveforms and as a report file simultaneously.
SOR+BMP	Both SOR and BMP files are saved.
SOR+JPG	Both SOR and JPG files are saved.

Linkage of realtime sample interval

This function links the sampling of averaged measurement and real-time measurement to measure pulses at the same sample interval. This function links the sampling of averaging measurement and real-time measurement to measure pulses at the same sampling interval. When this function is turned on, the same sample interval is used for averaged and real-time measurements, so the references of the measurement waveforms are aligned.

OFF: Sample intervals may differ between averaged and real-time measurements.

ON: Sample intervals for averaged and real-time measurements are aligned. The sample interval setting of the measurement conditions is applied.

During averaged measurement, pulse measurement is performed based on the sample interval (page "Sample interval" on page 3-6) setting of the measurement conditions. On the other hand, during real-time measurement, pulses are measured at the sample interval optimized in the instrument.

As such, if you perform a provisional pulse measurement using real-time measurement, check the waveform, and then perform a regular pulse measurement using averaged measurement, the measurement waveform reference may be different between the two.

Enabling this feature causes pulse measurements to be performed at the same sample interval, allowing the measurement waveform reference to be aligned.

Selecting measurement target channels

When "Linkage OSW control" is set to ON, the measurement of the next selected channel begins when the averaged measurement of the current channel is completed.

To use the Linkage OSW control feature, set Auto Save to ON. If Auto Save is set to OFF, waveforms cannot be saved because the display showing the measured waveforms is cleared when the target channel is changed.

3.2 Setting the Analysis Conditions (Analysis)


Procedure

Setting simple mode (Simple OTDR)


1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.



Simple OTDR setting list




3. Tap **Setup**, or press **SETUP**. A setup screen appears.
4. Tap the **Analysis Setup** tab. The following screen appears.



Setting Macro Bending (detecting bending loss)

5. Tap **Macro Bending**. A Macro Bending screen appears.



3.2 Setting the Analysis Conditions (Analysis)

Setting a launch fiber

5. Tap the **Launch Fiber Setting** tab. A Launch Fiber Setting screen appears.

Specify the launch fiber section using the distance from the end point (E).

Specify the launch fiber section using an event number.

Launch Fiber Setting

Set on Event Number

From Start

None

From End

None

Set on Distance

From Start

0.00m

From End

0.00m

Total RL Mode

Exclude END

Show END Point Loss

OFF

Set the start event (None, 1, 2).

Set the end event (None, 1, 2).

Set the distance from the start point (S) (0.00 m to 9999.99 m).

Set the distance from the end point (E) (0.00 m to 9999.99 m).

Calculation method for total return loss (Include END, Exclude END).

Turns END point loss display on or off

Setting pass/fail judgments

5. Tap **Pass Fail Judgment**.

6. Tap **dB/km, Total Loss**. The following screen appears.

dB/km

1310nm

1.00dB

1550nm

1.00dB

Total Loss

1310nm

10dB

1550nm

10dB

Set the loss threshold per kilometer for each wavelength (0.01dB to 9.99dB).

Set the total loss threshold for each wavelength (1dB to 65dB).

3-12


IM AQ7290-01EN

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.




3. Press **SETUP**. A setup menu appears.



3.2 Setting the Analysis Conditions (Analysis)

4. Press the **Analysis Setup** soft key. The following screen appears.



Set the IOR/backscatter level. See 3-16.

* The screen displays slightly differently in expert mode and simple mode, but the items that can be operated are the same. See the simple mode instructions.

Setting pass/fail judgments


5. Tap **Pass Fail Judgment**. A Pass Fail Judgment screen appears.
6. Tap the **Event** tab. The following screen appears.

Set the connector loss threshold (0.01dB to 9.99dB).

Set the splice loss threshold (0.01dB to 9.99dB).

Turns the pass/fail judgment on or off

You can select items when Pass Fail Judgment is set to ON.




- **Setting the splitter loss**

7. Tap **Splitter Loss**. A Splitter Loss screen appears.

Set the number of splitter stages (None, 1, 2).

Includes the number of splitter stages in the judgment conditions



Splitter loss judgment conditions

When either of the following conditions is met, it is recognized as a splitter event and displayed along with the number of splits.

- When the number of detected splitter splits is different from the setting
- When the detected splitter loss is greater than the splitter loss threshold of each split

3.2 Setting the Analysis Conditions (Analysis)

Setting marker pass/fail judgments

5. Tap **Pass Fail Judgment**. A Pass Fail Judgment screen appears.
6. Tap the **Marker** tab. The following screen appears.

Set the loss threshold between markers (①-②, ②-③) (0.01 dB to 9.99 dB).

Set the splice loss threshold (0.01dB to 9.99dB).

Turns the marker judgment on or off

You can select items when marker judgment is set to ON.

Marker tab

Selecting the option button of each judgment item enables its pass/fail judgment.

Set the return loss threshold (20dB to 70dB).

Set the threshold for the loss between markers (A - D) (0.10dB to 65.00dB).

Set the threshold for the loss between markers (A - B, C - D) (0.01dB to 9.99dB).

Set the level threshold for waveform heights between markers (A, B, C, D) (0.01 dB to 50.00 dB).

Set the dB/km threshold between markers (①, ②, ③) (0.01 dB to 9.99 dB).

Setting the IOR/backscatter level

5. Tap **IOR/Backscatter Level**. An IOR/Backscatter Level screen appears.


Set the IOR each wavelength (1.30000 to 1.79990).

Set the backscatter level base (1μs, 1ns).

Set the backscatter level for each wavelength.
1 μs pulse width*: -10.00 dB to -64.99 dB
1 ns pulse width*: -40.00 dB to -94.99 dB
* Pulse width used as a base for the backscatter level

Setting the splitter loss

5. Tap **Splitter Loss**. A Splitter Loss screen appears.



Loss threshold for each number of splitter splits

The loss threshold varies from 1.0 dB to 20.0 dB depending on the loss setting of the number of adjacent splitter splits.

Example of 4 branches:

If the adjacent “2 branches” is 3.0 dB and the other adjacent “8 branches” is 9.0 dB, the setting range of the loss threshold for the “4 branches” is 3.0 dB to 9.0 dB.

Explanation

Splice loss

If a splice loss that exceeds the specified threshold occurs, it is detected as an event.

The range is 0.01 dB to 9.99 dB.

Return loss

If a return loss that is less than or equal to the specified threshold occurs, it is detected as an event.

The larger the reflection, the smaller the return loss, so events (reflections) are detected when the return loss is less than or equal to the threshold.

The range is 20 dB to 70 dB.

End of fiber

If a reflection that exceeds the specified threshold occurs, it is detected as the end of the optical fiber cable (Fresnel reflection).

The range is 3 dB to 65 dB(AUTO).

Splitter loss

Events whose loss exceeds this value are assumed to be optical splitters according to the number splits.

The range is 1 dB to 20 dB.

Macro bending (bending loss)

When an optical pulse measurement is performed in multi wavelength measurement (when wavelength setting is 1310 nm/1550 nm or 1310 nm/1550 nm/1625 nm), you can compare the splice losses at each wavelength and display on the screen bending loss events that are caused by bends in the optical fiber cable.

Extension

This function displays the detected bending losses in the event list on the event screen when optical pulses are measured.

OFF: The bending losses are not displayed in the event list.

ON: The bending losses are displayed in the event list.

Threshold


This is the threshold of the difference between the splice losses of each wavelength when optical pulses are measured.

When the difference between the splice losses of each wavelength for the same event is larger than this value, the event is detected as a bending loss.


The range is 0.001 dB to 99.999 dB.

Launch fiber setting

When you connect a launch fiber cable to avoid near-end dead zones, you can set the launch fiber cable events (start point and end point) or start position so that the event information in the launch fiber section is excluded from the analysis conditions.



The same operations can be performed from the following screen while the event analysis screen is being displayed.



Pass fail judgment

A judgment is performed on the events detected in the target waveform, and those that exceed the specified threshold are displayed as fault events on the event screen.

- ON: Pass/fail judgment is set to ON, and events that have exceeded their thresholds are displayed with an asterisk attached to them (see section 1.5).
- OFF: Pass/fail judgment is set to OFF, and events that have exceeded their thresholds are not displayed with an asterisk attached to them.

Marker pass fail judgment

A judgment is performed on the marker values detected in the target waveform, and those that exceed the specified threshold are indicated as Fail on the marker analysis screen.

- ON: Pass/fail judgment is set to ON, and Fail is indicated for marker values that have exceeded their thresholds (see section 1.5).
- OFF: Pass/fail judgment is set to OFF. Fail is not indicated even if marker values have exceeded their thresholds.

Approximation method

When the instrument calculates splice loss, it extrapolates straight lines. These straight lines are known as approximation lines.

There are the following two kinds of approximation lines.

- Least squares approximation (LSA)
- Two point approximation (TPA)

LSA


The instrument calculates the loss between two points by using the least squares method on all the data between the two points (between 1 and 2).

This method has the following characteristics.

Advantage: Because all the data between the two points is used, errors in the calculated value are small. Fluctuations in the calculated values are reduced, and highly reproducible values can be obtained.


Disadvantage: If a large reflection or splice loss is present in the section whose loss is being calculated, those values are also included in the calculation, so large errors result.

If no events such as reflections and splice losses are present in the section being calculated, the LSA provides a value that has a smaller degree of error than the TPA.



TPA

The instrument uses the difference between the levels of the two specified points to calculate the loss. The level of fluctuation and reproducibility in the calculated value may vary greatly. If events such as reflections and splice losses are present in the section being calculated, the TPA provides a value that has a smaller degree of error than the LSA.



Backscatter level

Light that travels through an optical fiber cable displays a phenomenon known as Rayleigh scattering. Due to this phenomenon, light is sent backwards, in the direction opposite to the direction of propagation. This phenomenon is known as backscattering. The backscatter level setting is used when the instrument calculates the return loss and total return loss.

If you do not set the correct backscatter level, the return loss and total return loss measurements will be incorrect.

On the instrument, you can select the reference pulse width for the backscatter level (see section 3.2). The selectable range of backscatter levels vary depending on the reference pulse width.

1 μ s: The range is –10.00 dB to –64.99 dB.

1 ns: The range is –40.00 dB to –94.99 dB.

The instrument has the following preset backscatter levels that correspond to each wavelength.

Wavelength	1 μ s pulse width	1 ns pulse width
1310 nm	–50 dB	–80 dB
1550 nm	–52 dB	–82 dB
1625 nm	–53 dB	–83 dB
1650 nm	–53 dB	–83 dB

IOR

The instrument uses the index of refraction to calculate the distance. If you do not set the index of refraction correctly, the distance measurement will be incorrect. The index of refraction varies depending on the connected optical fiber cable. Enter the value recommended by the manufacture of the cable.

The instrument has the following preset indices of refraction that correspond to each wavelength.

Wavelength	IOR
1310 nm	1.46000
1550 nm	1.46000
1625 nm	1.48000
1650 nm	1.48000

The range is 1.30000 to 1.79999.

Splitter loss

If splitters are inserted, you can select whether to detect the losses caused by them.

If you set a threshold for each number of splitter splits, the number of splitter splits can be determined automatically from the measured loss. The loss threshold varies from 1.0 dB to 20.0 dB depending on the loss setting of the number of adjacent splitter splits.

3.3 Setting Display Conditions (OTDR)


Procedure

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.



3. Press **SETUP**. A setup menu appears.



4. Press the **OTDR Setup** soft key. The following screen appears.

Set the total loss calculation method (Cumul-Loss, Loss between S and E).

Cumulate: Integrated value of events

Between two points: Loss between S and E


Turns marker information display on or off

Displays on the screen the distance and loss value at the marker position.

Turns ghost cursor display on or off

This is for checking secondary reflections.

Set the marker mode (Marker, Line).



Turns approximated line display on or off
Displays an approximated line for waveform events.

Select the measurement distance unit.
This menu is not available on -HJ suffix code.

Select the reflection display (Return Loss, Reflection Level).

Set the cursor display method (CROSS(+), Line(|)).

Calculation method for total return loss (Include END, Exclude END).

Turns END point loss display on or off

Distance decimal places (.**, **.*, **.*)****

Turns the cursor dB display on or off

Locks screen operations

Screen operations can be locked after a given time elapses.

Configure the work completion notification.
Configure settings that indicate that the optical fiber cable being installed has reached the destination with an alarm or the like.

dB decimal places (.**, **.*, **.*)****

Set the cumulative loss type (Type1, Type2, Type3).

Select the cumulate loss calculation method.

Setting the cumulative loss type

5. Tap **Cumul-Loss Type**. A Cumul-Loss Type screen appears.



Cumulate loss type


With Type1, loss is measured from the measurement start point to the measurement point.
With Type2, loss is measured from the event marker (Y2) to the measurement point.
With Type3, loss is measured from the approximation line of the event marker (Y2) to the measurement point.

For each type, the loss measurement range varies depending on whether the distance reference is set (top illustration in the screen) or not set (bottom illustration in the screen). For details, see “Explanation” in this section.

Setting operation lock

5. Tap **Operation Lock Setup**. An Operation Lock Setup screen appears.

Enter the administrator PIN (the default value is 0000).



Enter the new administrator PIN again for confirmation.

6. Tap **Operation Lock Setup**. The following screen appears.

Select the restriction mode.

- No Check: Operation possible without entering the PIN.
- Check only once: Enter the PIN only for the first operation.
- Check everytime: Enter the PIN for every operation.

Enter the old user PIN
(the default value is 0000).

Enter the new user PIN.

Confirms the input

Enter the new user PIN again for confirmation.

Configure the work completion notification.

5. Tap **Work Completion Notice Setup**. A Work Completion Notice Setup screen appears.

Turns completion notification on or off

Turns the alarm sound after work
completion on or off

Set the confirmation message.

Set how to display the message confirming whether you
have moved the cursor to the work completion point.

Turns the message display after work completion on or off


Explanation

Marker mode

Markers

Move the cursor to the location that you want to measure, and set a marker. When you are measuring return loss and splice loss, they are calculated automatically when you set all the markers that are necessary for the measurement method that you are using. For instructions on how to use markers, see section 6.1.


Example of 4 Point Markers: Marker ① ② Y2 ③



Line

After you select the line marker that you want to operate from a set of multiple line markers, move the selected line marker directly. The value of the line marker's section is calculated, and the return loss and splice loss are measured. Each value is calculated in real time as you move the line marker. For instructions on how to use line markers, see section 6.1.

Example of 5 Point Markers: Line n N E F f



Note


Line is often used outside of Japan. Marker is often used within Japan. It is used on existing YOKOGAWA models.

Displaying approximation lines


In the 4 Point (marker mode set to Marker) or 5 Point (marker mode set to Line) marker modes, you can display the approximation lines that are used to calculate splice loss or return loss.

- OFF: Approximation lines are not displayed.
- ON: Approximation lines are displayed.

Example of 4 Point Markers: Marker ① ② Y2 ③




Example of 5 Point Markers: Line n N E F f



Event list display

You can select the items to show in the event list.




Ghost cursor

The ghost cursor is used to check for secondary reflections. A secondary reflection is a reflection that is detected in a location where no event actually occurs. The ghost cursor is automatically displayed at twice the distance from where the cursor (primary) is placed. The ghost cursor moves in sync with the cursor (primary).

OFF: The ghost cursor is not displayed.

ON: The ghost cursor is displayed.



How secondary reflections are generated

The optical pulse that is generated from position I in the following figure propagates in the direction of II.

↓


Light ray A that is reflected at connection II in the figure is reflected again at connection I and propagates in the direction of II as light ray B.

At this point, the instrument detects A as an event.

↓

B is again reflected by connection II, and this generates reflected light ray C. At this point, the instrument detects C as an event.

Because the instrument measures all the reflected light rays, A, C, and D, C is also detected as an event in the same manner that an actually generated reflection is. Therefore, while there is no actual event in this location, it appears as if an event has in fact occurred.




Distance unit

Set the unit of distance to show in the screen. The default setting is km.

Marker information

You can display the distance from the measurement reference point to each marker on the waveform display area.


- OFF: Marker information is not displayed.
- ON: Marker information is displayed.



Reflection display (when the suffix code is -HJ)

You can set the reflection display at the calculation result display area of measurement data to either of the following settings.

- Return loss: The ratio of the incident optical power level and the reflected optical power level is displayed.
- Reflection level: The reflected optical power level is displayed.




Cursor dB value

You can display not only the distance at the cursor position, but also the dB value.

OFF: Only the distance at the cursor position is displayed.


ON: The distance and the dB value at the cursor position are displayed.

Marker mode



dB value at the cursor position

Event analysis




dB value at the cursor position

Calculation method for total loss


Cumulate loss

The integrated value of the splice losses at each event from the measurement reference point (S) is displayed. This is the conventional calculation method.



Loss between S and E

The loss (TPA approximation method) between the measurement reference point (S) and the end of fiber (E) is displayed.



Note


If Loss between S and E is selected, markers ① and ② are placed automatically at the measurement reference point (S) and the END point (E) when event analysis is executed.

Calculation method for total return loss

Select whether to include the return loss value at the end of fiber (E) in the total return loss.

Include END: The value at END point is included in the total return loss. This is mainly used when a launch fiber is connected to the far end of the optical fiber cable under measurement and end event T is set in the launch fiber settings. The END point and launch fiber connection are also included in the calculation of the total return loss.


Exclude END: The value at END point is not included in the total return loss.



Display of the END point loss

ON: The END point splice loss is shown in addition to return loss. This is mainly used when a launch fiber is connected to the far end of the optical fiber cable under measurement and end event T is set in the launch fiber settings. The splice loss at the END point is calculated, and the value is displayed. Consequently, the splice loss at the connection point of the optical fiber under measurement and launch fiber will also be displayed correctly.

OFF: The splice loss at the END point is not displayed.




Cumulate loss type

You can select the cumulative loss measurement method from the following three types in the event analysis settings.


Type 1 (without distance reference)

This method does not include the near-end reflection in the cumulate loss value. The loss from measurement start point S to the start point of event No. 1 is measured.




Type 1 (with distance reference)

This method includes the near-end reflection in the cumulate loss value. The distance reference is set to the start point of the near-end reflection. The loss from distance reference R to the start point of event No. 1 is measured.




Type 2 (without distance reference)

This method does not include the near-end reflection in the cumulate loss value. The loss is measured using the same method as type 1 (without distance reference).




Type 2 (with distance reference)

This method does not include the near-end reflection in the cumulate loss value. The distance reference is set to the start point of the near-end reflection. The loss from near-end reflection end point Y2 to the start point of event No. 1 is measured.




Type 3 (without distance reference)

This method includes the near-end reflection in the cumulate loss value. The loss is measured from where the approximation line between measurement start point S and event No. 1 intersects distance 0 km to the start point of event No. 1.



Type 3 (with distance reference)

This method includes the near-end reflection in the cumulate loss value. The distance reference is set to the start point of the near-end reflection. The loss is measured from where the approximation line between end point Y2 of the near-end reflection and event No. 1 intersects distance 0 km to the start point of event No. 1.



dB Decimal

You can select the number of decimal places of the dB display.

**.: 1 decimal place

.:: 2 decimal places

.:*: 3 decimal places

Distance decimal

You can select the number of decimal places of the distance display.

** .***: 3 decimal places

** .****: 4 decimal places

** .*****: 5 decimal places

Operation lock

You can lock the following operations using a PIN (password).

Operations that can be locked

- This instrument's emission of light
- The REAL TIME and AVG keys of the OTDR function
- The visible light source ON soft key when a light source option (/VLS) is installed
- The light source ON soft key
- The LS Power Adjust soft key in an auto loss test (LS, loopback test)
- The LS Power Adjust soft key in a multi-fiber loss test (LS, loopback test)
- The Loss Test START soft key for executing the LS or loopback test of the auto loss test
- The Loss Test START soft key for executing the multi-fiber loss test

3.3 Setting Display Conditions (OTDR)

PIN

The following two PINs are available.

- **User PIN**

A PIN required to perform the above operations. The default value is 0000.

- **Administrator PIN**

A PIN required to set the user PIN and restrict the above operations.


The default value is 0000.

Cursor display format


You can select the cursor display format from the following.

CROSS(+): The position on the waveform is displayed with vertical and horizontal cursors that intersect.

LINE(): The position on the waveform is displayed with a vertical cursor.



Crosshair display



Line display

Work completion notice

See section 4.2.

3.4 Setting File Conditions (File)


Procedure

Setting simple mode (Simple OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.




Simple OTDR setting list



3.4 Setting File Conditions (File)

3. Tap **Setup**, or press **SETUP**.
4. Tap the **File Setup** tab. The following screen appears.



Initializes the instrument's internal memory (inside the internal memory).


Setting the file name

5. Tap **File Name Setup**. A file name setup screen appears.

Set the file name type.

(ID number, wavelength, distance range, pulse width, attenuation, average method, time, Comment 1 to Comment 10, Company Name, Name, Cable ID, Fiber ID, Cable Code, Originating Loc (A), Terminating Loc (B), OSW CH number)

Set the items that will be displayed into parts ① to ⑩ of the file name.



File name that will be assigned

If the value is AUTO, the actually selected values are displayed in parentheses.

Setting the direct save method

5. Tap **Direct Save Setup**. A Direct Save Setup screen appears.




The selected save destination is displayed.

Displays the file list of the folder shown in Save Folder.
For details on file operations, see section 9.6.

Setting the report format

5. Tap **Report Setup**. A Report Setup screen appears.



Note

For details on the items, see "Explanation" in this section.

Setting the file report format

5. Tap **File Report Setup**. A File Report Setup screen appears.

ID Position (Top, Bottom)

Set the ID position of the file name. You can select this when the order is set to ID.

Order (File Name, Date, ID)

Select the file export order (by file name, by date, by ID).

Number waveforms to display (1Trace, 2Trace)

Select the number of waveforms to show in a single page.

You can select the following items only when 2Trace is selected.

**Sort Order
(A → Z, Z → A)**
Selects the
output sort
order.

File Name	Date
A 1310nm_001	15:00
B 1310nm_002	09:00
C 1550nm_001	12:00
D 1550nm_002	18:00

**Preview of the
order in which
files will be
exported.**

Event List preview

Automatically arranged
according to the on/off state
of display items


Event list display items ON/OFF

Set the items you want to display to ON.
Up to 5 items can be set to ON.

Report format setup
See the previous page.


Format example (when the report format is 2Trace)

The report of file C is shown on the left and that of file D on the right.



Setting comments

5. Tap **Comment Setup**. A Comment Setup screen appears.



Comment Setup

Comment 1

Comment 2

Comment 3

Comment 4

Comment 5

Comment 6

Comment 7

Comment 8

Comment 9


Comment 10

Set a comment (up to 30 characters).
Enter a comment by following the procedure in section 2.5.

Setting a label

5. Tap **Label Setup**. A Label Setup screen appears.

Label, Company Name, Name, Cable ID, Fiber ID, Cable Code, Originating Loc (A), Terminating Loc (B)
Enter each item by following the procedure in section 2.5. You can enter up to 36 characters.



Label Setup

Label

Company Name

Name

Cable ID

Fiber ID

Fiber Type

Cable Code

Current Data Flag

Location(A)

Location(B)

Use File ID No.

Direction

Set the fiber type
(652:Conventional SMF, 653:Dispersion Shifted SMF, 654:Cut-Off Shifted SMF, 655:Non-Zero Dispersion Shifted SMF, 656:NZDSF for Wideband Transport, 657:Bend Optimized SMF, 651:Multi-Mode Fiber)

Set the current data flag
(BUILT (BC), REPAIRED (RC), OTHER (OT), and CURRENT (CC)).

Direction (A -> B, B -> A)
Shows from which side the optical fiber cable connecting the start position (A) and stop position (B) was measured.


Select the check box to use the file ID (ID number) as the fiber ID.
For details on ID numbers, see "Setting the File Name" on page 3-36.

Setting expert mode (OTDR)


1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.



3. Press **SETUP**. A setup menu appears.



4. Press the **File Setup** soft key. The following screen appears.



* The screen displays slightly differently in expert mode and simple mode, but the items that can be operated are the same. See the simple mode instructions.

Explanation

File names and comments

You can select up to 10 items to be used for file names. The items specified for fields ① to ⑩ under Name Type are displayed in order as a file name. The longest file name is 60 characters.

Item	Description
ID No.	<p>Four digit number</p> <p>The setting range is 0 to 9999. Four characters are assigned for the file name. For example, if you set the number to "1," "0001" will be used in the file name.</p> <p>One character (tape number)</p> <p>If you select to use the ID number for the file name, when Tape Number Type is set to anything other than OFF, the tape number is automatically appended to the ID number.</p> <p>Example: If you have a combination of ID No. "0" and Tape Number Type "a to c (3)," the file names will be set as follows: 0000a → 0000b → 0000c → 0001a → 0001b → 0001c.</p>
Wavelength	Six characters containing the wavelength number and unit (Example: 1310 nm)
Comment	Up to 30 characters. However, because the entire file name must be within 60 characters, you may not be able to set 30 characters.
Company Name	You can select some of the label items. For details, see the table under "Label" later in this section.
Name	
Cable ID	
Fiber ID	
Cable Code	
Originating Loc (A)	
Terminating Loc (B)	

- If the whole file name is longer than 60 characters, the excessive characters will be deleted.
- Blank cannot be specified for field ① under Name Type.
- You cannot set duplicate items for Name Type.

Types of Characters and Strings Allowed in File and Folder Names

The following restrictions apply to the types of characters and strings allowed in file and folder names.

- The following exact strings cannot be used due to MS-DOS limitations:
AUX, CON, PRN, NUL, CLOCK, CLOCK\$, LPT0, LPT1, LPT2, LPT3, LPT4, LPT5, LPT6, LPT7, LPT8, LPT9, COM0, COM1, COM2, COM3, COM4, COM5, COM6, COM7, COM8, COM9
- Of those characters on the keyboard that appears on the screen, the characters that can be used are 0-9, A-Z, a-z, _, -, =, (,), {, }, [,], #, \$, %, &, ~, !, ', and @.
@ cannot be entered consecutively.
- Keep the full path name (absolute path from the root folder) within 200 characters.
If this is exceeded, an error will occur when you perform file operations (save, copy, rename, create folder, etc.).
Full path name: When you are operating a folder, it is the path up to the folder name.
When you are operating a file, it is the path up to the file name.

Direct save

Setting the file type

Set whether to make the measurement results to be saved into waveform data or a report.

SOR: Saved as waveform data

PDF: Saved in a report format

SOR+PDF: Both waveform data and report format are saved simultaneously.

SOR+BMP: Both waveform data and BMP data are saved simultaneously.

SOR+JPG: Both waveform data and JPG data are saved simultaneously.

BMP: Saved as BMP data

JPG: Saved as JPG data

Linkage: Saved with the same file type selected in the file list.

Setting the save action

Set how to save the file when you save data.

Direct save: A file name as assigned automatically according to the file name setup conditions, and the file is saved.

Select ID: A file name as assigned automatically according to the file name setup conditions. Then, you set a 2-digit ID to be appended to the file name. Finally, the file is saved.

Report format

Measure conditions (Job Information)

The following information is included.

Label	Originating Loc (A)	
Company Name	Terminating Loc (B)	
Name	Current Data Flag	
Fiber ID	Direction	
Fiber Type	Supplier Name ¹	
Cable ID	Model Name ¹	
Cable Code	Unit Name ¹	
Report creation date and time ¹	FW Ver. ^{1, 2}	1 Automatically included by the instrument
	Calibration Date	2 Firmware version

Information such as label and company name can be specified on the Label Setup screen explained in "Setting Labels." Set these if necessary.

Measured results (Link Summary)

The following information is included.

- Total distance
- Total loss
- Total return loss
- Number of events
- Fault events
- Pass/fail judgments
- Measured date

Fiber surface image


OFF: The fiber end face image is not included in reports.

Manual: The fiber end face image is included in reports. The end face image is selected manually.

AUTO: The fiber end face image is included in reports. The end face image with the same number as the serial number of the report is retrieved and automatically included in the report. If the number is not available, select the end face image manually as in Manual.


Map, Waveform, Marker Information, Measurement Conditions, and Overview

These are included as shown below.



- Map**

The events in the event list are mapped as icons. Up to 100 events can be mapped. For a description of icons, see section 1.3.



3.4 Setting File Conditions (File)

Event search conditions

The following information is included.

- Splice loss
- Return loss
- End of fiber
- Splitter loss
- Backscatter level
- Macro bending

Pass fail judgment conditions

The following information is included.

- Connector loss
- Splice loss
- Return loss
- Splitter loss
- dB/km
- Total loss

Event list setup

The following information is included.

- Event number
- Distance
- Section
- Splice loss
- Return loss
- Cumulate loss
- dB/km
- Event type
- Section group index

Report format

If the file action is set to File Report, you can select the number of waveforms to display in a page.

If you select 2Trace, you can select the export order, sort order, and event list items.

Number of waveforms to display (report format)

1Trace: The waveform information of a single file is included in a single page.

2Trace: The waveform information of two files is included in a single page.

Sort by

Select the file export order when exporting multiple selected files to PDF.

File name: Files are exported to PDF in order by the file name string.

Date: Files are exported to PDF in order by date.

ID: Files are exported to PDF in order by ID number.

ID position

Set where in the file name the ID (ID number) of the selected file is located.* Files with ID numbers set to positions other than top or bottom cannot be exported to PDF in the correct order.

* For file name format, see page 3-36.

Top: The four digit number in the beginning of the file name is identified as the ID number.

Bottom: The four digit number in the end of the file name is identified as the ID number.

Sort order

A -> Z: In the case of numbers, the order is 0 to 9. In the case of alphabet characters, the order is a to z.

Z -> A: In the case of numbers, the order is 9 to 0. In the case of alphabet characters, the order is z to a.

Event list setup

Set the items to show in the event list. If the number waveforms the display (report format) is 2Trace, up to five items can be displayed in the event list. If five items are specified, other items cannot be specified.

OFF: Events are not displayed in the event list.

Items other than OFF: Selected items are displayed in the event list.

Setting labels

You can set the following items. If you save waveform data measured from an optical pulse to a file in SOR format, the following label information is also saved.

Item	Description
Company Name	Up to 36 characters
Name	Up to 36 characters
Cable ID	Up to 36 characters
Fiber ID	Up to 36 characters
Fiber Type	652:Conventional SMF General purpose single mode
	653:Dispersion Shifted SMF Dispersion shifted
	654:Cut-Off Shifted SMF Cut-off shifted
	655:Non-Zero Dispersion Shifted SMF Non-zero, dispersion shifted, single mode
	656:NZDSF for Wideband Transport Wideband non-zero, dispersion shifted, single mode
	657:Bend Optimized SMF Bend optimized single mode
	651:Multi-Mode Fiber Multi mode
Cable Code	Up to 36 characters
Originating Loc (A)	Up to 36 characters
Terminating Loc (B)	Up to 36 characters
Current Data Flag	Shows the operation state. BUILT (BC), REPAIRED (RC), OTHER (OT), and CURRENT (CC)

4.1 Performing Averaged Measurements

In averaged measurements, the data that is acquired from each pulse is averaged and displayed. In simple mode, analysis results are displayed in MAP mode. In expert mode, analysis results are displayed in TRACE or MAP mode.



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Setting simple mode (Simple OTDR)

In this mode, the absolute minimum amount of measurement conditions are set. You only have to set the wavelength. Conditions such as distance range, pulse width, and event search are set automatically at the start of the measurement.

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.
3. Tap **TRACE**. A TRACE screen appears.



4.1 Performing Averaged Measurements


4. Tap **Wavelength** to set the wavelength.



Executing an averaged measurement

5. Press **AVG**. The measurement starts, and the analysis results are displayed.
- During averaged measurement, the duration to average over or the progress is displayed in the top area of the screen. Also, during measurement, a mark appears at the top of the display to indicate that the laser light is on. When averaged measurements are completed, measurement is stopped automatically, event analysis is executed, and the analysis results are displayed on the screen. If you press AVG again during averaged measurement, measurement is stopped.

Analysis results (MAP screen)



Average duration or progress


If the average duration is set to AUTO, the duration to average over is displayed in the top area of the screen.

If set to any other value, the progress is displayed. When the measurement completes successfully, 100% is displayed. The time it takes to complete a measurement varies depending on settings such as the distance range and the average count.

6. Tap **TRACE**. Analysis results are displayed in TRACE mode.



Analysis results (TRACE screen)



Shows
operating
instructions

Note

If distance range and pulse width are set to auto, the instrument automatically selects the optimal values internally immediately before starting a measurement. Change these values if necessary. For details, see section 3.1.

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.
3. Tap **Wavelength** to set the wavelength.




Executing an averaged measurement

4. Press **AVG**. The measurement starts, and the analysis results are displayed.

During averaged measurement, the duration to average over or the progress is displayed in the top area of the screen. If the average duration is set to AUTO, the duration to average over is displayed in the top area of the screen. If set to any other value, the progress is displayed. When the measurement completes successfully, 100% is displayed. Also, during measurement, a mark appears at the top of the display to indicate that the laser light is on. When averaged measurements are completed, measurement is stopped automatically, event analysis is executed, and the analysis results are displayed on the screen. If you press AVG again during averaged measurement, measurement is stopped.

Analysis results (TRACE screen)



The menu that can be used during averaged measurement or the menu that can be used after averaged measurement is displayed automatically depending on the usage condition.

Menu during averaged measurement

Marker	Marker operation See section 6.1.
Comment	Set comments. See section 3.4.
Label	Set labels. See section 3.4.

Menu after averaged measurement

The event analysis menu appears.

Display

List

Event Edit/Fix

2-point Marker

Rotary Knob

Event

Switches the event analysis result display (Summary, List, Detail)
This is the same function as switching the analysis result display.

Edit or fix events.

2 Point Markers
See section 6.1.

Selects the rotary knob function (Cursor, Event)
The setting is retained even if you turn off the power.

5. Tap **MAP**. Analysis results are displayed in MAP mode.



Analysis results (MAP screen)

2025/01/22 09:31 Average 00:00 dark Coarse 4090

Total distance : 2.13705km

0km 1km 2km

915m 259m 82.6m 361m

1.433km 1.692km 1.775km 2.13705km

Shows the setup screen

Press [AVG] to start the measurement.

Meas

List of events

No.	Distance (km)	Section (km)	Loss (dB)	Return Loss (dB)	Cum-Loss	dB/km	Type	Section IDR
3	1.69249	0.25924	0.574	72.657	16.849	11.531	↗	1.46000
4	1.77514	0.08265	0.283		17.375	-0.580	↘	1.46000
E	2.13705	0.36191		67.859	21.256	9.942	↗	1.46000

Press the Meas tab to set the wavelength. Press the AVG key to start averaged measurement while maintaining MAP mode.

Note

If distance range and pulse width are set to auto, the instrument automatically selects the optimal values internally immediately before starting a measurement. Change these values if necessary. For details, see section 3.1.

Explanation

Averaged measurement (AVG)

In averaged measurements, the data that is acquired from each pulse is averaged and displayed as a waveform. In averaged measurements, the signal-to-noise (S/N) ratio improves. This is effective when you want to detect faint events that are buried in noise.

Distance range

With the auto setting, the instrument detects the open end (end point) at the start of an averaged measurement and automatically calculates the length of the optical fiber cable. When setting the distance range manually, set a distance range appropriate for the length of the optical fiber cable to be measured. For details on the appropriate distance range, see section 3.1.

Pulse width

With the auto setting, when the distance range is set to auto, the minimum pulse width that can measure the distance to the open end (end point) is selected. When setting the pulse width manually, set a pulse width appropriate for the distance range. For details on the appropriate pulse width, see section 3.1.

Average count and average duration

With the auto setting, the average method is selected according to the distance range and the loss in the optical fiber cable being measured.

Attenuation

With the auto setting, an attenuation value is selected according to the distance range and the loss in the optical fiber cable being measured. If you want to set the attenuation value manually, select a value appropriate for the pulse width. For details on the attenuation value appropriate for the pulse width, see section 3.1.

Switching the display between TRACE mode and MAP mode

You can switch the data display screen.

TRACE mode: The data display screen shows the waveform of optical pulse measurement.

MAP mode: The data display screen shows the events detected through event analysis and displays them with icons.

Event icon display

The following events are displayed using icons.



**Start point
(Near-end
reflection)**



Splice



**Connector
(PC connector)**



**Connector
(APC connector)**



Bend



Splitter



**End point
(Fresnel
reflection)**

Note

When the data display screen is in MAP mode, the following features cannot be used.

- Operating the cursors
- Performing marker analysis
- Zooming In on or Out of Waveforms

4.2 Performing Real-time Measurement

In real-time measurement, the waveform display is updated in real time. This feature is used to monitor the waveforms. Real-time measurement is not possible in MAP mode (the mode is automatically switched to TRACE mode before making a measurement).



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure


Setting simple mode (Simple OTDR)

In this mode, the absolute minimum amount of measurement conditions are set. You only have to set the wavelength. Conditions such as distance range and pulse width are set automatically at the start of the measurement.

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.
3. Tap **TRACE**. A TRACE screen appears.



4. Tap **Wavelength** to set the wavelength.




Executing a real-time measurement

5. Press **REAL TIME**. A real-time measurement will begin.

During measurement, a mark appears at the top of the display to indicate that the laser light is on. The words “Check Point” appears at the cursor on the screen. Pressing REAL TIME again stops the measurement.

Analysis results (TRACE screen)




Note

If distance range and pulse width are set to auto, the instrument automatically selects the optimal values internally immediately before starting a real-time measurement. Change these values if necessary. For details, see section 3.1.

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.
3. Tap **Wavelength** to set the wavelength.




Executing a real-time measurement

4. Press **REAL TIME**. A real-time measurement will begin.


During measurement, a mark appears at the top of the display to indicate that the laser light is on. Pressing REAL TIME again stops the measurement.

Analysis results (TRACE screen)




The menu that can be used during real-time measurement or the menu that can be used after real-time measurement is displayed automatically depending on the usage condition.

Menu during real-time measurement




Menu after real-time measurement

**Note**

If distance range and pulse width are set to auto, the instrument automatically selects the optimal values internally immediately before starting a real-time measurement. Change these values if necessary. For details, see section 3.1.


Work completion notice

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.
3. Tap the **Advanced Measurement** soft key and then the **Work Completion Notice** soft key. The following screen appears.



4.2 Performing Real-time Measurement

4. Press **REAL TIME**. A real-time measurement will begin.
During measurement, a mark appears at the top of the display to indicate that the laser light is on.
5. Tap the waveform display screen. A cursor appears at the tapped position.
If Notification is set to ON, the word “CheckPoint” appears at the top area of the cursor.
6. Press the **Next** soft key and then the **Completion Check** soft key to select ON.
When the measurement to the Check Point distance is complete, you are notified with a message or an alarm sound. The alarm sound turns off when you turn off the work completion check.



Note

You can perform measurements efficiently by moving the cursor to a position slightly after the installation point (depending on how fast the optical fiber cable will be installed). This is because the instrument notifies you of the work completion, which is your sign to measure the connection loss at that point (splice, connection, etc.). This setting is the same as the work completion notice in section 3.3.


Rerouting work

When installed optical fiber cables are moved because of road construction or other external factors (rerouting work), using this feature enables you to compare the event waveform before the construction to that after the construction. This makes it easy to check the presence of obstacles caused as a result of the rerouting work.

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.
3. Press **REAL TIME**. A real-time measurement will begin.
During measurement, a mark appears at the top of the display to indicate that the laser light is on. The words “Check Point” appears at the cursor on the screen.

4. Press the **Next** soft key and then the **Rerouted Fiber Comparison** soft key.

During real-time measurement




Step 4 to step 10 are the steps for the rerouting work explained in this section.

Measuring the Connection Loss between the Measurement Start Point and Measurement Endpoint before the Construction

5. Press the **2-location Marker** soft key. A marker soft key menu appears for monitoring loss values.
6. Place the **A** marker at the measurement start point and the **B** marker at the measurement end point.


The connection loss between A and B is measured.



Capture the waveform data before the construction

7. Press the **Capture Trace** soft key.


The waveforms displayed on the current screen are captured. Because markers are not captured, separately record the connection loss value between A and B before the construction.



Measuring the connection loss between the measurement start point and measurement end point after the construction


8. Press the **2-location Marker** soft key. A marker soft key menu appears for monitoring loss values (see the previous page).
9. Place the Ⓐ marker at the measurement start point and the Ⓑ marker at the measurement end point.

The connection loss between A and B is measured. Check that there are no problems in the connection loss value before the construction and the connection loss value after the construction.



Comparing waveform data before the construction and after the construction

10. Press the **Trace Shift** soft key and then the **Trace Shift Right** soft key. The waveform data (captured waveform) before the construction moves to the right side of the screen. Use **Trace Shift Right** or **Trace Shift Left** depending on the differences in the start points before the construction and after the construction. In this example, because the distance between the start point and the end point after the construction is long, the waveform data before the construction is moved to the right side.



Explanation

Real-time measurement

In real-time measurement, the waveform display is updated in real time. This feature is used to monitor the waveforms. Because averaged measurement requires a certain amount of measurement time, checking (monitoring) whether waveforms can be displayed correctly on the data display screen before starting averaged measurement can save time. In addition, you can operate markers and cursors during measurement. For cursor operation, see sections 3.2 and 6.1. For marker operation, see section 6.1.

Distance range

With the auto setting, the instrument detects the open end (end point) at the start of a real-time measurement and automatically calculates the length of the optical fiber cable. When setting the distance range manually, set a distance range appropriate for the length of the optical fiber cable to be measured. For details on the appropriate distance range, see section 3.1.

Pulse width

With the auto setting, when the distance range is set to auto, the minimum pulse width that can measure the distance to the open end (end point) is selected. When setting the pulse width manually, set a pulse width appropriate for the distance range. For details on the appropriate pulse width, see section 3.1.

Attenuation

With the auto setting, an attenuation value is selected according to the distance range and the loss in the optical fiber cable being measured. If you want to set the attenuation value manually, select a value appropriate for the pulse width. For details on the attenuation value appropriate for the pulse width, see section 3.1.

Switching the measurement mode


The real-time measurement waveform display updates the displayed waveform each time an optical fiber cable is measured. This update rate can be changed according to your application.

Hi-Speed: The quality of the displayed waveforms decreases slightly, but the waveform display is updated quickly. Reflections on the displayed waveform may saturate or may be buried in noise.

Hi-Reflection: The quality of the display waveforms is prioritized. Waveforms are displayed and updated with high precision.

Cutting the waveform display noise

This feature removes noise at the far-end point.



Switching the display between TRACE mode and MAP mode

When you start a real-time measurement, the data display screen automatically switches to TRACE mode.


Saving waveforms during real-time measurement

After real-time measurement, waveforms shown on the data display screen are saved in memory. If event analysis is performed on real-time measurement waveforms, MAP display data is also saved in memory.

Work completion notice

Before you check whether the work is complete, move the cursor slightly after the extension work point or before the work completion point on the optical fiber cable, and turn on the work completion notification.

When the fiber end detection position (the event) during real-time measurement is the same as the cursor position (CheckPoint), the instrument gives a notification (message indication and alarm sound) that the work is complete.



Notification

Turns on or off the work completion notice feature.

OFF: The work completion notice feature is disabled.

ON: The work completion notice feature is enabled.

Notification (Message)

OFF: Work completion is not notified with a message.

ON: Work completion is notified with a message.

Notification (Alarm)

OFF: Work completion is not notified with an alarm sound.

ON: Work completion is notified with an alarm sound.

Confirmation

No Check: A confirmation message is not displayed on the screen even if you press the Completion Check soft key.


Check only once: A confirmation message is displayed on the screen the first time you press the Completion Check soft key.

Check everytime: A confirmation message is displayed on the screen every time you press the Completion Check soft key.

Rerouting work

When installed optical fiber cables are moved because of road construction or other external factors (rerouting work), using this feature enables you to compare the event waveform before the construction to that after the construction. This makes it easy to check the presence of obstacles caused as a result of the rerouting work.

The markers of 2-location Marker are used to measure two sections as loss measurements for when the optical fiber cable is switched. The measurement of the two sections is performed the marker pairs ① and ② and the marker pairs ③ and ④.



4.3 Performing High Resolution Measurement

When analyzing waveforms in real-time measurement, you can limit the range to be analyzed and measure at high resolution to obtain detailed measurements.



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Executing a measurement


1. On the MENU screen, select **OTDR**.
2. Press **REAL TIME**.
Measurement will start. The screen shows the measurement waveform, and the RealTime menu appears. A mark appears in the top area of the screen to indicate that the laser light is on.

Specifying the range

3. Press the **Next** soft key and then the **Meas.Range Change** soft key.
4. Turn the **rotary knob** to move the cursor to the center of the range you want to analyze.

Setting the sampling interval

- Press the **Sampling Interval** soft key to set the sampling interval.
The waveform measured at the specified sampling interval is displayed.



Note

The amount of measurement scope movement varies depending on the amount of cursor movement (see section 6.1).

Averaged measurement with Hi Resolution setting


If the sample interval is set to High Reso. in real-time measurement, averaged measurement can be performed with those conditions.

- Press **AVG** to perform averaged measurement while maintaining the high-resolution conditions.


Explanation

In normal measurement, the sampling interval is set so that data can be sampled at all distances according to the specified distance range. The maximum number of data sampled by this instrument is 256000 (when the distance range is 512 km).

Therefore, if the distance range is large (e.g., 400 km), the sampling interval becomes long, and events occurring between samples cannot be analyzed in detail. Waveform zooming explained in section 5.1 simply expands the measured results at the sampling resolution set for each distance range; it does not increase the resolution.



In high resolution measurement, you move the cursor to the location where you want to analyze in detail and set the sampling resolution. The sampling resolution that you can select here is all intervals regardless of the distance range. The measurement scope is determined by the selected sampling resolution with the cursor at the center. If there is no cursor, the left edge of the present measurement scope becomes the reference.



5.1 Zooming and Moving Displayed Waveforms

Procedure

Setting simple mode (Simple OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.
3. Tap the **TRACE/MAP** button to set the data display screen to TRACE mode.




4. Perform a measurement or load a file to display a waveform on the screen.
When performing an averaged measurement, wait for the measurement to complete. When loading a waveform data file, use an SOR file that has been measured and saved with the instrument.

Zooming the displayed waveform

5. Display a cursor at the waveform position you want to zoom. An marker and cursor control screen appears. For the cursor operation procedure, see section 6.1.

Zooms the waveform at the cursor position



Set the control mode to ZOOM.

Cursor and marker operation screen


If you do not use markers or cursors for about 8 seconds, the screen will close automatically.

6. Set the control mode to ZOOM, and press the **arrow keys**. The displayed waveform expands or contracts.

Moving the displayed waveform

5. Display a cursor at the waveform position you want to move. An marker and cursor control screen appears. For the cursor operation procedure, see section 6.1.

Zooms the waveform at the cursor position



Closes the window

Set the control mode to SHIFT (move).

Cursor and marker operation screen

If you do not use markers or cursors for about 8 seconds, the screen will close automatically.

6. Set the control mode to SHIFT, and press the **arrow keys**. The displayed waveform will move.

Note


You can move zoom waveforms by dragging on the data display screen. Drag an area besides the waveform or cursor display area.

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.
3. Perform a measurement or load a file to display a waveform on the screen.
When performing an averaged measurement, wait for the measurement to complete. When loading a waveform data file, use an SOR file that has been measured and saved with the instrument.

Expanding the data screen

4. Tap the data display screen expand button. The area for displaying the waveform data is expanded.




Note

You can zoom waveforms without expanding the data display screen. Expand the data display screen if necessary.

Zooming the displayed waveform

4. Press **SCALE**. A scale menu appears.



5. Press the **Zoom** soft key.
6. Press the **arrow keys**. The displayed waveform expands or contracts.

Moving the displayed waveform

5. Press the **Shift** soft key.
6. Press the **arrow keys**. The displayed waveform will move.

Note

You can move zoom waveforms by dragging on the data display screen. Drag an area besides the waveform or cursor display area.

Explanation

Zooming in and out

You can press the arrow keys to zoom the displayed waveform in or out.

When the cursor is displayed, the waveform is zoomed at the cursor position.


When the cursor is not displayed, the waveform is zoomed at the left edge of the display.

Down arrow key: Zoom in vertically on the waveform.


Up arrow key: Zoom out vertically of the waveform.

Left arrow key: Zoom in horizontally on the waveform.


Right arrow key: Zoom out horizontally of the waveform.



Cursor position



Press the left arrow key to zoom the displayed waveform horizontally.



Press the down arrow key to zoom the displayed waveform vertically.

Shifting the horizontal and vertical axes

You can move the screen by pressing the arrow keys.

Down arrow key: The screen moves down.

Up arrow key: The screen moves up.

Left arrow key: The screen moves left.

Right arrow key: The screen moves right.


Auto zoom

The auto zoom feature contains the following two types of zoomed displays.

- Zoom the waveform at the cursor position
The cursor on the waveform display screen is shown in the center of the zoomed display.
- Zoom the waveform at event positions
When the instrument has detected events during event analysis, the selected event is zoomed and displayed.

Overview display

The overview display is linked to the zoomed waveform display. The blue box indicates where in the entire waveform display area the zoomed waveform display is showing.



5.2 Displaying a Reference Trace

Procedure

Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.


Reference trace screen

3. Display the waveform on the screen. Press the **Ref. Trace** soft key and then the Set Reference Trace soft key. The reference trace is displayed in white.



Moving the reference trace

1. Press the **Trace Shift** soft key.
2. Press the **Trace Shift Up** or **Trace Shift Down** soft key. The reference trace will move.



Explanation

Reference trace

You can also create a reference trace from waveforms that you load from files. By creating a reference trace before work, you will be able to check the work progress. For details on loading waveforms, see section 9.5.

Comparing traces

The instrument displays the differential trace of the current waveform and reference trace.

6.1 Analyzing Waveforms

Procedure

Setting simple mode (Simple OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.
3. Tap **TRACE**. A TRACE screen appears.



Note

You can operate cursors and markers only in TRACE mode.

4. Press **REAL TIME**. A real-time measurement begins, and the data display screen shows the waveform.

Waveform data display




Note

- For instructions on how to use real-time measurement, see section 4.2.
- You can use cursors and markers also when you load waveform data from a USB memory device, microSD memory card, or internal memory. For instructions on how to load waveform data, see section 9.4.

Displaying the cursor

5. Turn the rotary knob, or tap the data display screen. A cursor appears.

A cursor appears at the tapped position.




Note

When you turn the rotary knob to the right, a cursor appears at the left edge of the data display screen.

Moving the cursor


6. Tap the position on the data display screen that you want to move the cursor to. The cursor moves to the position that you tapped. You can also move the cursor by dragging the cursor on the data display screen or by turning the rotary knob. By pressing the rotary knob, you can set the amount the cursor moves when the rotary knob is turned. For details, see “Explanation” in this section.

The cursor moves to the position that you tap.



Marker operation (4 Point Markers)


- Tap a marker button. The selected marker is displayed at the cursor position.



Setting markers on a waveform

Set four markers in order starting from the position closest to measurement reference point S (example of 4 point markers).

For details on how to perform waveform analysis using markers, see the explanation.



Cursor and marker operation screen

If you do not use markers or cursors for about 8 seconds, the screen will close automatically.

Note

- When you set the markers, set them so that the ① marker is on the measurement start point S side.
- The measured loss value differs depending on the specified approximation method.
- Set the ② marker to the correct position. The splice loss changes greatly depending on the position of ②.
- For details on the approximation method, see “Approximation Method” in section 3.2.

Marker analysis results

Splice loss and return loss values are displayed on the screen as marker analysis results. (The reflection level is displayed if Reflection term is set to Reflection level (see section 3.3).)

For the analysis procedure of splice loss and return loss, see the explanation.

Setting expert mode (OTDR)


1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.

Note

You can operate cursors and markers only in TRACE mode.

3. Press **REAL TIME**. A real-time measurement begins, and the data display screen shows the waveform.

Waveform data display




Note

- For instructions on how to use real-time measurement, see section 4.2.
- You can use cursors and markers also when you load waveform data from a USB memory device, microSD memory card, or internal memory. For instructions on how to load waveform data, see section 9.4.

Displaying the cursors

4. Turn the rotary knob, or tap the data display screen. A cursor appears.

A cursor appears at the tapped position.




Note

When you turn the rotary knob to the right, a cursor appears at the left edge of the data display screen.

Moving the cursor


5. Tap the position on the data display screen that you want to move the cursor to. The cursor moves to the position that you tapped. You can also move the cursor by dragging the cursor on the data display screen or by turning the rotary knob. By pressing the rotary knob, you can set the amount the cursor moves when the rotary knob is turned. For details, see “Explanation” in this section.

The cursor moves to the position that you tap.



Marker operation (4 Point Markers)


6. Tap a marker button. The selected marker is displayed at the cursor position.



Setting markers on a waveform

Set four markers in order starting from the position closest to measurement reference point S (example of 4 point markers).

For details on how to perform waveform analysis using markers, see the explanation.



Cursor and marker operation screen

If you do not use markers or cursors for about 8 seconds, the screen will close automatically.

Note


- When you set the markers, set them so that the ① marker is on the measurement start point S side.
- The measured loss value differs depending on the specified approximation method.
- Set the ② marker to the correct position. The splice loss changes greatly depending on the position of ②.
- For details on the approximation method, see “Approximation Method” in section 3.2.
- For details on how to use 2 Point Markers, 5 Point Markers, 6 Point Markers, see “Soft Key Menu (Markers).”

Marker analysis results

Splice loss and return loss values are displayed on the screen as marker analysis results. (The reflection level is displayed if Reflection term is set to Reflection level (see section 3.3).)

For the analysis procedure of splice loss and return loss, see the explanation.

7. Press the **Marker** soft key. A marker soft key menu appears.

When marker mode is set to Marker (see section 3.3)


2 Point Markers
Switches to the screen for measuring with 2 Point markers. For details, see the explanation.


4 Point Markers
Switches to the screen for measuring with 4 Point markers. For details, see the explanation.

6 Point Markers
Switches to the screen for measuring with 6 Point markers. For details, see the explanation.

2-location Marker
Place markers on the waveform data and monitor the loss between S and E and analysis values of up to two events. See page 6-11.

Preset markers
Register markers that you set in advance, and apply them on waveforms during measurement when necessary.

Auxiliary function
Displays a menu used to set and clear the distance reference and clear markers and cursors. See page 6-8.

When marker mode is set to Line (see section 3.3)


2 Point Markers
Switches to the screen for measuring with 2 Point markers. For details, see the explanation.


5 Point Markers
Switches to the screen for measuring with 5 Point markers. For details, see the explanation.

Preset

Auxiliary Function

2 Point Markers (when the marker mode is Marker)


8. Press the **2 Point Markers** soft key. A soft key menu for the 2 markers method appears.

**Note**

- When you set the markers, set them so that the ① marker is on the measurement start point (distance reference) side.
- The measured loss value differs depending on the specified approximation method.

- Distance reference**

Normally, the location where the instrument and the optical fiber cable are connected is the measurement reference point. This reference point is the distance reference. It is used to calculate the distance to the cursor and markers. If you are using a launch fiber to perform measurements, move the distance reference the length of the launch fiber before performing measurements.




- Cursor link (Moving all markers together)**

You can move all markers while maintaining the distance between them.

2 Point Markers (when the marker mode is Line)

8. Press the **2 Point Markers** soft key. A soft key menu for the 2 markers method appears.




Note

- When you set the markers, set them so that the n marker is on the measurement start point (distance reference) side.
- The measured loss value differs depending on the specified approximation method.

4 Point Markers (when the marker mode is Marker)

8. Press the **4 Point Markers** soft key. A soft key menu for the 4 markers method appears.




Note

- Set the markers in the order shown above, starting with the measurement start point (the distance reference).
- The measured loss value differs depending on the specified approximation method.
- Set the ② marker to the correct position. The splice loss changes greatly depending on the position of ②.

6 Point Markers (when the marker mode is Marker)


8. Press the **6 Point Markers** soft key. A soft key menu for the 6 markers method appears.

**Note**

- Set the markers in the order shown above, starting with the measurement start point (the distance reference).
- The measured loss value differs depending on the specified approximation method.
- Set the ② marker to the correct position. The splice loss changes greatly depending on the position of ②.

5 Point Markers (when the marker mode is Line)

8. Press the **5 Point Markers** soft key. A soft key menu for the 5 markers method appears.




Note

- Set the markers in the order shown above, starting with the measurement start point (the distance reference).
- The measured loss value differs depending on the specified approximation method.
- Set marker E to the correct position. The splice loss changes greatly depending on the position of E.

2-location Marker (splice loss at two locations) (when the marker mode is Line)

8. Press the **2-location Marker** soft key. A 2-location Marker soft key menu appears.



6.1 Analyzing Waveforms

Presetting markers

- Using 2 Point Markers, 4 Point Markers, or 6 Point Markers, place markers on the waveform data.
- Press the **Preset** soft key. A preset soft key menu appears.

Select the action (Register, Delete, SetMarker)


Select the action to perform when you tap the **(A)** or **(B)** soft key.

Register: Registers the markers on the current waveform data to preset A or preset B.

Delete: Deletes the markers registered in preset A or preset B.

SetMarker: Displays the markers registered in preset A or preset B on the waveform.

Registers the markers (e.g., 4 Point Markers) on the current waveform data.



Displays the information of the markers registered in the preset.

• Registering markers

- Press the **Action** soft key to select **Register**.
- Press the **(A)** or **(B)** soft key. The markers applied to the waveform are registered, and the marker information is displayed on the preset information display screen.

• Setting the markers registered in preset A or preset B

- Display the measurement target waveform data on the data display screen.
- Press the **Action** soft key to select **SetMarker**.
- Press the **(A)** or **(B)** soft key. The markers registered in preset A or preset B are displayed on the waveform data.

Note

Preset markers exceeding the distance range of the waveform display cannot be applied.

• Deleting the markers registered in preset A or preset B


- Press the **Action** soft key to select **Delete**.
- Press the **(A)** or **(B)** soft key. The markers registered in preset A or preset B are deleted.

Note

A marker applied to the waveform is not cleared. To delete markers set on the waveform, press the Delete Cursor/Marker soft key. See page 6-8.


Analyzing sections

4. Press the **Section Analysis** soft key. A section analysis soft key menu appears.



Setting the start and end points


5. Move the cursor to the start point position. For the cursor operation procedure, see section 6.1.
6. Press the **Set Start Marker** soft key. Shows marker S.
7. Move the cursor to the end point position.
8. Press the **Set End Marker** soft key. Shows marker E



6.1 Analyzing Waveforms

Setting the Start or End Point to a Set Marker (①, ②, n, or E)

5. Press the **To be set by Marker** soft key. The position of marker ① or n already set on the waveform data changes to a start point and the position of marker ② or E changes to an end point.




Note

For details on how to set markers ①, ②, n, and E, see section 6.1.

Adjusting the reference level


9. Press the **Auxiliary Function** soft key and then the **Reference Level Adjust** soft key. Marker ㊟ appears.



Explanation


2 Point Markers

The instrument measures the distance and the loss between two points. If reflection is detected between the two points, the return loss is also measured. The splice loss value changes depending on the approximation method that you have specified. This can be used when Marker Mode is set to Marker or Line.




4 Point Markers (when the marker mode is Marker)

The instrument uses the following four points to perform the measurement: the measurement start point ①, the splice loss start point ②, the splice loss end point Y2, and the measurement end point ③. At position ②, the level difference between the approximation line ②-① and the approximation line Y2-③ is calculated as the splice loss. The splice loss changes greatly depending on the position of ②. Set the correct position for ②. The splice loss value changes depending on the approximation method that you have specified. This can only be used when Marker Mode is set to Marker.




5 Point Markers (when the marker mode is Line)

The instrument uses the following five points to perform the measurement: the near-end point (n), a point (N) that is used to calculate the near-end side's approximation line, a point (E) where splice loss is detected, a point (F) that is used to calculate the far-end side's approximation line, and the far-end point (f). At position E, the level difference between the approximation line n–N and the approximation line F–f is calculated as the splice loss. The splice loss changes greatly depending on the position of E. Set the correct position for E. The splice loss value changes depending on the approximation method that you have specified. This can only be used when Marker Mode is set to Line.



6 Point Markers (when the marker mode is Marker)

The instrument measures using the 6-point method when there are two adjacent splice loss events. The instrument uses the following six points to perform the measurement: the first splice loss start point ①, start point Y1 used to calculate the approximation line, end point Y3 used to calculate the approximation line, the second splice loss start point ②, the second splice loss end point Y2, and the measurement end point ③. At the position of marker ②, the level difference between the approximation line Y1–Y3 and the approximation line Y2–③ is calculated as the splice loss.



Setting the amount that the cursor moves

Press the rotary knob to set whether to move the cursor in coarse steps or fine steps. Tap the screen to set the cursor to move in fine steps.

COARSE: The cursor moves a large amount.

FINE: The cursor moves a small amount.

The amount that the cursor is set to move is displayed in the upper right of the screen.

Amount of cursor movement




6.2 Analyzing Events

Procedure

Setting simple mode (Simple OTDR)


1. Press **MENU**. A MENU screen appears.
2. Tap the **Simple OTDR** icon. A simple OTDR setting list appears.
3. Tap **Setup**, or press **SETUP**. A setup screen appears.
4. Tap the **Analysis Setup** tab. You can set event search conditions.
For event search conditions, see section 3.2.
5. Press **AVG**. The measurement begins, and the data display screen shows the waveform.
When averaged measurement is completed, event analysis is automatically executed, and the event analysis results are shown on the data display screen. For details on averaged measurement, see section 4.1.



6.2 Analyzing Events

When the Launch Fiber Setting is ON

When a launch fiber is connected and measured waveform data is displayed, analysis can be performed by assuming the start point of the launch fiber to be the origin event (O). The length of the launch fiber from the origin (O) to the distance reference (R) is displayed.





Setting expert mode (OTDR)

1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR** icon. A TRACE screen appears.

Displaying event analysis results (TRACE mode)


3. Press **AVG**. The measurement begins, and the data display screen shows the waveform. When averaged measurement is completed, event analysis is automatically executed, and the event analysis results are shown on the data display screen. For details on averaged measurement, see section 4.1.



6.2 Analyzing Events

When the launch fiber setting is on

When a launch fiber is connected and measured waveform data is displayed, analysis can be performed by assuming the start point of the launch fiber to be the origin event (O). The length of the launch fiber from the origin (O) to the distance reference (R) is displayed.



Executing an event analysis


4. Press **ESC**.
5. Press the **Event Analysis** soft key. Event analysis is performed, and the event results are displayed on the waveform data. For details on the event analysis results, see “Displaying Event Analysis Results (TRACE mode)” on page 6-19.

Editing or fixing events

There may be cases where, because the backscattering light level is too small at a reflection point in an optical fiber cable, the reflection cannot be detected as an event, or there may be cases where noise is detected as an event. In such cases, you can adjust the events by editing them as follows:

- Insert events
- Delete events
- Edit event markers
- Fix event positions

6. Press the **Event Edit/Fix** soft key. An event edit soft key menu appears.



Insert events

7. Press the **Rotary Knob** soft key to select Cursor.
8. Turn the rotary knob to move the cursor to the position where you want to insert an event.
9. Press the **Ins. Event (Cursor)** soft key. An event is inserted at the cursor position.


**A virtual event is inserted at the cursor position.
Event numbers are updated automatically.**



The inserted event is added to the event list.

The same operations can be performed from the following screen while the event analysis screen is being displayed.

6.2 Analyzing Events



Note

- The event list can display up to 100 events.
- If you insert an event between two events that are displayed, the new event takes on the number that follows the event on the left, and all subsequent event numbers are increased by one. You cannot insert events to the left of the S point.
- You cannot insert events to the left of the distance reference. You can use the Set Distance Reference soft key to move the distance reference. For details about the distance reference, see page 6-8.
- If you insert an event to the right of the E event, the inserted event becomes the E event, and a new number is assigned to the former E event.

Delete events

7. Press the **Rotary Knob** soft key to select Event.
8. Turn the rotary knob to select the event you want to delete.
9. Press the **Del.Event (Event)** soft key. The selected event is deleted.

The color of the selected event changes.




The selected event is deleted.
The subsequent event numbers are each decreased by one.



The deleted event is deleted from the event list.

The same operations can be performed from the following screen while the event analysis screen is being displayed.



Closes the window

Event edit control screen

Appears when you use the cursor on the data display screen. If you do not use the cursor for about 8 seconds, the screen will close automatically.

Deletes an event

The same operation as step 9 can be performed.

Note


- If only the S point and the E event are displayed, you cannot delete any events.
- If you delete an event, the subsequent event numbers will all be reduced by one.
- You cannot delete the S point.

6.2 Analyzing Events


Edit event markers

You can move an event marker to recalculate return loss and splice loss.


- 7. Press the **Event MarkerEdit** soft key. An event marker edit soft key menu appears.
- 8. Press the **Rotary Knob** soft key to select Event.
- 9. Turn the rotary knob to select the event you want to edit.
The color of the selected event changes.
- 10. Press the **Rotary Knob** soft key to select Cursor.
You can now use the marker menu.



You can select an event to edit when the **Rotary Knob** soft key is set to Event.



Note For details on how to set markers, see “4 Point Markers” on page 6-9 (marker mode is Marker).
For details on how to set line markers, see “5 Point Markers” on page 6-11 (marker mode is Line).


Example when marker mode is set to Marker

Shows the current marker placed when event analysis was executed

Splice loss and return loss (or reflection level) of the selected event

You can edit the splice loss and return loss (or reflection level) values by moving the marker position.

Detailed information about the selected event

Example when marker mode is set to Line

Shows the current line marker placed when event analysis was executed

6.2 Analyzing Events

Fixing events

Event positions can be fixed. Fixed events are handled as master events. You can configure the instrument so that in subsequent event analysis only master events are handled.

7. Press the **Event Fix** soft key. An Event Fix Mode screen appears.

Events are not fixed.

Mode 1:
Fixed events remain on display.
New events will be added.
Then a before and after trace picture will be shown with events remarked as " " and "NEW".

Mode 2:
Only fixed events remain on display.
New events will NOT be added.
Then a before and after trace picture will be shown with events remarked as " ".

Master mode
Registers the current placed event as the master.
New events are not detected even when the waveform data is updated.
Only the master event is displayed on the updated waveform data.

Add mode
Registers the current placed event as the master.
New events are detected when the waveform data is updated. Both the master event and the new detected events are displayed on the updated waveform data.

Changing the event type

7. Press the **Rotary Knob** soft key to select Event.
8. Turn the rotary knob to select the event you want to change.
9. Tap the Details tab.
10. Tap the event type display. An event type selection screen appears.
11. Select the event type you want to change.

File Name : 1550nm_2km_50ns_SOR

872.68m

Distance 0.87268km
Section 0.40246km
Loss 0.108dB
Return Loss 61.417dB
Cumul-Loss 0.355dB
dB/km 0.181dB/km
Event Type
Section 1.0000

Change the event type.

Details tab

Tap the event type display.



Note

You can also change the event type of distance reference R.

2-point markers

The section distance and section loss between two markers are measured.

6. Press the **2 Point Markers** soft key. A soft key menu for the 2 markers method appears.
7. Turn the rotary knob to move the cursor to the analysis start position.
8. Press the **(A)** soft key. Marker **(A)** is displayed at the cursor position.
9. Turn the rotary knob to move the cursor to the analysis end position.
10. Press the **(B)** soft key. Marker **(B)** is displayed at the cursor position.





Displaying event analysis results (MAP mode)

3. Tap the **TRACE/MAP** button to set the data display screen to MAP mode.
When the data display screen is in MAP mode, the button is TRACE.




Note
If you switch the data display screen to MAP mode, event analysis is automatically performed.
The results of event analysis are displayed with icons.

4. Press **AVG**. The measurement begins, and the data display screen shows the waveform.
When averaged measurement is completed, event analysis is automatically executed, and the event analysis results are shown on the data display screen. For details on averaged measurement, see section 4.1.



When the Launch Fiber Setting Is ON

When a launch fiber is connected and measured waveform data is displayed, analysis can be performed by assuming the start point of the launch fiber to be the origin event (O). The length of the launch fiber from the origin (O) to the distance reference (R) is displayed.



Distance to the origin event (launch fiber length)


Note

If you display waveform data using the following methods, you need to manually execute event analysis. See “Soft Key Menu (during event analysis)” explained later.

- When a real-time measurement is performed
- When waveform data (without event analysis information) is loaded from a USB memory device, internal memory, or microSD memory card. Event analysis information is not included in waveform data of real-time measurement or waveform data of averaged measurement that is aborted in the middle of a measurement.

Editing events


3. Tap an icon in the data display area. The icon is displayed in the center position.
4. Tap the icon displayed in the center position. An event type edit screen appears.
5. Select the event type you want to change.



Event icon display

The event selected in the event analysis result display is shown at the center. Tapping the icon of another event on the screen will show that event at the center. You can move the icon horizontally by dragging the icon. Tap the icon in the center to display the event types that can be changed.

Change the event type.



Explanation

Event analysis results

Event number

A number is displayed on the waveform next to the event. The measurement reference point is displayed as S and the fiber end point as E. In the section between S to E, the numbers are in ascending order from the left of the display.

Distance

The distance from the measurement reference point to each event is displayed. If you move the distance reference, which is the measurement reference point, the distance from the distance reference to each event is displayed. For details about the distance reference, see page 6-8.

Splice loss

The splice loss for each event is displayed.

Return loss

The return loss for each event is displayed.

In TRACE mode, the following is displayed.

When the return loss of distance reference R exceeds 99.999 dB, "> 99.999" is displayed.

When the return loss of an event other than the distance reference exceeds 99.999 dB, "----" is displayed.

Cumulate loss

The loss from the measurement reference point is displayed. If the distance reference is specified, the distance reference is the measurement reference point. If the distance reference is not specified, the measurement reference point (S) is the measurement reference.

dB/km


The loss per kilometer between events is displayed.

Event type


The type of each event is displayed with the following symbols.

: Positive splice loss

: Negative splice loss

: Reflection

: Bending loss (macro bending)

: Splitter insertion loss

: Superimposed reflections

Total loss

Displayed in the following manner depending on the total loss calculation method. For the setup procedure, see section 3.3.

Cumulate loss:	The integrated value of the splice losses at each event from measurement reference point S is displayed.
Loss between S and E:	The loss between the measurement reference point (S) and the end of fiber (E) is displayed.

Total return loss

The integrated value of the return losses of each event.

The following is a description of the TRACE mode.

Rotary knob feature

You can select the operation that occurs when you turn the rotary knob from the following.

Cursor: The cursor moves continuously.

Event: The cursor moves directly between detected events.

Inserting an event

- The event list can display up to 100 events.
- If you insert an event between two events that are displayed, the new event takes on the number that follows the event on the left, and all subsequent event numbers are increased by one. You cannot insert events to the left of the S point.
- You cannot insert events to the left of the distance reference. For details about the distance reference, see page 6-8.
- If you insert an event to the right of the E event, the inserted event becomes the E event, and a new number is assigned to the former E event.

Delete events

- If only the S point and the E event are displayed, you cannot delete any events.
- If you delete an event, the subsequent event numbers will all be reduced by one.
- You cannot delete the S point.
- If you set a distance reference (R point), the S point disappears from the screen. In this situation, the measurement reference point is the distance reference. If you delete the distance reference, the S point is displayed again at its original position.
- If you delete the E event, the event that has the largest number becomes the E event.

Edit event markers

Event markers are used to calculate the splices losses and reflection losses at event positions.

Normally, event markers are automatically assigned, but when event markers are assigned to noise and other undesirable waveforms, correct values cannot be calculated. In such cases, you can obtain correct values by moving event markers.

Event fix mode


Event positions can be fixed. Fixed events are handled as master events. You can configure the instrument so that in subsequent event analysis only master events are handled.

How the events that are detected at positions other than the master event positions are displayed varies depending on the Event Fix Mode as follows:

When event fix mode is set to append mode


Events detected at positions other than the master event positions are also displayed in the event list.

Events other than fixed events are also detected.

**When event fix mode is set to master mode**

Only the events that are detected at the master event positions are displayed in the event list.

Not detected even when an event exists.



Section analysis

In section 6.1, each item was measured with the distance reference as the reference point, but in section analysis, each item is measured with the location that is specified as the start point within the specified section as the reference point.

The distance, return loss, total loss, and loss per division (dB/km) between the S and E markers are displayed on the screen.

Marker auto setting (set from markers)

You can automatically set marker ① or marker n as the start point and marker ② or marker E as the end point. You can use this feature to automatically set markers on waveform data in which marker ① and ② or n and E are already set.

Adjusting the reference level

If you set marker ③, which represents the reference point, the return loss is measured with this location as the reference. The instrument uses the backscattering light level of the reference point to calculate the return loss. If you do not set the reference point, the start point is used as the reference point.

7.1 Using the Utility Menu

Procedure


1. Press **MENU**. A MENU screen appears.
2. Tap the **OTDR**, **Light Source**, **Power Meter**, **Power Checker**, or **Visible Light Source** icon. The corresponding control screen appears.

A Utility menu is displayed at the left edge of the control screen.

MENU screen



Example of light source screen



Utility menu




Utility features shown on the tab
Tap a tab to display the setup menu.

Select the utility feature to shown on the tab.

Shows or hides tabs

Utility feature selection screen




Drag on to the tab the utility feature to show on the tab


7.1 Using the Utility Menu

3. On the Utility menu, tap the tab of the function you want to configure. A setup screen appears. For details on each setting, see the respective sections.


Power meter (OPM)
(See section 7.4.)




Power checker (OPC)
(See section 7.5.)




Fiber inspection probe (FIP)
(See section 7.6.)



Light source (LS)
(See section 7.2.)



Visible light source (VLS)
(See section 7.3.)



Optical switch box (OSW)
(See section 7.7.)



The setup screen is also displayed by tapping the icon for each function on the utility function selection screen displayed by tapping +.

Note

You can run multiple utility features simultaneously.

Explanation

The Utility menu allows you to change relevant settings without having to switch setup screens. The following six features can be displayed on the Utility menu.

- Light source (LS)
- Visible light source (VLS)
- Optical power meter (OPM)
- Optical power checker (OPC)
- Fiber inspection probe (FIP)
- Optical switch box (OSW)

Of the above features, four can be displayed in tabs.

7.2 Using the Light Source



WARNING

During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.

French



AVERTISSEMENT

Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.

Procedure

1. Press **MENU**. A MENU screen appears.


7.2 Using the Light Source

2. Tap the **Light Source** icon. A light source screen appears.

MENU screen



Light source screen



Light mark

Light Source ON Turns the optical output on

Light Source OFF Turns the optical output off

Wavelength Set the wavelength.

Modulation Set the modulation mode.

Set the modulation mode.

Set the wavelength.


Turns the optical output on and off

When you tap ON, the measurement light turns on. When turned on, a mark appears on the instrument display to indicate that the light is on. When you tap OFF, the measurement light turns off.

You can edit the settings in the screen or using the soft key menu.

Setup using the Utility menu

On the OTDR, power meter, power checker, or visible light source setup screen, tap **LS** (light source) on the Utility menu. A light source setup screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

Note

Check the wavelength and modulation mode settings before turning on the light source.

Explanation

The following measurement light wavelengths can be generated.

You can produce continuous light (CW) or light that has been modulated at the selected frequency (modulation mode).

Model	Measurement light wavelength	Modulation mode
AQ7292A	1310 nm, 1550 nm	CW, 270 Hz, 1 kHz, 2 kHz
AQ7293A	1310 nm, 1550 nm	CW, 270 Hz, 1 kHz, 2 kHz
AQ7294A	1310 nm, 1550 nm	CW, 270 Hz, 1 kHz, 2 kHz
AQ7293F	1310 nm, 1550 nm, 1650 nm	CW, 270 Hz, 1 kHz, 2 kHz
AQ7293H	1310 nm, 1550 nm, 1625 nm	CW, 270 Hz, 1 kHz, 2 kHz
AQ7294H	1310 nm, 1550 nm, 1625 nm	CW, 270 Hz, 1 kHz, 2 kHz

7.3 Using the Visible Light Source (/VLS option)



WARNING

During measurement, light is transmitted from the instrument's VLS port. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.

French



AVERTISSEMENT

Lorsque l'instrument génère de la lumière, la lumière est émise à travers le port VLS. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.

Procedure


1. Press **MENU**. A MENU screen appears.

2. Tap the **Visible Light Source** icon. A visible light source screen appears.

MENU screen




Visible Light Source Screen



7.3 Using the Visible Light Source (/VLS option)

Setup using the Utility menu

On the OTDR, power meter, power checker, or light source setup screen, tap **VLS** (visible light source) on the Utility menu. A visible light source setup screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

Note

Connect an optical fiber cable to the VLS port (/VLS option).

Explanation

A visible light can be emitted as a measurement light.
The wavelength is 650 nm.
Set the modulation mode to CW or 2 Hz.

7.4 Using the Optical Power Meter (/SPM, /HPM option)

Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Power Meter** icon. A power meter screen appears.

MENU screen



Optical power meter screen


Sets the reference value to the current measured value (–80 to 40dBm). The reference value appears if you press the DREF soft key or set the unit to dB.

MAX (maximum), MIN (minimum)

Turns the display on or off (see the next page)

Enter a value and assign it to the reference value (–80 to 40dBm)

The reference value appears if you press the DREF soft key or set the unit to dB. Tapping the value or the word Reference displays a number input screen.



Performing setup

- Press **SETUP**.
- Tap **Power Meter** or **Logging**. The following screen appears.

Power meter


Turns the maximum and minimum value menu on or off

Set the average times.

Turns light source and optical power meter interlock on or off

Set the wavelength mode.


Closes the window



Logging


Set the measurement interval

Set the number of times (10 to 36000).



Executing the zero set

- After step 4, close the optical power meter screen. The screen returns to the power meter screen.
- Remove the optical fiber cables from the instrument and close the OPM port cover, or make sure that the power meter section is not receiving any light, and then tap **ZERO SET**.



Note


Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes. Performing a zero-set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

Measuring the optical power

7. Connect an optical fiber cable to the OPM port. The measured value is displayed on the power meter screen. For the position of the OPM port, see “Component Names and Functions” in the Getting Started Guide, IM AQ7290-02EN.

Holding the measurement display


8. Press the **HOLD** soft key. The measured value at that point remains displayed. When you press the HOLD soft key again, the hold mode will be cleared.

**Setting the reference value to the currently displayed measured value**

8. Tap **DREF**. The reference value is set to the current measured value, and the measurement display changes to dB units. The measurement display indicates a value relative to the reference value.

Measurement

The display changes to show values relative to the reference value (dB). If the absolute measurement value (dBm) after executing DREF is the same as a reference value, 0 dB is displayed.



DREF

The measurement value after executing DREF (e.g., -9.69 dBm) becomes the reference value.

Setting the Light Source Feature for Loss Tests

8. Tap **Wavelength** or **Modulation** to set the wavelength or modulation. Tap ON on the light source on the screen to output light for loss testing.

7.4 Using the Optical Power Meter (/SPM, /HPM option)

Saving the results of optical power measurements for multi-fiber cables (saving data)

8. Press the **Save Data** soft key. A screen appears for saving the results of optical power measurements for multi-fiber cables.

Tap on the screen or turn the rotary knob to move the cursor (blue frame) to the core number that you want to save the measured data for.

Measured data saved

Core numbers set to Skip appear dimmed.

Measured data not saved

Save Data

Delete Data

Skip

Save

Delete measured data.
See page 7-13.

Specify skipping.
To cancel skipping, press this soft key again.
Grayed out when a core number whose measurement data is saved

Core	No.	nm	Data	Mod.	Ref	Offset	Date
1	1	1310	-99.99 dBm	CW	---	0.00 dB	01/16 13:51
1	2	1310	-99.99 dBm	CW	---	0.00 dB	01/16 13:52
1	3	---	---	---	---	---	---

Measured data (measurement conditions and measured values)
Shows the optical power value currently being measured and the measurement conditions

Executes saving
Saves the data temporarily in the internal memory of the instrument. To save the data to a file (CSV format), see section 9.4.

Saved data information

You can save up to three sets of data in the save area of the specified core.


Note

You can save the optical power meter measurement results by following the procedure explained in section 9.4. The “Save Data” feature explained in this action is for saving multiple measurement results (such as the measurement of a multi-fiber cable) in a single file. Even if data is saved in this section, the CSV file is not saved. To save the data in CSV format, follow the instructions in section 9.4.

If you save the data according to the procedure explained in section 9.4 without using the “Save Data” feature explained in this section, the optical power measurement of a single fiber is saved to a file in CSV format. Each time you save the data according to the procedure explained in section 9.4, a CSV file with a new name is saved.


- Deleting measured data

9. Press the **Delete Data** soft key. A data delete soft key menu appears.



Logging measurement of optical power values (logging)

8. Press the **Logging** soft key. A logging measurement screen appears.




You can also use the up, down, left, and right arrow keys to zoom in and out on the waveform.

7.4 Using the Optical Power Meter (/SPM, /HPM option)


• Setting the auxiliary function

9. Tap the **Auxiliary Function** soft key. A soft key menu appears for the auxiliary function of the logging screen.



Setup using the Utility menu

On the OTDR, light source, power checker, or visible light source setup screen, tap **OPM** (power meter) on the Utility menu. A power meter setup screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

Explanation

Wavelength

The photodetector in the optical power measurement area has wavelength sensitivity characteristics. The photodetector corrects the sensitivity according to the set wavelength and measures optical power more accurately. The wavelength setting range and setting step vary depending on the wavelength mode set in the detailed setup screen. Set the wavelength in the following range.

/SPM or /HPM option

Wavelength mode	Setting range and setting step
Simple	850 nm, 1300 nm, 1310 nm, 1490 nm, 1550 nm, 1625 nm, 1650 nm
Detail	Set the wavelength to a value from 800 nm to 1700 nm in 1 nm steps.
CWDM	Select from 1270 nm to 1610 nm wavelengths subdivided in 20 nm steps.

Modulation mode

You can select the modulation mode of the light to be measured from the following:
CW (continuous light), 270 Hz, 1 kHz, 2 kHz

Unit

Set the optical power display unit from the following.

dB (absolute value), dBm (absolute value), W (absolute value)

- Unit W is preceded by a prefix m (10^{-3}), μ (10^{-6}), n (10^{-9}), or p (10^{-12}).
- The following relation holds between the absolute display unit dBm and W.

$$P_{\text{dBm}} = 10 \times \log (P_{\text{w}} \times 10^3)$$

P_{dBm} : optical power (unit dBm), P_{w} : optical power (unit W)

Reference value

You can set a reference value and display the relative measured values (the differences from the reference value).

- When you tap DREF, the displayed measured value becomes the reference value. From this point, relative values will be displayed. The unit changes to dB.
- When you tap DREF or set the unit to dB, the Reference box appears on the power meter screen.
- You can set the reference value in the Reference box. The range is -80 dBm to 40 dBm.
- When you set the unit to dBm or W, the Reference box disappears, and the absolute measured values will be displayed.

Wavelength mode

You can select the wavelength mode of the light to be measured from the following:

Simple, Detail, CWDM

Like the “wavelength” item described earlier, the setting range and setting step vary depending on the mode.

Average times

The average value is displayed as the measured value. Select the average count from the following.

1, 10, 50, 100

Turning light source and optical power meter interlock on and off

When an optical fiber is connected from the light source port of this instrument to the optical power measurement port of the same instrument to measure optical power, the wavelength and modulation mode settings of the light source can be reflected in the power meter settings.

ON	The light source settings are reflected on the optical power meter side from the time it is turned ON.
OFF	The settings are not reflected.

Loss display

Set how to display the measured values for loss tests (when the light source is on).

Difference from the reference value	The value obtained by subtracting the reference value from the measured value is displayed (a negative value is displayed).
Loss value	The value obtained by subtracting the reference value from the measured value is displayed as a loss (a positive value is displayed).

Turning the maximum and minimum value menu on and off

A menu can be displayed in the soft key menu for updating the maximum and minimum measured values.

ON	The menu is displayed. The minimum and maximum values are also displayed.
OFF	The menu is not displayed. The maximum and minimum values are also not displayed.

The maximum and minimum values can be updated to the latest data from the menu.

Offset

You can add a specified value (the offset value) to measured input optical power values and display the results as measured values.

The range is –9.900 dB to 9.900 dB.

Threshold

You can set upper and lower threshold values and determine whether or not the measured values fall within them.

- The range for upper and lower threshold values is –80 dBm to 40 dBm. The upper limit must be greater than the lower limit.
- If the measured values are less than or equal to the upper limit and greater than or equal to the lower limit, the corresponding bar graph is displayed in green.
- If the measured values exceeds the upper limit or fall below the lower limit, the corresponding bar graph is displayed in red.

Holds the measured value display

When you press the HOLD soft key, the measured values, bar graph, maximum value, minimum value, and the on/off state of the maximum and minimum value display are no longer updated. The value at the time that you pressed the HOLD soft key remains displayed. To release the hold, press the HOLD soft key again.


Zero set

Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes.

Performing zero set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

Loss test

The loss test loops back the other end of the optical fiber cable being measured to measure the optical power emitted by the light source of this instrument with the optical power meter of this instrument. This allows you to check the level of loss that occurs relative to the optical output power value of the light source.



Saving the results of optical power measurements for multi-fiber cables

Skip

When Skip is selected, the corresponding core is not measured. By specifying Skip on cores that do not need to be measured, you can save time.

Saving data

When you execute a save operation, up to three sets of data can be saved temporarily in the save area of the specified core number.

For details on saving data to files, see section 9.4.

Deleting data

You can delete data from the save areas for each core number individually or all cores at once.

Starting core number

Set the starting core number in the following range.

1 to 9900


Tape number type

By setting the tape number type, you can the tape number accordingly.

The core number display will be as follows.

OFF: 1, 2, 3, ...

a-d(4): 1a, 1b, 1c, 1d, 2a, 2b, 2c, 2d, 3a, 3b, 3c, 3d, ...



7.4 Using the Optical Power Meter (/SPM, /HPM option)

Number of cores or tapes

Set the number of cores or tapes in the following range.

Tape number type	Number of cores or tapes
Off	10 to 100 cores (in steps of 10)
a-b(2)	Number of tapes: 1 to 50
a-c(3)	Number of tapes: 1 to 33
a-d(4)	Number of tapes: 1 to 25
a-e(5)	Number of tapes: 1 to 20
a-f(6)	Number of tapes: 1 to 16
a-g(7)	Number of tapes: 1 to 14
a-h(8)	Number of tapes: 1 to 12

Note

The data saved in the save area of the core number list can be consolidated and saved in a single CSV file. The data that you save can be edited in a spreadsheet application. The file can also be loaded into the instrument.

Save data format

Measured results are saved in the following CSV format.

Company Yokogawa Test and Measurement Corporation

Model AQ7292A
Function PowerMeter

Start No 1

Tape No Type off
Number Of Fibers 100

Data storage settings

Data Ver1.01

Core No	nm	Data	Unit	Modulation	Reference(dBm)	Offset(dB)	Date	SKIP
1	1310	-9.886	dBm	CW	0	0	2025/2/1 19:05	SKIP
1	2							
1	3							
2	1							
2	2							SKIP
2	3							SKIP
2								SKIP

Measurement

Core number

Up to three sets of data can be stored for each core. In this example, a set of data is stored in core number 1

Example in which core number 2 has been skipped

Logging measurement of optical power values

Executing logging and saving

While the optical power meter screen is displayed, the instrument is constantly measuring the optical power. To save the measured values, execute logging.

- Press the Logging START soft key to start logging. While logging, the Logging START soft key on the menu changes to Logging STOP.
- When the specified number of entries have been logged or when you press the Logging STOP soft key, logging stops. The Logging STOP soft key on the menu changes to Logging START, and the file save screen appears.
- The logging results can be saved in csv format.

Interval

Set the interval for logging the measured values from the following.

500 ms, 1 s, 2 s, 5 s, 10 s

Times

Set the number of times to log in the following range.

10 to 36000

Graph display of logging data

Set Display to Logging to display the measured values on a graph in real time during logging.

Logging results that have been saved in CSV format cannot be displayed on a graph.

- **Selecting the cursor**

You can switch between the two cursors (C1 and C2) that are displayed on the screen. If the selected cursor is outside of the display area, the display position is automatically changed so that the cursor is in the center of the screen. If the cursor is at the left or right edge of the screen, because the sections that are outside of the measurement range cannot be displayed, even if you switch to the other cursor, the selected cursor will not be displayed in the center of the screen.

- **Auto zoom**

The vertical zoom factor is set automatically so that all the logging data is displayed.

The median value between the maximum and minimum of the logging data is the center position on the screen.

If there is no logging data, auto zoom is not performed.

- **Zoom initialization**

Zoom initialization returns the vertical and horizontal zoom factors to $\times 1$.

- **Zooming in and out**

You can press the arrow keys to zoom the displayed graph in or out. The graph is zoomed at the cursor position.

Up and down arrow keys: Zooms in or out vertically. (The up arrow key zooms in; the down arrow key zooms out.)

Zoom factors are $\times 1$, $\times 2$, $\times 5$, $\times 10$, $\times 20$, and $\times 50$.

Left and right arrow keys: Zooms in or out horizontally. (The right arrow key zooms in; the left arrow key zooms out.)

Zoom factors are $\times 1$, $\times 2$, $\times 5$, $\times 10$, $\times 20$, and $\times 50$.

You cannot zoom in on the graph so much that there are less than 11 logging data points on the screen.

Note

The logging results are saved in a CSV file, so you can open it with a spreadsheet application. However, CSV files cannot be loaded in to this instrument.

7.4 Using the Optical Power Meter (/SPM, /HPM option)

Saving logging data

Logging results are saved in the following CSV format.

Company Yokogawa Test and Measurement Corporation	
Model AQ7292A	
Function Logging	
Start Date	Mon Dec 23 09:34:26 2024
Measurement start date and time	
Wavelength	1550
Modulation	CW
Offset	0
Unit	dB
Interval(ms)	1000
Measurement Number	10
Logging Count	10
Reference	10000
Measurement conditions	
-6553	
-6584	
-6973	
-6713	
.	
Measurement result	
(When the unit is dB or dBm,	
1000 times the actual	
measurement value is recorded.	
Example: actual measured value	
of -6553 is -6.553 dB)	

7.5 Using the Power Checker (/PC option)

Procedure

Displaying the power checker screen

1. Press **MENU**. A MENU screen appears.
2. Tap the **Power Checker** icon. A power checker screen appears.


MENU screen



Power Checker Screen

Sets the reference value to the current measured value (–80 to 40dBm). The reference value appears if you press the DREF soft key or set the unit to dB.

Enter a value and assign it to the reference value (–80 to 40dBm) The reference value appears if you press the DREF soft key or set the unit to dB. Tapping the value or the word Reference displays a number input screen.



Executing a zero set


3. Remove the optical fiber cables from the instrument and close the OPM port cover, or make sure that the power meter section is not receiving any light, and then tap **ZERO SET**.

Measuring the optical power

4. Set the wavelength.
5. Connect an optical fiber cable to the OTDR port (Port1). The measured value is displayed on the power checker screen. For the position of the OTDR port, see “Component Names and Functions” in the Getting Started Guide, IM AQ7290-02EN.

Setup using the utility menu

On the OTDR, light source, power meter, or visible light source setup screen, tap **OPC** (power checker) on the Utility menu. A power checker setup screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

Explanation

Wavelength

The photodetector of the optical power checker has wavelength sensitivity characteristics. The photodetector corrects the sensitivity according to the set wavelength and measures optical power more accurately. Select the wavelength from the following:

1310 nm, 1490 nm, 1550 nm, 1625 nm, 1650 nm

Unit

Set the optical power display unit from the following.

dB (absolute value), dBm (absolute value), W (absolute value)

- Unit W is preceded by a prefix m (10^{-3}), μ (10^{-6}), n (10^{-9}), or p (10^{-12}).
- The following relation holds between the absolute display unit dBm and W.

$$P_{\text{dBm}} = 10 \times \log (P_{\text{w}} \times 10^3)$$

P_{dBm} : optical power (unit dBm), P_{w} : optical power (unit W)

Reference value

You can set a reference value and display the relative measured values (the differences from the reference value).

- When you press the DREF soft key, the displayed measured value becomes the reference value. From this point, relative values will be displayed. The unit changes to dB.
- When you press the DREF soft key or set the unit to dB, the Reference box appears on the power meter screen.
- You can set the reference value in the Reference box. The range is -80 dBm to 40 dBm.
- When you set the unit to dBm or W, the Reference box disappears, and the absolute measured values will be displayed.

Threshold

You can set upper and lower threshold values and determine whether or not the measured values fall within them.

- The range for upper and lower threshold values is -80 dBm to 40 dBm (when the unit is dBm). The upper limit must be greater than the lower limit.
- If the measured values are less than or equal to the upper limit and greater than or equal to the lower limit, the corresponding bar graph is displayed in green.
- If the measured values exceeds the upper limit or fall below the lower limit, the corresponding bar graph is displayed in red.

Zero set

Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes.

Performing zero set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

7.6 Using the Fiber Inspection Probe

Procedure

Displaying the fiber inspection probe screen

1. Press **MENU**. A MENU screen appears.
2. Tap the **Fiber Inspec Probe** icon. A fiber inspection probe screen appears.

MENU screen




Probe model

When a probe is automatically recognized by the instrument, the model name of the probe is displayed on the screen. If the probe is not recognized, "Unknown" is displayed. If "Unknown" is displayed, pass/fail judgment is not possible.

Fiber inspection probe screen

File name of the saved still image



File name of the next still image to be saved

Data save location folder

Fiber surface image

Displays the image in real time

Holds the image display

Executes pass/fail judgment

A pass/fail judgment is performed, and the result (summary) is displayed.

Displays results

Displays the judgment results (detail). This is available when a pass/fail judgment is executed.

Executes saving


Still image is saved to a BMP file. This is available for still images. For the file save destination, see section 9.4. For the procedure to set the file name, see section 3.4.

Set the network (station mode).

Set this when using a wireless LAN fiber inspection probe for inspection. (See page 7-26.)

Performing setup

3. Press **SETUP**.
4. Tap **Fiber Surface Pass/Fail Setup**. A Fiber Surface Pass/Fail Setup screen appears.



Note

If you change threshold setting after setting the judgment reference, "User" is displayed for the judgment reference setting to indicate that the reference is user defined.

Connecting the fiber inspection probe

3. Connect the fiber inspection probe to the USB port (Type-A) of this instrument.
4. Connect the probe of the fiber inspection probe to the end face of the optical fiber cable.

Note

For instructions on how to use the fiber inspection probe, see the user's manual for the probe.

Connecting a wireless LAN-compatible fiber inspection probes


3. On the fiber inspection probe screen of step 2, tap **Network Setup**.
A network setup screen for station mode appears. These are the same settings as the network settings in system setup. For details, see section 10.5.

Set the ID name (SSID).

A character input screen appears. For information about how to enter text, see section 2.5.

Set the authentication password.


A character input screen appears. For information about how to enter text, see section 2.5.



4. Tap **Connect to Access Point** to connect to the fiber inspection probe.


Executing pass/fail judgment

- Press the **Still Image** soft key.
- Press the **Judge** soft key. A judgment is performed, and the result (summary) is displayed. Before executing pass/fail judgment, adjust the fiber inspection probe knob to focus on the image.



Displaying judgment results (Details)

- Press the **Result** soft key. The inspection results are displayed.




Note

Pass/fail judgment complies with IEC 61300-3-35.


Using the fiber inspection probe from the Utility menu

On the OTDR, light source, power meter, or visible light source setup screen, tap **FIP** (fiber inspection probe) on the Utility menu. A fiber inspection probe screen appears.



Displaying the still image

Tap **Still Image**. A still image display screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

Explanation

Connecting a fiber inspection probe

Hot-plugging is supported: you can connect or disconnect the USB device at any time, regardless of whether the instrument is on or off.

If you connect the USB fiber inspection probe while the instrument is on, the instrument will automatically recognize the probe.

For cautions regarding connecting the probe, see Note in section 9.1.

For information about compatible fiber inspection probes, contact your nearest YOKOGAWA dealer.

Connecting a wireless LAN-compatible fiber inspection probes

When connecting a wireless LAN fiber inspection probe to this instrument, use the station mode of the instrument's WLAN settings. Connect the fiber inspection probe to the instrument using the SSID and password set in station mode.

Holding the image display

The still image size is VGA for both the USB2.0 and USB1.1 fiber inspection probes.

Note

If a USB2.0 fiber inspection probe is connected, it will take some time to display the still image.

Saving data

You can save the still image. Video cannot be saved.

Pass/fail judgment (/FST option)

Configure the pass/fail judgment.

- **Selecting the optical fiber cable**

Select the type of optical fiber cable to be judged.

SM: Single mode

MM: Multi mode

- **Selecting the judgment reference**

Select the ferrule's polished surface of optical fiber cable to be judged. The judgment reference varies depending on the polished surface.

UPC, SPC: For spherical surface polishing

APC: For angled spherical surface polishing

User: When judgment execution and threshold are set manually (when any of the settings is changed, the judgment reference is automatically set to User (UPC User, SPS User, or APC User for SM)). When you select the polished surface, the judgment execution on/off and scratch or defect judgment threshold values explained below are set automatically.

- **Turning judgment execution on or off**

Judgment of scratches and defects are executed separately by size. The size value is fixed.

Clearing the check box turns off the judgment execution. Pass/fail judgment is not performed on scratches or defects whose check box has been cleared.

- **Setting the scratch or defect judgment threshold values**

Set the number of scratches and defects that will be judged as fail. The setting range is 0 to 100.

If the judgment execution check box explained above is cleared, No Limit is displayed.

Judgment results (Summary)

Displays the judgment results and the number of detected scratches (Scratch) and detects (Defect). The detection count is displayed separately for the core, cladding, and contact areas. The judgment will be fail if there is even only a single fail (×) judgment.

<input checked="" type="checkbox"/>	Scratches	Core	Cladding	Contact	Fiber Type	SM
	Defects	0	2	0	Standard	SPC
		0	0	0		

Judgment result
Pass: ✓ (green)
Fail: × (red)

**Number of detected
 scratches and defects**

Judgment results (Details)

For each of the core, cladding, and contact areas, the threshold (Setting) and detection count (Result) are displayed.

If the detection count (Result) exceeds the threshold (Setting), the judgment will be fail (×).

Scratches and defects are detected separately by size.

Example

Scratch(≤3μm): Scratches that are 3 μm or less

Scratch(>3μm): Scratches that exceed 3 μm

Defect(2 to 5μm): Defects from 2 μm to 5 μm

Saving data

The judgment result image and a judgment result file (including judgment settings) in CSV format are saved with the same file name (excluding the extension). Video cannot be saved.

Judgment result syntax (csv file)

BMP File 0000.BMP : File name
 Result PASS : Judgment result
 Fiber Type SM : Optical fiber cable type
 Standard SPC : Judgment reference type

Area	Kind	Condition	Setting	Result (Detections)	Judge	
Core	Scratch1	<=3um	2	1	Pass	Judgment of scratches that are 3 μm or less in length in the core area
Core	Scratch2	>3um	0	2	Fail	Judgment of scratches that exceed 3 μm in length in the core area
Core	Defect1	Any	0	3	Fail	Defect judgment in the core area
Core	Defect2	---	NoLimit	4		
Cladding	Scratch1	<=3um	NoLimit	5	Pass	Judgment of scratches that are 3 μm or less in length in the clad area
Cladding	Scratch2	>3um	3	6	Fail	Judgment of scratches that exceed 3 μm in length in the clad area
Cladding	Defect1	<5um	NoLimit	7	Pass	Judgment of defects that are 5 μm or less in length in the clad area
Cladding	Defect2	5 to 10um	5	8	Fail	Judgment of defects that are 5 μm to 10 μm in length in the clad area
Cladding	Defect3	>10um	0	9	Fail	Judgment of defects that exceed 10 μm in length in the clad area
Contact	Scratch	Any	NoLimit	10	Pass	Scratch judgment in the contact area
Contact	Defect1	<20um	NoLimit	11	Pass	Judgment of defects that are 20 μm or less in length in the contact area
Contact	Defect2	20 to 30um	5	12	Fail	Judgment of defects that are 20 μm to 30 μm in length in the contact area
Contact	Defect3	>30um	0	13	Fail	Judgment of defects that exceed 30 μm in length in the contact area

7.7 Controlling the Optical Switch Box



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables from this instrument or from the optical switch. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.


Procedure

Displaying the optical switch screen

The optical switch screen is opened from the Utility menu.

Displaying the OTDR screen

1. On the OTDR, light source, power meter, or visible light source setup screen, tap **OSW** (optical switch) on the Utility menu. An optical switch setup screen appears.



The features shown on the Utility menu and their display positions vary depending on the settings. For details, see section 7.1.

2. Tap the number of the control screen. The optical switch changes to the optical port corresponding to the number you tapped.

Controlling the optical switch during multi-fiber measurement (OTDR)

Setting “Linkage OSW control” to ON in the multi-fiber measurement project settings causes the optical switch to change automatically when you select a measurement target core number and execute a measurement. The optical switch control screen does not appear. For details, see section 8.2.

8.1 Displaying a Map of the Line Configuration and Events (OTDR Smart Mapper)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the OTDR Smart Mapper screen

1. Press **MENU**. A MENU screen appears.


8.1 Displaying a Map of the Line Configuration and Events (OTDR Smart Mapper)

2. Tap the **OTDR Smart Mapper** icon. An OTDR Smart Mapper screen appears.

MENU screen



OTDR Smart Mapper screen



Set the number of splitter stages and the number of branches (see the next page).

Save data directly.

Set the wavelength (see section 3.1).

Set the distance range (see section 3.1).

Set the averaging conditions (see section 3.1).

Set the index of refraction (see section 3.1).

Set the attenuation (see section 3.1).

Set the pulse width (see section 3.1).

Performing setup

- Press **SETUP**.

Measurement conditions

- Press the **Measure Setup** soft key. The Meas Setup screen appears.

Set the distance range.
Set the wavelength.

Set the pulse width.
You do not need to set this when the distance range is set to AUTO.

Turns the fiber-in-use alarm on or off

Turns connection check on or off

Set auto save.

Initializes the measurement settings

Set the number of splitter stages.

- Setting the pulse width

- Tap **Pulse Width**. A pulse width setup screen appears.
Select the pulse width. setup method (AUTO, Manual).

Set the pulse width.
You can edit this when the pulse width setup method is manual.

- Setting the network configuration

Set the number of splitter stages and the number of branches.

- Tap **Network Configuration**. A Network Configuration screen appears.
Select the number of splitter stages.

Set the number of branches of each stage.

Note

- Pulse width setup is a feature for individually setting the three pulse width values explained in “Viewing and editing waveforms in trace mode” on page 8-7. For the pulse width feature used in Adapt Trace, see “Smart Mapper” in section 1.7.
- For details on the setup screen that appears when you select a setting and the descriptions of the settings other than those of pulse width and network configuration, see section 3.1.

Analysis conditions

4. Press the **Analysis Setup** soft key. The Analysis Setup screen appears.


Set the splice loss (0.01dB to 9.99dB).

Set the end of fiber (AUTO, 3dB to 64dB).

Set the launch fiber. (See section 3.2.)

Set the return loss (20dB to 70dB).

Set the splitter loss. (See section 3.2.)



Set pass/fail judgment.
(See section 3.2.)

Set the approximation method.

Executes initialization
Press to reset the analysis settings to their factory defaults.

Set the approximation method (marker).

Set the backscatter level.

Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.2.

OTDR setup (display setup)

4. Press the **OTDR Setup** soft key. A OTDR setting window appears.

Set the total loss calculation method (Cumul-Loss, Loss between S and E).

Cumulate: Integrated value of events

Between two points: Loss between S and E

Turns marker information display on or off

Displays on the screen the distance and loss value at the marker position.


Turns ghost cursor display on or off

This is for checking secondary reflections.

Set the cursor display method.

Set the marker type.

Select the reflection display.



Turns approximated line display on or off

Displays an approximated line for waveform events.

Distance decimal places

Turns the cursor dB display on or off

Locks screen operations

Screen operations can be locked after a given time elapses.

dB decimal places

Calculation method for total return loss

Set the cumulative loss type.

Select the cumulate loss calculation method.

Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.3.


File conditions

4. Press the **File Setup** soft key. A file setup screen appears.

Set the report format. (See section 3.4.)

Set comments for file names. (See section 3.4.)

Set the file name. (See section 3.4.)



Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.4.


Executing an averaged measurement

5. Press **AVG**. A measurement will begin.

Measurements are performed four times using the set averaging conditions. A wait screen is displayed while the measurement is in progress.

Also, during measurement, a mark appears at the top of the display to indicate that the laser light is on. When averaged measurements are completed, measurement is stopped automatically, event analysis is executed, and the analysis results are displayed using icons on the screen. If you press AVG again during averaged measurement, the measurement is aborted. When you abort the measurement, the measurement results are not displayed.


Map display of the measurement results

**Note**


- The icon display method is the same as the display in MAP mode of event analysis in section 1.4.
- For details on event information display, see “Event analysis” in section 4.1.

Viewing and editing waveforms in trace mode

7. Tap the **TRACE/MAP** button to set the data display screen to TRACE mode.
A waveform view/edit screen appears.




Waveform view/edit screen

**Note**

For details on event information display, see “Event analysis” in section 1.4.

Editing waveforms

3. Press the **Waveform Edit** soft key. A soft key menu appears for operating the composite waveform display.



Explanation

Measurement conditions

For details on the measurement conditions, see section 3.1.

Wavelength

The wavelengths that you can specify vary depending on the model.

Model	Wavelength
AQ7292A	1310 nm, 1550 nm
AQ7293A	1310 nm, 1550 nm
AQ7294A	1310 nm, 1550 nm
AQ7293F	1310 nm, 1550 nm, 1650 nm
AQ7293H	1310 nm, 1550 nm, 1625 nm
AQ7294H	1310 nm, 1550 nm, 1625 nm

Distance range

Select a distance range from the following options.

AUTO, 100 m, 200 m, 500 m, 1 km, 2 km, 5 km, 10 km, 20 km, 30 km, 50 km, 100 km

Network configuration

Set the number of splitter stages and the number of branches of each stage.

Select the number of splitter stages from Unknown, 1, and 2.

Select the number of branches from Unknown, 2 Branches, 4 Branches, 8 Branches, 16 Branches, 32 Branches, and 64 Branches.

Analysis

For details on analysis, see section 3.2.

Approximation method

The following two types of approximation methods are available.

- LSA: The instrument calculates the loss between two points by using the least squares method on all the data between the two points.
- TPA: The instrument uses the difference between the levels of the two specified points to calculate the loss.

OTDR setup

Marker mode

Select whether to display markers or lines on the waveform screen.

Cumulate loss type

Cumulate loss: The integrated value of the splice losses at each event from measurement reference point S is displayed.

Loss between S and E: The loss (TPA approximation method) between the measurement reference point (S) and the end of fiber (E) is displayed.

dB decimal

Set the number of decimal places to display.

**.: 1 decimal place

**.: 2 decimal places

**.: 3 decimal places

Reflection display

Select the value to display in the calculation result display area of the waveform display screen.

Return loss: The ratio of the incident optical power level and the reflected optical power level is displayed.

Reflection level: The reflected optical power level is displayed.

Cursor

Set the cursor display to crosshair or line.

Total return loss

Select whether to include the return loss value at the end of fiber (E) in the total return loss.

Include END: The value at end of fiber (E) is included in the total return loss.

Exclude END: The value at end of fiber (E) is not included in the total return loss.

Distance decimal

Set the number of decimal places to display.

**.: 3 decimal places

**.: 4 decimal places

**.: 5 decimal places

Event icon display

The following events are displayed using icons.



**Start point
(Near-end
reflection)**



Splice



**Connector
(PC connector)**



**Connector
(APC
connector)**



Bend



Splitter



**End point
(Fresnel
reflection)**

8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the multi-fiber measurement screen

1. Press **MENU**. A MENU screen appears.
2. Tap the **Multi Fiber Project** icon. A multi-fiber measurement screen appears.

MENU screen



8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)

Multi-fiber measurement screen

The background color of the cell indicates the storage status of the measurement data and the pass/fail judgment result.

If only the measurement results of either wavelength are stored during multi wavelength measurement, only half of the cell background color is displayed. If the measurement results of both wavelengths are stored, the background color of the cell is displayed in its entirety.

Gray: Measured data saved

Green: Measured data saved, pass judgment

Red: Measured data saved, pass judgment

Core number
Using the arrow keys or the rotary knob, move the cursor to the cell of a core number you want to measure.

▲ **Measured data of optical power already saved**

▼ **Observation data of the fiber end face already saved**

Core numbers set to Skip appear dimmed.

The save destination drive/folder name/project name of the current project

The number of cores whose measurement results have been saved

New Project

You can either initialize the current settings and create a new project or duplicate the current settings and create a new project. See page 8-27.

Wavelength

Set the wavelength for the real-time measurement or averaged measurement.

You can select from the wavelengths set in the setup measurement conditions.

Clears the check mark (when measured data has been saved)

Deletes the measurement data of the selected core number and clears the result display

Confirm the waveform.

Displays the OTDR waveform screen showing the results of a real-time or averaged measurement
See page 8-19 or 8-21.

When measured data is not saved

Skip

Sets whether to skip the measurement of the selected core number

The screenshot displays the Multi-Fiber Measurement interface. At the top, a status bar shows the date and time. Below it, a grid of core numbers (1-96) is shown, with some cells highlighted in gray, green, or red. A cursor is positioned over core number 1. To the right of the grid, a sidebar contains buttons for 'New Project', 'Wavelength', 'All', 'Delete Check Mark', and 'Open Trace'. Below the grid, a section labeled 'File Name: 1310nm0013.SOR / Label:' shows measurement conditions: Wavelength (1310nm, 1550nm), Distance (20km), and Pulse (100ns). A waveform plot is displayed below this section. To the right of the waveform, a section labeled '[FP]' shows test data of the fiber end face. At the bottom, a 'Preview area' shows the core number at the cursor location.

Waveform data
Measured data of the optical power meter


Test data of the fiber end face

Measurement conditions of the waveform data
Displays the set wavelength, distance, and pulse width values. Check marks appear next to the wavelengths for which measured data is saved.

Preview area
Information about the core number at the cursor location

Menu for executing measurements

When you tap a core number on the multi-fiber measurement screen, a menu appears for executing measurements. The displayed content of the menu varies depending on whether there is measurement data that has been saved.



Performing setup

- Press **SETUP**.

Project setup

- Press the **Project Setup** soft key. A project setup screen appears.

Set the number of cores or tapes (1 to 2000).

If you select the Enable to create over 100 fibers check box, you can set the number of fibers to 100 or more.

Selected: The selectable range of number of cores is 100 to 2000.

Not selected: The selectable range of number of cores is 1 to 100 (the setting resolution varies depending on the number of units).

Set the starting core number (1 to 9900).


Set the project name.

A character input dialog box will open.

Select the drive.

Selectable when auto save is ON.

Set the tape number.



Set the label.

The same label can be entered for all cores (see section 3.4).

Set the file name type.

See the next page.

Project information

You can view the project settings and measurement settings in a table (see the next page).

Set OSW control.

The optical switch can be changed automatically when you select the numbers of the cores to be measured and execute a measurement (see page 8-29).

Set the number of cores in each division.

You can set this when the tape number is set to OFF (see page 8-29).

Note

When you change the measurement core information, all the previous core measurements are discarded.


- **Setting the file name type**

5. Tap **File Name Setup**. A file name setup screen appears.

Set the file name type.


(Project Name, ID No., Wavelength, Distance Range, Pulse Width, Attenuation, Average Method, Comment 1 to Comment 10, Company Name, Name, Cable ID, Fiber ID, Cable Code, Originating Loc (A), Terminating Loc (B), OSW CH number)

Set the items that will be displayed into parts ① to ⑩ of the file name.



- **Displaying project information**

5. Tap **Project Information**. The contents of the current project are displayed.



Measurement conditions

4. Press the **Measure Setup** soft key. The Meas Setup screen appears.

Set the sample interval.



Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.1.

Analysis conditions

4. Press the **Analysis Setup** soft key. The following screen appears.

The screenshot shows the 'Analysis Setup' screen with the following settings and callouts:

- Connector Loss/Splice Loss:** 0.10dB. Callout: **Set the end of fiber (AUTO, 3dB to 64dB).**
- End of Fiber:** AUTO. Callout: **Set the splice loss (0.01dB to 9.99dB).**
- Macro Bending:** OFF. Callout: **Turns macro bending on or off**
- Launch Fiber Setting:** OFF. Callout: **Turns launch fiber on or off**
- Approx. Method(Marker):** TPA. Callout: **Set the approximation method (marker).**
- IOR/Backscatter Level:** (Callout: **Set the IOR/backscatter level. See section 3.2.**)
- Return Loss:** 70dB. Callout: **Set the return loss (20dB to 70dB).**
- Splitter Loss:** (Callout: **Setting the Splitter Loss See section 3.2.**)
- Pass/Fail Judgement:** OFF. Callout: **Turns the pass/fail judgment on or off See section 3.2.**
- Approx. Method(Event):** LSA. Callout: **Set the approximation method.**
- Default:** (Callout: **Executes initialization Press to reset the analysis settings to their factory defaults.**)

The right sidebar shows the navigation menu with 'Analysis Setup' selected.

Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.2.

OTDR setup (display setup)

- Press the **OTDR Setup** soft key. The following screen appears.

Turns marker information on or off

Displays on the screen the distance and loss value at the marker position.

Turns ghost cursor on or off
Checks secondary reflections.

Set the marker type.

Turns approximated line display on or off

Displays an approximated line for waveform events.

The screenshot shows the 'OTDR Setup' screen with the following settings and callouts:

- Marker Mode:** Marker (Callout: Turns marker information on or off)
- Ghost Cursor:** OFF (Callout: Turns ghost cursor on or off)
- Marker Info.:** ON (Callout: Turns marker information on or off)
- Total Loss Mode:** Cumul-Loss (Callout: Set the cumulative loss type)
- Cumul-Loss Type:** Type1 (Callout: Select the cumulate loss calculation method)
- dB Decimal:** **, *** (Callout: dB decimal places)
- Approx. Line:** OFF (Callout: Turns approximated line display on or off)
- Reflection term:** Return Loss (Callout: Select the reflection display)
- Cursor:** CROSS(+) (Callout: Set the cursor display method)
- Total RL Mode:** Exclude END (Callout: Calculation method for total return loss)
- Show END Point Loss:** OFF (Callout: Turns END point loss on or off)
- Distance Decimal:** **, ***** (Callout: Distance decimal places)
- Cursor Value:** OFF (Callout: Turns the cursor dB on or off)
- Operation Lock Setup:** (Callout: Operation Lock Setup - Locks screen operation)

Set the calculation method for total loss

Note

For details on the setup screen that appears when you select a setting and the descriptions of the settings, see section 3.3.

Performing averaged measurements

After setting the SETUP menu, close the setup screen, and return to the multi-fiber measurement screen in step 2.

- Tap the core number you want to perform an averaged measurement on. A menu appears for executing a measurement.

Example of measuring core number 25

Dest.	Folder	Int. Memory/MPJ/NewProject	1	2	3	4	5	6	7	8	9	10
11	12	13	14	RealTime	16	17	18	19	20			
21	22	23	FIP	25	OPM	27	28	29	30			
31	32	33	Average	36	37	38	39	40				
41	42	43	44	45	46	47	48	49	50			
51	52	53	54	55	56	57	58	59	60			
61	62	63	64	65	66	67	68	69	70			
71	72	73	74	75	76	77	78	79	80			

OTDR feature (average)

- Tap the **Average** menu. Averaged measurement begins.

The measured waveform is displayed on the screen, and while the measurement is in progress, a laser emitting mark is displayed at the top of the screen.

Core number being measured

Averaged measurement in progress indication

The OTDR port emitting light

Laser on indication

OTDR waveform screen



Marker operation

See section 6.1.

Event analysis

Cannot be selected during measurement.

Set labels.

See section 2.5.

Wavelength*

Displays the wavelength currently being measured

Returns to the list*

Returns to the multi-fiber measurement screen (core selection screen)

Cannot be controlled on the OTDR waveform screen of multi-fiber measurement. When event search is set to on in the setup measurement conditions, the analysis results are displayed when the measurement is complete.

* This setting is valid when auto save is on.

Note

- If Wavelength on the multi-fiber measurement screen is set to "All," measurement is executed using multiple wavelengths for each core.
- If you enter the label characters in the label setting of the project setup screen, the same label characters can be entered at once for all cores.
- You can also execute an averaged measurement using the AVG key.

8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)

When Auto Save is set to ON in the measurement (Measure) conditions of setup

When measurement is complete, the measured results are automatically saved. The screen returns automatically to the multi-fiber measurement screen, and pass/fail judgment indications appear in the core number cells whose measurement results have been saved.

When Auto Save is set to OFF in the measurement (Measure) conditions of setup


When measurement is complete, the measured results are not automatically saved. The OTDR waveform screen will be displayed. To return to the multi-fiber measurement screen, press the Return to Multi-Core FiberMenu soft key. When returning to the multi-fiber measurement screen, a message appears for confirming the saving of the measured results. If necessary, save the measured results.

Soft key menu when auto save is OFF and averaged measurement is complete

▶ OTDR	
Display List	Display Switches the event analysis result display (see section 6.2)
Current SM 1550nm	Current trace Switches the wavelength of the current trace (when measuring multiple wavelengths)
◀ Event Edit/Fix	Edit or fix events. See section 6.2.
◀ 2-point Marker	2-point markers Set the 2-point marker of event analysis (see section 6.2).
Return to Multi-Core FiberMenu	Returns to the list Returns to the multi-fiber measurement screen (core selection screen)

8-21


5. Tap the core number you want to perform a real-time measurement on. A menu appears for executing a measurement.



- Core number being measured**

The OTDR port emitting light

OTDR waveform screen



7. Press **REAL TIME**. Real-time measurement will stop.
To return to the multi-fiber measurement screen, display the soft key menu, and press the Return to Multi-Core FiberMenu soft key. When returning to the multi-fiber measurement screen, a message appears for confirming the saving of the measured results. If necessary, save the measured results.

8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)

Soft key menu after real-time measurement completion

▶ OTDR	
◀ Marker	Marker See section 6.1.
◀ Event Analysis	Event analysis See section 6.2.
◀ Section Analysis	Section analysis See section 6.1.
Wavelength	Set the wavelength. Switches the wavelength to perform real-time measurement
SM 1310nm	
Return to Multi-Core FiberMenu	Returns to the list Returns to the multi-fiber measurement screen (core selection screen)

Note


- In real-time measurement, measured results are not automatically saved.
 - If Wavelength on the multi-fiber measurement screen is set to "All," measurement of "Waveform 1" is executed. To measure "Wavelength 2" and later, save the measured results of "Waveform 1," and then press the Wavelength soft key in the soft key menu to switch the wavelength.
 - If you enter the label characters in the label setting of the project setup screen, the same label characters can be entered at once for all cores.
-

Measuring the optical power

After setting the SETUP menu, close the setup screen, and return to the multi-fiber measurement screen in step 2.

- Tap the core number you want to measure the optical power of. A menu appears for executing a measurement.

Optical power meter (OPM)



Example of measuring core number 25

- Tap the **OPM** menu. A power meter screen appears.

For details on how to operate the optical power meter, see section 7.4.

To return to the previous screen, tap Return to Multi-Core FiberMenu on the soft key menu.

Core number being measured



SETS the reference to the currently displayed measured value

See section 7.4.

Holds the measured value display

See section 7.4.

Deletes the measurement data of the core number

See section 7.4.

Saves data

A screen appears for saving the results of optical power measurements for multi-fiber cables. See section 7.4.

Returns to the list

Returns to the multi-fiber measurement screen (core selection screen)

Measured results that have been saved

Performing setup

- Press **SETUP**. An optical power meter setup screen appears.

- Tap the **Power Meter** tab. A power meter screen appears.

For details on how to set up the optical power meter, see section 7.4.

8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)

Executing a zero set

9. After step 8, close the optical power meter screen. The screen returns to the power meter screen.
10. Remove the optical fiber cables from the instrument and close the OPM port cover, or make sure that the power meter section is not receiving any light, and then tap **ZERO SET**.

For details on how to perform zero set on the optical power meter, see section 7.4.

Measuring the optical power

11. Set the wavelength.
12. Connect an optical fiber cable to the OPM port. The measured value is displayed on the power meter screen. For the position of the OPM port, see “Component Names and Functions” in the Getting Started Guide, IM AQ7290-02EN.

Using the fiber inspection probe

After setting the SETUP menu, close the setup screen, and return to the multi-fiber measurement screen in step 2.

5. Connect the fiber inspection probe to the core of the optical fiber cable you want to inspect.
6. Tap the core number that you are connecting the fiber inspection probe to. A menu appears for executing a measurement.

Fiber inspection probe (FIP)

Dest. Folder Int. Memory/MPJ/NewProject										Multi Fiber Project		
1	2	3	4	5	6	7	8	9	10	New Project		
11	12	13	14	Realtime	16	17	18	19	20			
21	22	23	FIP	25	OPM	27	28	29	30	Wavelength	All	
31	32	33	34	Average	36	37	38	39	40			
41	42	43	44	45	46	47	48	49	50	Skip		
51	52	53	54	55	56	57	58	59	60			
61	62	63	64	65	66	67	68	69	70			
71	72	73	74	75	76	77	78	79	80			


Example of measuring core number 25

7. Tap the **FIP** menu. A fiber inspection probe screen appears.

For details on how to use the fiber inspection probe, see section 7.6.

To return to the previous screen, tap Return to Multi-Core FiberMenu on the soft key menu.

Core number being measured



Displays the image in real time
See section 7.6.

Holds the image display
See section 7.6.

Executes pass/fail judgment
See section 7.6.

Executes saving
Press the soft key to save the still image to a BMP file. For the file save destination, see section 9.4. For the procedure to set the file name, see section 3.4.

Returns to the list
Returns to the multi-fiber measurement screen (core selection screen)


Previewing measured results

Using the arrow keys or the rotary knob, move the cursor to the core number cell of the multi-fiber measurement screen. The preview area at the bottom of the screen displays the measurement conditions, measurement date, and the measurement result waveform of the selected core number. For details on pass/fail judgment, see section 3.2.

Real-time/averaged measurement preview


- **When pass/fail judgment is set to OFF**

Check marks appear next to the wavelengths for which measured data is saved.




- **When pass/fail judgment is set to ON (/FST option)**

Judgment result marks appear next to the wavelengths for which measured data is saved.



- **Optical power measurement results and fiber inspection probe observation results**

The optical power of the measured wavelength is displayed. An image data is displayed for the fiber inspection probe observation results.




Creating a new project

3. Continuing from step 2 on 8-11, click the **New Project** soft key. A character input dialog box will open.
4. Enter the project name by following the procedure in section 2.5.
5. Tap **Enter** in the character input dialog box displays the following screen.

Initialize setting

Initializes the settings of the current project and creates a new project



Creates without changing the settings

Duplicates the settings of the current project to create a new project

Cancel

Cancels the creation of a new project.

Set the project save destination.

(Int.Memory, SD Card, USB Memory 1, USB Memory 2)

6. Tap **Initialize setting** or **Takeover current setting**. A new project is created, and a multi-fiber measurement screen appears.

To change the project settings, see "Project setup" on page 8-14.

The contents of the current project can be viewed in project information on page 8-15.

Explanation

Project setup

Saving the project

The project file and measurement result files of each core can be compressed in MPZ format and saved. For information on how to save files in MPZ format, see section 9.4.

The created project information is saved in CSV format in the MPJ folder of the specified destination media.

Note

Decompressing MPZ files

On the AQ7933 OTDR emulation software (sold separately), run Utility > MPZ Converter. Select the source file (MPZ file) and the conversion destination. An MPJ file and SOR files will be extracted.

AQ7933 is a PC software application for analyzing and creating reports of waveform data measured by the instrument.

Loading a project

An MPJ file created using the “multi-fiber project” feature included in the AQ7933 OTDR Emulation Software can be loaded into the instrument.

Note

- On the instrument, you can only create projects whose measurement conditions of all cores are the same. “Multi-Fiber Project” can be used to create projects whose measurement conditions are different for each core.
- To load a past project into the instrument, you need an MPJ file and an SOR file (data saved with the project).

NoJudge display

If an MPJ file of an older version is loaded, the file may contain core information whose event analysis has not been executed even when pass/fail judgment is set to ON. If this occurs, you can turn off the display of pass/fail judgment setting once and then turn it back on so that pass/fail judgment is executed again on the measured data and pass or fail is indicated.

Number of cores or tapes

Set the number of cores or tapes in the following range.

Tape number	Number of cores or tapes			
OFF	Cores 4 to 96 (4 cores)	Cores 8 to 96 (8 cores)	Cores 10 to 100 (10 cores)	Cores 12 to 96 (12 cores)
a-b(2)	Tapes 1 to 50	Tapes 1 to 50	Tapes 1 to 50	Tapes 1 to 50
a-c(3)	Tapes 1 to 33	Tapes 1 to 33	Tapes 1 to 33	Tapes 1 to 33
a-d(4)	Tapes 1 to 25	Tapes 1 to 25	Tapes 1 to 25	Tapes 1 to 25
a-e(5)	Tapes 1 to 20	Tapes 1 to 20	Tapes 1 to 20	Tapes 1 to 20
a-f(6)	Tapes 1 to 16	Tapes 1 to 16	Tapes 1 to 16	Tapes 1 to 16
a-g(7)	Tapes 1 to 14	Tapes 1 to 14	Tapes 1 to 14	Tapes 1 to 14
a-h(8)	Tapes 1 to 12	Tapes 1 to 12	Tapes 1 to 12	Tapes 1 to 12

You can set the number of cores in steps of 8 when the number of cores in each division is set to “8 cores” and in steps of 10 when the number of cores in each division is set to “10 cores.”

Example: When the number of cores in each division is set to “8 cores,” even if you set the number of cores to 12, it will be set to 16.

Number of cores in each division

When Tape No is set to OFF, you can set the number of columns shown on the main view screen. If you will set the number of cores to 97 or higher, first set Num of Units to 10 cores.

4 cores

Dest.	Folder	Int. Memory/MPJ/NewProject							
1	2	3	4	45	46	47	48		
5	6	7	8	49	50	51	52		
9	10	11	12	53	54	55	56		
13	14	15	16	57	58	59	60		
17	18	19	20	61	62	63	64		
21	22	23	24	65	66	67	68		
25	26	27	28	69	70	71	72		
29	30	31	32	73	74	75	76		
33	34	35	36	77	78	79	80		
37	38	39	40	81	82	83	84		
41	42	43	44	85	86	87	88		

File Name: 1310nm0001.SOR / Label:

4 columns 4 columns

8 cores

Dest.	Folder	Int. Memory/MPJ/NewProject							
1	2	3	4	5	6	7	8		
9	10	11	12	13	14	15	16		
17	18	19	20	21	22	23	24		
25	26	27	28	29	30	31	32		
33	34	35	36	37	38	39	40		
41	42	43	44	45	46	47	48		
49	50	51	52	53	54	55	56		
57	58	59	60	61	62	63	64		
65	66	67	68	69	70	71	72		
73	74	75	76	77	78	79	80		
81	82	83	84	85	86	87	88		

File Name: 1310nm0001.SOR / Label:

8 columns

10 cores

Dest.	Folder	Int. Memory/MPJ/NewProject							
1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80

File Name: 1310nm0001.SOR / Label:

10 columns

12

Dest.	Folder	Int. Memory/MPJ/NewProject									
1	2	3	4	5	6	7	8	9	10	11	12
13	14	15	16	17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32	33	34	35	36
37	38	39	40	41	42	43	44	45	46	47	48
49	50	51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70	71	72

File Name: 1310nm0001.SOR / Label:

12 columns

In the project settings, setting “Linkage OSW control” to ON causes optical switch port numbers to appear. When you select the numbers of the cores to be measured and execute a measurement, the optical switch changes automatically. When “Measure all channels” is set to ON, after the averaged measurement of the selected core is completed, the channel is switched to measure the next core, and the averaged measurement continues.

Measurement setup

Same settings as OTDR. For details, see section 3.1.

Wavelength

You can set Wavelength 1, Wavelength 2, and Wavelength 3. Depending on the setting of Wavelength 1, only OFF may be set for Wavelength 2. Wavelength 3 can be set to AQ7293H or AQ7294H.

Model	Wavelength 1	Wavelength 2	Wavelength 3
AQ7292A	1310 nm, 1550 nm	OFF, 1310 nm, 1550 nm	—
AQ7293A	1310 nm, 1550 nm	OFF, 1310 nm, 1550 nm	—
AQ7294A	1310 nm, 1550 nm	OFF, 1310 nm, 1550 nm	—
AQ7293F	1310 nm, 1550 nm, 1650 nm	OFF, 1310 nm, 1550 nm	—
AQ7293H	1310 nm, 1550 nm, 1625 nm	OFF, 1310 nm, 1550 nm, 1625 nm	OFF, 1310 nm, 1550 nm, 1625 nm
AQ7294H	1310 nm, 1550 nm, 1625 nm	OFF, 1310 nm, 1550 nm, 1625 nm	OFF, 1310 nm, 1550 nm, 1625 nm

8.2 Measuring a Multi-Fiber Optical Cable (Multi-Fiber Project)

Distance range

Set the distance range according to the length of the optical fiber cable. Specify a distance range value that is greater than the length of the optical fiber cable that you will measure.

The distance range can be set to any of the following values.

AUTO, 100 m, 200 m, 500 m, 1 km, 2 km, 5 km, 10 km, 20 km, 30 km, 50 km, 100 km, 200 km, 300 km, 400 km, 512 km

Sample interval

The maximum number of sample data points is 256000. The shortest sample interval is determined by the distance range.

Normal: The sampling interval is matched to the measurement update interval and pulse width. For real-time measurement, the sampling interval is such that an update interval of 5 times per second can be ensured.

High resolution: The instrument uses a sample interval that would result in the greatest number of data points. If you use a short sample interval, you can measure for finer changes, but the data size of the measured result becomes large.

Pulse width

The selectable pulse width varies depending on the distance range and type.

Distance range	Pulse width
100 m to 500 m	3 ns, 10 ns, 20 ns, 30 ns
1 km to 5 km	3 ns, 10 ns, 20 ns, 30 ns, 50 ns, 100 ns, 200 ns, 300 ns, 500 ns
10 km to 50 km	50 ns, 100 ns, 200 ns, 300 ns, 500 ns, 1 μ s, 2 μ s, 5 μ s
100 km to 512 km	50 ns, 100 ns, 200 ns, 300 ns, 500 ns, 1 μ s, 2 μ s, 5 μ s, 10 μ s, 20 μ s

Average unit

Set whether to perform averaging using measurement duration or measurement time.

Duration: Averages over the set measurement duration.

Time: Averages over the set measurement count.

Average duration

Set this when the average unit is set to Time.

Select the average duration from the following:

AUTO, 5 s, 10 s, 20 s, 30 s, 1 min, 3 min, 5 min, 10 min

When set to AUTO, measurement continues until the noise floor level reaches a certain level.

Average times

Set this when the average unit is set to Time.

Select the average duration from the following:

AUTO, 2¹⁰ (1024 times), 2¹¹ (2048 times), 2¹² (4096 times), 2¹³ (8192 times), 2¹⁴ (16384 times), 2¹⁵ (32768 times), 2¹⁶ (65536 times), 2¹⁷ (131072 times), 2¹⁸ (262144 times), 2¹⁹ (524288 times), 2²⁰ (1048576 times)

2¹⁰ is 2 to the power of 10 (1024 times).

When set to AUTO, measurement continues until the noise floor level reaches a certain level.

Average method

There are two methods: Hi-Speed and Hi-Reflection.

Hi-Speed: All sections are measured according to the specified attenuation.

Hi-Reflection: Measurements are made with optimum attenuation according to the backscattered light level of each section.

Analysis setup

Same settings as OTDR. For details, see section 3.2.

Connector loss and splice loss

If a splice loss that exceeds the specified threshold occurs, it is detected as an event.

Return loss

If a return loss that is less than or equal to the specified threshold occurs, it is detected as an event.

End of fiber

If a reflection that exceeds the specified threshold occurs, it is detected as the end of the optical fiber cable (Fresnel reflection).

Splitter loss

Events whose loss exceeds this value are assumed to be optical splitters according to the number splits.

Macro bending (bending loss)

When an optical pulse measurement is made with multi-wavelength measurement, the connection loss of each wavelength is compared and detected as an event when the bending loss generated by the bending of the optical fiber cable exceeds a set threshold value.

Launch fiber setting

When you connect a launch fiber cable to avoid near-end dead zones, you can set the launch fiber cable events (start point and end point) or start position so that the event information in the launch fiber section is excluded from the analysis conditions.

Pass fail judgment

A judgment is performed on the events detected in the target waveform, and those that exceed the specified threshold are displayed as fault events on the event screen.

Approximation method

LSA: The instrument calculates the loss between two points by using the least squares method on all the data between the two points. The loss can be calculated with smaller error than TPA when there are no events such as reflections or connection losses within the interval to be calculated.

TPA: The instrument uses the difference between the levels of the two specified points to calculate the loss. The loss can be calculated with smaller error than LSA when there are events such as reflections or connection losses within the interval to be calculated.

Backscatter level

The backscatter level setting is used when the instrument calculates the return loss and total return loss.

If you do not set the correct backscatter level, the return loss and total return loss measurements will be incorrect.

Index of refraction (IOR)

The instrument uses the index of refraction to calculate the distance. If you do not set the index of refraction correctly, the distance measurement will be incorrect.

OTDR setup

Same settings as OTDR. For details, see section 3.3.

Marker mode

Select whether to display markers or lines on the waveform screen.

Reflection display

Select the value to display in the calculation result display area of the waveform display screen.

Return loss: The ratio of the incident optical power level and the reflected optical power level is displayed.

Reflection level: The reflected optical power level is displayed.

Cursor

Set the cursor display to crosshair or line.

Total loss

Select the calculation method for the displayed loss.

Cumulate loss: The integrated value of the splice losses at each event from the measurement reference point (S).

Loss between S and E: The loss (TPA approximation method) between the measurement reference point (S) and the end of fiber (E).

Total return loss

Select whether to include the return loss value at the end of fiber (E) in the total return loss.

Include END: The value at end of fiber (E) is included in the total return loss.

Exclude END: The value at end of fiber (E) is not included in the total return loss.

dB decimal

Set the number of decimal places to display.

**.: 1 decimal place

**.: 2 decimal places

**.: 3 decimal places

Distance decimal

Set the number of decimal places to display.

**.: 3 decimal places

**.: 4 decimal places

**.: 5 decimal places

Saving measurement data

Measurement data for real-time measurement, averaged measurement, OPM, and FIP are stored in the following folder.

Save destination device > MPJ > Project name folder

Real-time measurement and averaged measurement data are in SOR format. OPM data is in CSV format. FIP data is in BMP format.

8.3 Monitoring Optical Fiber Cables (Schedule Measurement, /MNT option)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the schedule measurement screen


1. Press **MENU**. A MENU screen appears.
2. Tap the **Schedule Measurement** icon. A Schedule Measurement screen appears.

MENU screen



8.3 Monitoring Optical Fiber Cables (Schedule Measurement, /MNT option)



Schedule Measurement screen



Performing setup

3. Press **SETUP**.
4. Press the **Schedule Measurement** soft key. The following screen appears.

Select the drive.




5. After completing the schedule measurement, measurement settings, analysis settings, and OTDR settings, close the setup screen and return to the screen shown in step 2.

Note

- When a schedule measurement is being performed, you cannot change the schedule.
- When a schedule measurement is being performed, you cannot perform marker analysis or event analysis. When a schedule measurement is stopped, you can perform marker analysis or event analysis on the measurement waveform data. But, you cannot save the analysis results.
- If you do not set “Linkage OSW control” to ON and select the channel to be linked, you will not be able to set the optical switch channel in the display items of the display content settings.

Setting the display contents

6. Press the **Display** soft key. The waveform display screen (OTDR) appears.


**Note**

The following operations cannot be performed when optical pulse measurement is in progress.

- Moving the cursor
- Switching the display (between waveform and logging)
- Auxiliary function


Setting the auxiliary function

6. Press the **Auxiliary Function** soft key. The waveform display screen (OTDR) appears.




Setting the display items

- 6. Press the **Display Item Setup** soft key. A display item setup message appears.
- 7. Tap **OK**. A display item setup menu appears.



Display item

- 8. Press the **Display Item** soft key. A display item setup screen appears.




For each trace, set the wavelength, monitored items, and optical switch channel (when Linkage OSW control is on).

Note

- If markers are not set, after the first measurement, marker 1 is set automatically to the near end of the waveform data and marker 2 to the far end.
- When a schedule measurement is being performed, you cannot set the display items.
- When a schedule measurement is being performed, you cannot perform marker or event analysis even if you switch to waveform display.

Point monitoring

8. Press the **Point Monitoring** soft key. A point monitoring setup screen appears.



Starting a schedule measurement

9. Press the **Start Schedule Measurement** soft key. Measurement will start according to the start time setting.

To stop an ongoing schedule measurement, press the **Stop Schedule Measurement** soft key.

Explanation

Schedule setup

Interval (min)

Set the interval to measure optical pulses.

The range is 1 to 60 minutes (in 1 minute steps).

Duration (days)

Set the duration to measure optical pulses.

The range is 1 to 120 days (in 1 day steps).

Setting Possible

The number of days is automatically calculated from the measurement interval and the size of the memory in which measured data will be saved. The result is displayed here. Select the drive according to the required duration. Note that even if a number greater than 120 is displayed, the maximum duration (days) that you can set is 120.

Selecting the drive

Select the drive where you want to save the measurement data.

Int. Memory: The internal memory of this instrument.

SD Memory: microSD memory card.

USB Memory 1: The first USB memory device detected.

USB Memory 2: The second USB memory device detected.

Start time

Measurement starts from the specified time.

OFF: Measurement starts immediately.

ON: Measurement starts at the specified date and time.

Selecting measurement target channels

Select the channels for schedule measurement. When “Linkage OSW control” is set to ON, the optical switch for the target channel in schedule measurement switches automatically in sync with the measurements.

Setting the display contents

Select Logging or Trace.

logging

The measured optical pulse power values are logged on the time axis. You can view the places where the optical power is changing. Also, you can view the date and time and the power value at the cursor position.

Trace

You can display the waveform data at the cursor position. While waveform data is being displayed, the menu changes.

Switching the cursor target trace

Switches the logging data to display on the screen. Trace for which the monitoring item is set to OFF in “Setting the display items” described later will not be displayed.

Setting the display items


Monitor items

- **Monitoring measured values between markers (splice loss, return loss, loss(1-2), dB/km(1-2), loss(2-3), dB/km(2-3))**

To display monitor items, you need to set markers. Averaged measurement and real-time measurement can be performed while the schedule measurement screen is displayed. Connect the optical fiber cable to be monitored and execute an optical pulse measurement. Then set the markers necessary for item display (events). For details on how to set markers, see section 6.1. For details on the items, see “Splice Loss” in section 1.4.

- **Monitoring measured values at fixed points (Point A, Point B, Point C, Point D)**


Monitors the variation in the measured values at the specified points. You can set up to four points.



Saving measurement data

Save destination and file name

Schedule measurement data excluding schedule data (CSV format) is saved to the following path.



The above example shows the destination of a file saved on October 20, 2024 at 9:00 a.m.

The file name is wavelength_minute.SOR.

The name of the file for 1310 nm and 9:20 is

1310_20.SOR

Schedule data (logging graph data)

When a schedule measurement finishes, logging graph data in CSV format is automatically saved in root folder/SCHEDULE. The time when a scheduled measurement begins is used for the file name.

Example: 202410200901.CSV if it begins on October 20, 2024 at 9:01 a.m.

• Schedule data format

Company	Yokogawa Test and Measurement Corporation				
Model	AQ7292A				
Function	Schedule Measurement				
Start Date	2024/12/4 13:13		Measurement start date and time		
Start TimeT	1733317980				
Data	Ver1.02				
Wavelength1	1550		Set the measured wavelength.		
Wavelength2	1310				
Wavelength3					
Wavelength4					
Trace1(Wavelength)	1310		Set the display items.		
Trace1(Item)	3				
Trace1(CH)	1		Monitor items (Item)		
Trace2(Wavelength)	1310				
Trace2(Item)	4		1: splice loss 7: point ① -1 : Not use 6 : CH7		
Trace2(CH)	2				
Trace3(Wavelength)	1550		2: total return loss 8: point ② 0 : CH1 7 : CH8		
Trace3(Item)	7				
Trace3(CH)	4		3: loss (① - ②) 9: point ③ 1 : CH2 8 : CH9		
Trace4(Wavelength)	1550				
Trace4(Item)	8		4: dB/km(① - ②) 10: point ④ 2 : CH3 9 : CH10		
Trace4(CH)	6				
Interval(min)	5		5: loss (② - ③) 0: OFF 3 : CH4 10 : CH11		
Duration(days)	1				
MeasureCount	2		6: dB/km (② - ③) 4 : CH5 11 : CH12		
MonitoringPointA	599				
MonitoringPointB	1067		Schedule measurement settings		
MonitoringPointC	1340				
MonitoringPointD	-1		Number of times measurements have been completed		
LinkageOswControl	0				
Trace1	Trace2	Trace3	Trace4	Schedule measurement results (When the unit is dB or dBm, 1000 times the actual measurement value is recorded. Example: 36964→36.964 dB)	
36964	149391	16293	10997		
41772	168823	16324	11166		
	• • • • •				

8.3 Monitoring Optical Fiber Cables (Schedule Measurement, /MNT option)

Loading schedule data

If the CSV file and the SOR waveform data for the schedule period have the same configuration as described in “Save destination and file name,” the graph and waveform can be analyzed again after the CSV file is loaded into this instrument.

8.4 Performing an Auto Loss Test (Auto Loss Test)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the Auto Loss Test Screen


1. Press **MENU**. A MENU screen appears.
2. Tap the **Auto Loss Test** icon. An auto loss test screen appears.

MENU screen




8.4 Performing an Auto Loss Test (Auto Loss Test)

Schedule Measurement screen




Performing setup

- 3. Press **SETUP**.
- 4. Press the **Auto Loss Test** soft key. The following screen appears.




Selecting the function

5. Press the **Function** soft key. A function selection menu appears.




- **When the function is set to Light Source**

Configure the light source display screen.




- **When the function is set to Power Meter**

Configure the power meter display screen.




- **When the function is set to Loopback**

Configure the loopback display screen.



Operation on the optical power meter side




Optical power meter display screen

- Press the **Function** soft key to select **Power Meter**. You can now operate the optical power meter display screen.

Set the reference value (-80 to 40dBm).

The reference value appears if you tap the DREF soft key or set the unit to dB. See section 7.4.




Executing a zero set

- Remove the optical fiber cables from the instrument and close the OPM port cover, or make sure that the power meter section is not receiving any light, and then tap **ZERO SET**.

Note

Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes. Performing a zero-set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

Operation on the light source side



Light source display screen

- Press the **Function** soft key and select **Light Source**. A light source soft key menu appears, and you will be able to operate the light source display screen.

Output wavelength

When you start a loss test, the instrument generates the specified wavelengths in order. The current wavelength appears here.

Starts a loss test (ON)

Starts a loss test During a loss test, wavelength 1 and wavelength 2 switch alternately. This is the same function as the Loss Test START on the soft key Menu.




Set the wavelength.
(Wavelength 3 is displayed for AQ7293H and AQ7294H.)

Optical power adjustment
Before a loss test, you can adjust the amplitude of the optical output of the light source.


8.4 Performing an Auto Loss Test (Auto Loss Test)

Adjusting the optical power

7. Before starting the loss test, directly connect the OTDR port of the instrument (light source side) to the OPM port with a short optical fiber cable.




8. Tap **LS Power Adjust**. The following screen appears.



Starts optical power adjustment
The measurement light turns on.
When adjustment ends normally, the
instrument returns to the previous screen.

Executing a loss test

9. Connect the OTDR port of the instrument (light source side) to the OPM port of the instrument (optical power meter side) with an optical fiber cable.



- 10.** On the light source side of the instrument, press the **Loss Test START** soft key. The loss test starts, and the soft key display changes to Loss Test STOP. Then, on the power meter side of the instrument, the optical power value of the wavelength is displayed on the screen.

On the light source side of the instrument, press the Loss Test STOP soft key to end the loss test.


Note

When you start a loss test, the optical power values of wavelength 1 and wavelength 2 (if the wavelength is set) are measured once. Then, the soft key display changes to Loss Test STOP, which you can use to end the loss test. You can also end the loss test by tapping OFF on the light source display screen.

Saving data


- 11.** On the optical power meter side of the instrument, press the Save Data soft key. A screen appears for saving the results of optical power measurements for multi-fiber cables. For details, “Saving the Results of Optical Power Measurements for Multi-Fiber Cables” in section 7.4.

Loopback operation (operation of the light source and optical power meter)



Loopback display screen

6. Press the **Function** soft key and select **Loop Back**. You can now operate the loopback display screen. On the loopback display screen, you can operate the light source screen and the optical power meter screen. For a description of the display screen, see “Optical power meter display screen” and “Light source display screen.”



Optical power adjustment
Before a loss test, you can adjust the amplitude of the optical output of the light source.

Executes zero-set

Starts a loss test
The light source generates the specified wavelengths of measurement light in order. The optical power meter measures the optical power of the light that it receives.

Saves data
A screen appears for saving the results of optical power measurements for multi-fiber cables. See section 7.4.

Executing a zero set


7. Remove the optical fiber cables from the instrument and close the OPM port cover, or make sure that the power meter section is not receiving any light, and then tap **ZERO SET**.

Note


Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes. Performing a zero-set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

Adjusting the optical power

8. Before starting the loss test, directly connect the OTDR port of the instrument (light source side) to the OPM port with a short optical fiber cable.




9. Tap **LS Power Adjust**. The following screen appears.

**Starts optical power adjustment**

The measurement light turns on. When adjustment ends normally, the instrument returns to the previous screen.

Executing a loss test

10. Loop back the optical fiber cable connected to the OTDR port of the instrument at the far end of the cable installation, and connect the other end of the optical fiber cable to the OPM port of the instrument.



11. Press the **Loss Test START** soft key. The loss test starts, and the soft key display changes to Loss Test STOP. Then, the optical power value of the wavelength is displayed on the instrument screen.

Press the Loss Test STOP soft key to end the loss test.

Note

When you start a loss test, the optical power values of wavelength 1 and wavelength 2 (if the wavelength is set) are measured once. Then, the soft key display changes to Loss Test STOP, which you can use to end the loss test. You can also end the loss test by tapping OFF on the light source display screen.

Saving data

12. Press the **Save Data** soft key. A screen appears for saving the results of optical power measurements for multi-fiber cables. For details, "Saving the Results of Optical Power Measurements for Multi-Fiber Cables" in section 7.4.

Explanation

This feature is available on models with the /SPM or /HPM option.

Models without the above option do not have the Auto Loss Test feature, so combine these models with a light source and the optical power meter feature to perform the loss test. For details, see sections 7.2 and 7.4.

Zero set

Perform a zero-set whenever necessary, such as after you have turned on the power or when the ambient temperature changes.

Performing zero set adjusts the internal deviation of the optical power measurement section and enables you to obtain more accurate absolute optical power values.

Optical power adjustment

Adjust the optical power of the light source as necessary. When you execute optical power adjustment, the instrument automatically identifies the optical power level and adjusts itself accordingly. Perform optical power adjustment on the light source side.

- Press the Execute soft key to execute the optical power adjustment. When adjustment ends normally, the instrument returns to the previous screen. While adjusting, the word "Execute" on the menu changes to "Abort." All soft keys other than Abort will be invalid.
- When you press the Abort soft key, the optical power adjustment will be aborted. The word "Abort" on the menu returns to "Execute." The adjustment value returns to the previous value before the execution.
- Connect an optical fiber that is no longer than a few meters. Make sure that the fiber is free from dirt, scratches, bends, and other potential causes of optical loss.
- The default adjustment value is set to the factory default value.

Executing an auto loss test

Configure the optical power meter side and the light source side. Connect the optical fiber or optical circuit to be tested to the optical power measurement port on the optical power meter side and the light source port on the light source side. Then execute the loss test. The optical power of the light passing through the optical fiber or optical circuit to be tested is measured on the optical power meter side.

Loss display

Set how to display the measured values.

Difference from the reference value	The value obtained by subtracting the reference value from the measured value is displayed (a negative value is displayed).
Loss	The value obtained by subtracting the reference value from the measured value is displayed as a loss (a positive value is displayed).

8.5 Performing a Multi Fiber Loss Test (Multi Fiber Loss Test)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT

- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the Multi fiber loss test screen

1. Press **MENU**. A MENU screen appears.
2. Tap the **Multi Fiber Loss Test** icon. An auto loss test screen appears.


MENU screen



Multi fiber loss test screen

Master

Project condition status




Switches master and slave

Creating new project conditions

Loads the previous project
Loads the previous project To load other project conditions that were created separately, see section 9.4.

Slave



Switches master and slave

Optical power adjustment

Before a loss test, you can adjust the amplitude of the optical output of the light source.

Loads the previous project

Loads the previous project To load other project conditions that were created separately, see section 9.4.

Receives project conditions from the master

Project conditions created on the master are loaded.

- Project condition status**

Before starting a multi-fiber loss test, set the conditions (e.g., number of cores) of the multi-fiber optical cable to be measured. The project conditions are created on the master side and then sent to the slave side.

On the slave side, the project conditions sent from the master side are received and loaded into the instrument.

Setting: Indicates that the master and slave are being selected or the project information is being created.

Sending: Indicates that the project conditions are being sent from the master side to the slave side.

Receiving: Indicates that the project conditions sent from the master side are being received on the slave side.

Complete: Indicates that the transmission of the project conditions has been completed between the master side and slave side. After completion, a screen appears for executing multi-fiber loss tests.

Creating and loading projects

Creating new project conditions

3. Press the **Master Slave** soft key to select **Master**.
4. Press the **New Project** soft key. A project setup screen appears.

Set the number of cores or tapes (1 to 2000).

Set the starting core number (1 to 9900).

Set the project name.
A character input dialog box will open.

The Project Setup screen contains the following fields and controls:

- Project Name:** A text input field.
- Start No:** A numeric input field with the value 1.
- Num Of Fibers:** A numeric input field with the value 100.
- Wavelength 1:** A dropdown menu showing "SM 1310nm".
- Wavelength 2:** A dropdown menu showing "OFF".
- Wavelength 3:** A dropdown menu showing "OFF".
- Offset:** A numeric input field with the value 0.000dB.
- Complete:** A button at the bottom center.
- Right Sidebar:** Contains three buttons: "Master Slave", "New Project" (highlighted in blue), and "Previous Project".

Set the tape number.

Set wavelength 2.

Set the offset.
(-9.900 to 9.900dB)

Finishes the setting of the project conditions
When the setup screen closes, the project condition status changes to "Sending."

Set wavelength 3.
Set wavelength 1.


This screen displays a numeric keypad (1-30) and a diagram of two devices, labeled "Master" and "Slave", connected by a line. Above the diagram are three status buttons: "Setting", "Sending" (highlighted), and "Complete". To the right of the keypad is a vertical list of numbers from 40 to 100. At the bottom right is a button labeled "Project Transmission START". The status bar at the very bottom reads "Please send Project information to Slave."

Press to share the project with the slave. For instructions on how to share with the slave, see the next page.


The newly created project can be shared with slaves.

Sharing the project conditions

5. Connect the OTDR port of the instrument on the master side and the OPM port of the instrument on the slave side with an optical fiber cable.



6. On the slave side, press the **Receive Project from Master** soft key. The soft key changes to "Stop."
7. On the master side, press the **Project Transmission START** soft key.



Loading a previous project

3. On the multi fiber loss test screen of step 2, press the **Previous Project** soft key. The project is loaded, and a table of core numbers is displayed.

8.5 Performing a Multi Fiber Loss Test (Multi Fiber Loss Test)


Screen after a project is loaded


When a project is set or loaded, a table of core numbers is displayed.

Master

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

Core	No	nm	Data	Mod.	Ref	Offset	Date
1	1	---	---	---	---	---	---/---/---
1	2	---	---	---	---	---	---/---/---
1	3	---	---	---	---	---	---/---/---

Master

Slave

Connect optical fiber to be measured to OPM.
Press [Loss test START].

Save Data

Skip

Loss Test START


Sets the loss test of the selected core to skip


Starts a loss test

Slave

1	2	3	4	5	6	7	8	9	10
11	12	13	14	15	16	17	18	19	20
21	22	23	24	25	26	27	28	29	30
31	32	33	34	35	36	37	38	39	40
41	42	43	44	45	46	47	48	49	50
51	52	53	54	55	56	57	58	59	60
61	62	63	64	65	66	67	68	69	70
71	72	73	74	75	76	77	78	79	80
81	82	83	84	85	86	87	88	89	90
91	92	93	94	95	96	97	98	99	100

Core	No	nm	Data	Mod.	Ref	Offset	Date
1	1	---	---	---	---	---	---/---/---
1	2	---	---	---	---	---	---/---/---
1	3	---	---	---	---	---	---/---/---

Master

Slave

Now waiting for Core no.
to measure from Master.

Save Data

LS Power Adjust


Loss Test START

Optical power adjustment


Before a loss test, you can adjust the amplitude of the optical output of the light source.

Adjusting the optical power (slave)

8. Before starting the multi-fiber loss test, directly connect the OTDR port on the slave side of the instrument to the OPM port with a short optical fiber cable.



9. Press the **LS Power Adjust** soft key. A LS Power Adjust screen appears.




Starts optical power adjustment
The measurement light turns on. When adjustment ends normally, the instrument returns to the previous screen.

When the adjustment is complete, the screen returns to the table of core numbers.

Executing the multi-fiber loss test

10. In addition to the optical fiber connected in step 5, connect the OPM port of the instrument on the master side and the OTDR port of the instrument on the slave side with an optical fiber cable.



11. On the master, tap the core number you want to perform a loss test on.
12. On the master, press the **Loss Test START** soft key to start the test. The core number for which a loss test was started on the slave becomes active.
13. On the slave, press the **Loss Test START** soft key to start the test on the slave side. The light to be measured is output from the OTDR port on the slave.

When the measurement is complete, the result is displayed in the measurement data display area of the master.

14. Repeat steps 11 to 13 to test other core numbers.

Master

8	9	10	Save Data
18	19	20	
28	29	30	
38	39	40	
48	49	50	
58	59	60	
68	69	70	
78	79	80	
88	89	90	Skip
98	99	100	
set	Date		Loss Test START

Tap the core number you want to perform a loss test on.

Starts a loss test

Slave

8	9	10	Save Data
18	19	20	
28	29	30	
38	39	40	LS Power Adjust
48	49	50	
58	59	60	
68	69	70	
78	79	80	
88	89	90	
98	99	100	
Offset	Date		Loss Test START

The core number for which a loss test will be executed becomes active.

Starts a loss test

1	2	3	4	5	6	7	8	9	10	Save Data
11	12	13	14	15	16	17	18	19	20	
21	22	23	24	25	26	27	28	29	30	
31	32	33	34	35	36	37	38	39	40	
41	42	43	44	45	46	47	48	49	50	
51	52	53	54	55	56	57	58	59	60	
61	62	63	64	65	66	67	68	69	70	
71	72	73	74	75	76	77	78	79	80	
81	82	83	84	85	86	87	88	89	90	Skip
91	92	93	94	95	96	97	98	99	100	
Core No	nm	Data	Mod.	Ref	Offset	Date				Loss Test START
10	1									
10	2									
10	3									

The color changes when the loss test of the target core is completed.

When the lost test of the target cores completed, you can start the loss test of the next core.

The measurement results are displayed when the loss test of the target core is completed.

Explanation

This feature is available on models with the /SPM or /HPM option.

The same project conditions must be shared between the master and slave. The project conditions can be shared using the following methods.

Sending the project conditions

Send the project conditions from the master to the slave.

Decide in advance which optical fiber cable to use to transmit the project conditions (signal transmission optical fiber cable) from the master to the slave. Before sending the project conditions, connect one end of the signal transmission optical fiber cable to the OTDR port on the master side and the other end to the OPM port on the slave side.

- On the slave side, prepare to receive the project conditions.
- On the master side, check that the slave is ready to receive the test conditions, and send the conditions.

Note

When a project is sent, loss test results and skip information are not transmitted.

Loading a project file

Load the same project file into the master and the slave. Have the project file stored in the internal memory of the instrument, microSD memory card, or a USB memory device in advance.

Restarting an interrupted loss test

In a multi-fiber optical cable loss test, you may need to interrupt the test before the loss tests have been completed on all cores. If you want to resume the loss test using the same shared project, the test can be resumed while retaining the data of the completed tests. Data is maintained even when you turn the instrument off.

- The loss test must be performed using the same project.
- If you reload the project file, the data of the loss test up to that point will be deleted and cannot be recovered.

Optical power adjustment

Adjust the optical power of the light source as necessary. When you execute optical power adjustment, the instrument automatically identifies the optical power level and adjusts itself accordingly. Perform optical power adjustment on the light source side.

- Press the Execute soft key to execute the optical power adjustment. When adjustment ends normally, the instrument returns to the previous screen. While adjusting, the word "Execute" on the menu changes to "Abort." All soft keys other than Abort will be invalid.
- When you press the Abort soft key, the optical power adjustment will be aborted. The word "Abort" on the menu returns to "Execute." The adjustment value returns to the previous value before the execution.
- Connect an optical fiber cable that is no longer than a few meters. Make sure that the optical fiber cable is free from dirt, scratches, bends, and other potential causes of optical loss.
- The default adjustment value is set to the factory default value.

8.6 Performing Advanced Analysis (Advanced Analysis)



WARNING

- During measurement, light is transmitted from the instrument's light source ports. Do not disconnect the connected optical fiber cables. Visual impairment may occur if the light enters the eye.
- Close the covers of any light source ports that do not have optical fiber cables connected to them. Visual impairment may occur if light that is mistakenly emitted from these ports enters the eye.

French



AVERTISSEMENT


- Lorsque l'instrument génère de la lumière, la lumière est émise à travers les ports de source lumineuse. Ne pas débrancher les câbles de fibre optique connectés. Des lésions oculaires peuvent être causées si le faisceau lumineux pénètre l'œil.
- Couvrir les caches des ports de source lumineuse libres. Sur les modèles dotés de deux ports de source lumineuse ou plus, protéger les yeux contre l'émission accidentelle de lumière depuis le mauvais port.

Procedure

Displaying the Advanced Analysis (Waveform Analysis) screen

1. Press **MENU**. A MENU screen appears.
2. Tap the **Advanced Analysis** icon. A menu appears for selecting the analysis.

MENU screen




Multi trace analysis: Up to four waveforms can be loaded and compared.

2 way trace analysis: The waveform measured from each end can be combined and compared.

Differential trace: You can display a waveform obtained by subtracting the values of one waveform from those of another waveform selected as the current trace.

Multi trace analysis


3. Tap the **MultiTrace** icon. A MultiTrace screen appears.



Displays the waveform information loaded into Trace1 to Trace4 (wavelength (WL), dynamic range (DR), power value (PW))


Loading a waveform

4. Press the **Load** soft key. A menu appears for selecting the waveform load destination trace.
5. Press the soft key of the trace number you want to load the waveform into. A file operation window appears.



8.6 Performing Advanced Analysis (Advanced Analysis)

Waveform display example




Note

- The current waveform display before switching to the multi trace analysis screen is read into the trace that is selected as the current trace.
- Changing the current trace clears the vertical waveform shift.

2-Way Trace Analysis

3. Tap the **2-WayTrace** icon. A 2 way trace analysis screen appears.



List of events

Displayed by tapping the List tab.

For details on events, see the explanation in section 6.2.

Details tab				
No.	Distance (km)	Loss (dB)	Return Loss (dB)	Event Type
No. 1	0.87063km	0.47022km		
	0.163dB	0.178dB		
	60.990dB			
	↗	↘		

Trace A Trace B Merged

Display of separate events

Displayed by tapping the Detail tab.

Displays the next event


Summary tab				
	Distance	Total Loss	Total RL	dB/km
Trace A	1.43325	0.867	12.507	0.605
Trace B	1.43325	0.755	12.104	0.527
Merged		0.000	<0.000	0.000

Cumulative display of events

Displayed by tapping the Summary tab.

Loading analysis waveforms

4. Press the **Load** soft key. A menu appears for selecting the waveform load destination trace.
5. Press the soft key of the trace number you want to load the waveform into. A file operation window appears.




8.6 Performing Advanced Analysis (Advanced Analysis)

Combines the waveforms of each direction


To display the two waveforms obtained by measuring the same section from two directions, one of the waveforms can be reversed and superimposed on the other waveform, which is specified as the current waveform.

TraceA




Displays the waveform viewed from one end

TraceB



Displays the waveform viewed from the other end


2 way trace waveform display (displays the event number of TraceA of the current trace)



Combines the waveform viewed from one end and that viewed from the other end and displays the result

Executes 2 way trace


2 way trace waveform display (Combines and displays the events of TraceA and TraceB)



When Merged is selected, the events of TraceA and TraceB are combined.



Differential trace

3. Tap the **Diff.Trace** icon. A difference trace analysis screen appears.



Loading analysis waveforms


4. Press the **Load** soft key. A menu appears for selecting the waveform load destination trace.
5. Press the soft key of the trace number you want to load the waveform into. A file operation window appears.



8.6 Performing Advanced Analysis (Advanced Analysis)

2-location Marker

This is an example of placing 2-location Marker markers on the differential (Diff.) trace.



Explanation

Multi trace analysis

Loading waveform data

Up to four traces can be loaded. Loaded traces are displayed on a single screen, so you can compare them. The type of file that you can load is SOR.

Loaded waveforms are displayed at the 0 m position on the horizontal axis or so that their distance references match that of the current trace. Each loaded trace can be shifted vertically as you like.

Current trace

You can select the current trace from Trace 1 to Trace 4.

When you expand or reduce the current trace, other traces are adjusted accordingly.

Cursors are displayed on the current trace. Distance and splice loss that are displayed in the marker information are those of the current trace.

2 way trace analysis

Loading waveform data

The type of file that you can load is SOR.

Traces that meet the following conditions can be combined.

- Event lists are available.
- The wavelengths and pulse widths of the two traces are the same.
- The distances from the measurement reference (S) to the end event (E) are the same.


Current trace

The current trace can be set to one of the combined traces.

Cursors are displayed on the current trace.

Waveform display of 2 way trace analysis

The horizontal axes of the combined traces are aligned so that the end point of the Trace1 (in the end A to end B direction) match the 0 m position (distance reference) of the Trace2 (in the end B to end A direction).



Note

When optical fibers with different backscattered light levels are connected, the loss can be negative. When optical fibers with different backscattered light levels are connected, the average loss measured from both directions is the correct loss value. The 2 way trace analysis function automatically calculates the correct loss value.

Differential trace

Loading waveform data

The type of file that you can load is SOR.

A differential trace of traces that meet the following conditions can be displayed.

- Sample interval
- Measurement start position

Current trace

The current trace can be set to one of the traces that are used for taking the difference.

Cursors are displayed on the current trace. Distance and splice loss that are displayed in the marker information are those of the current trace.

Differential trace analysis

The differential trace is the result of subtracting the values of the current trace from those of the other trace.

Loss value monitor

You can place cursors and 2-location Marker markers on the current trace or differential trace and monitor the following values.

- Loss (dB)
- Distance (km)

The differential trace cannot be saved.

9.1 Connecting USB Storage Devices to the USB Ports

CAUTION

Do not remove a USB memory device or turn off the power when the USB memory access indicator is blinking or when data is being saved or loaded from internal memory. Doing so may damage the storage device (USB memory or internal memory) or corrupt its data.

French

ATTENTION

N'enlevez pas un dispositif de mémoire USB et ne coupez pas l'alimentation électrique lorsque l'indicateur d'accès à la mémoire USB clignote ou lorsque les données sont en train d'être enregistrées ou chargées à partir d'une mémoire interne. Vous risqueriez d'endommager le support de stockage (mémoire USB ou mémoire interne) ou les données qu'il contient.

Use a portable USB memory device for the USB storage device. Connect it directly to a Type-A USB port of the instrument.

Hot-plugging is supported: you can connect or disconnect the USB device at any time, regardless of whether the instrument is on or off.

When the power is on, the instrument automatically detects the USB memory device after it is connected.

Note

- Use a portable USB memory device for the USB storage device. Do not connect incompatible USB memory devices.
- Connect USB memory devices directly to the instrument, not through a USB hub.
- You cannot use protected USB memory devices (such as those that contain encrypted content).
- Do not remove and connect a USB memory device at short intervals. Provide at least a 10-second interval between removal and connection.
- Do not connect or remove a USB memory device from the time when the instrument is turned on until key operation becomes available.
- USB memory devices complying with USB 1.0/1.1/2.0 can be used.
- The destination drive is displayed in the order in which the USB memory devices are connected to the instrument, with the USB port recognized first as USB Memory 1 and the second as USB Memory 2.

9.2 Connecting a microSD Memory Card

CAUTION

- Before connecting a microSD memory card, turn off the power.
 - Do not insert the microSD memory card in the wrong direction. Doing so may damage the microSD memory card and the instrument.
-

French

ATTENTION

- Avant de connecter une carte mémoire microSD, mettez l'appareil hors tension.
 - N'insérez pas la carte mémoire microSD dans le mauvais sens. Cela pourrait endommager la carte mémoire microSD et l'instrument.
-

Compatible microSD memory cards

You can use memory cards that conform to the SDC, SDHC, or SDXC standard with the instrument. For details, contact your nearest YOKOGAWA dealer.

Note

When using a microSD memory card with a PC, make sure that the PC is compatible with the memory card. Also, depending on the type of PC, some of the microSD memory cards listed above may not function properly. Check it in advance.

How to insert a microSD memory card


See the Getting Started Guide, IM AQ7290-02EN.

9.3 Using the Instrument as a Mass Storage Device

Procedure


1. Turn on the instrument.
2. Connect the Type-C USB port on the top panel of the instrument to the USB port of the PC with an USB cable.

For a description of the top panel, see “Component Names and Functions” in the Getting Started Guide, IM AQ7290-02EN. If the instrument is connected to the PC for the first time as a mass storage device, a USB driver is automatically installed in the PC.



3. Press **SETUP**. The system setup screen appears.
4. Set **USB Function** to Storage. For the procedure, see section 10.1.
5. On your PC, start Explorer or another browser.

Select the USB drive.



Note

- The ends of the USB cable supplied with the instrument are both Type-C. If the USB port on your PC is of a different type, prepare your own USB cable.
- The BACKUP folder is an instrument system folder. Do not change or delete this folder. If you change or delete it by mistake, restart the instrument. The folder will be created automatically when it restarts.
- Waveform data and report files of measured results are saved in the USER folder. The necessary folders are created automatically for each file operation. You can view the contents of the USER folder through file operations on the instrument.
- Do not save files in the root folder (same folder level as BACKUP and USER). Doing so can reduce the processing capability of the instrument. Files saved in the root folder are automatically deleted the next time the instrument is started.

9.4 Saving and Loading Data

CAUTION

Do not remove a USB memory device or turn off the power when the USB memory access indicator is blinking or when data is being saved or loaded from internal memory. Doing so may damage the storage device (USB memory or internal memory) or corrupt its data.

French

ATTENTION

N'enlevez pas un dispositif de mémoire USB et ne coupez pas l'alimentation électrique lorsque l'indicateur d'accès à la mémoire USB clignote ou lorsque les données sont en train d'être enregistrées ou chargées à partir d'une mémoire interne. Vous risqueriez d'endommager le support de stockage (mémoire USB ou mémoire interne) ou les données qu'il contient.

Procedure

Saving Data (excluding system settings)

1. With the data you want to save displayed, press **FILE**. A file list screen appears.
2. Press the **Save** soft key.
3. Select the data save format. The data format that can be saved depends on the function being performed.
4. Press the **Execute** soft key. A file is created in the selected save format.

File list screen for saving data


Set the file list display method (1 column, 2 columns).

☰ : 1 column display

☷ : 2 column display

Sort the file list.

Displays the contents of the next higher level folder



See section 3.4.

Saving the data of multi wavelength measurement (1310 nm/1550 nm) (SOZ format)

You can save the two waveforms of multi wavelength measurement as a single data file in SOZ format. When the data is saved in SOR format, the current waveform is saved. To save the two wavelengths separately, save each file by switching the current waveform display. The wavelength indication in the file name is automatically set to the wavelength of the current waveform.


Files in SOZ format can only be loaded into this instrument. To perform analysis on a PC using the AQ7933 OTDR emulation software, save each wavelength in SOR format.


Note

- You cannot use this when the power meter logging feature is in use.
- For details on file operation, see section 9.6.

Saving the system setup data (CFG format)


1. Press **MENU**. A MENU screen appears.
 2. Press **FILE**. A file list screen appears.
 3. Press the **Save** soft key.
 4. Press the **Execute** soft key. A file is created in CFG format.
- Set the file list display method (1 column, 2 columns).**

: 1 column display

: 2 column display

Sort the file list.

Displays the contents of the next higher level folder



Note

- System setup data can be saved only from the data management button window of the MENU screen.
- For details on file operation, see section 9.6.

Loading data

1. Press **File**. A file list screen appears.
2. Press the **Load** soft key.
3. Tap the file to load to select it. Files that can be loaded depend on the function being performed.
4. Press the **Execute** soft key. The file is loaded and displayed on the screen.

File list screen for loading data


Set the file list display method (1 column, 2 columns).

≡: 1 column display

≡≡: 2 column display

Sort the file list.

Displays the contents of the next higher level folder



Note

- The data that can be loaded by this instrument depends on the function being performed.
- You cannot use this when the power meter logging feature is in use.

Explanation

Saving data

The following types of files can be saved.

System setup

Extension	Description
CFG	System settings are saved to a file in CFG format.

OTDR features

Extension	Description
SOR	Waveform data measured from an optical pulse (including the measurement conditions) is saved in an SOR file format that conforms to Telcordia SR-4731.
SOZ	Optical pulse waveform data (including the measurement conditions) for two wavelengths measured with the multi wavelength measurement feature is saved.
BMP	Screen image of the waveform data is saved to a BMP file.
JPG	Screen image of the waveform data is saved to a JPEG file.
SOR+BMP	Both SOR and BMP files are saved.
SOR+JPG	Both SOR and JPG files are saved.
CSV (waveform)	Waveform data measured from an optical pulse is saved to a file in CSV format.
CSV (event)	Event data is saved to a file in CSV format.
SOR+PDF	Both files, the SOR file and report file, are saved simultaneously.
SET	Measurement condition information file is saved.

The screen image immediately before entering the file operation screen is saved.

• CSV (waveform) file format

Label			
Date and time	Fri Jan 10 10:04:24 2025		Label and date
Wavelength	SM 1310nm		
Distance range	5km		
Pulse width	30ns		
Attenuation			
Average duration	Auto		
IOR	1.46		
Data size	10000		
Sample interval	50cm		
			Measurement conditions
[km]	[dB]		
0	14.227		
0.00051	32.466		
0.00103	32.464		
0.00154	32.468		
			Measurement
↑	↑		
Distance	Total return loss		

- **CSV (event) file format**

Label] Label and date
Date and time	Fri Jan 10 10:04:24 2025			
Wavelength	SM 1310nm] Measurement conditions
Distance range	5km			
Pulse width	30ns			
Attenuation				
Average duration	Auto			
IOR	1.46			
Data size	10000			
Sample interval	50cm			
Approximation method	LSA] Analysis conditions
Backscatter level	-50.00dB			
Splice loss	0.10dB			
Return loss	70dB			
End of fiber	65dB			
Distance	2.13705km] Measurement
Total loss	22.033dB			
Total return loss	<46.526dB			
Number of events	3			
Event No	Distance (km)	Section distance (km)	Splice loss (dB)] Event information
1	0.51745	0.51745	0.106	
2	1.58315	1.0657	1.237	
END	2.13705	0.5539	68.721	

OTDR Smart Mapper

Extension	Description
BMP	Screen image of the waveform data is saved to a BMP file.
JPG	Screen image of the waveform data is saved to a JPEG file.
SMP	Adapt Trace data measured from an optical pulse (including the measurement conditions) is saved to a file in SMP format.
SMP+PDF	Both files, the SMP file and report file, are saved.

The screen image immediately before entering the file operation screen is saved.

Multi-fiber measurement feature

Extension	Description
MPZ	SOR files, MPJ files, and BMP files are compressed and saved to MPZ files. They can be used as storage files. AQ7933 OTDR emulation software is required to extract the files. On the AQ7933 OTDR emulation software, run Utility > MPZ Converter. For details, see the AQ7933 manuals.
TXT	Multi-fiber measurement conditions, waveform data summary information, and optical power measurements are saved to a tab separated file.
SOR*	Waveform data from measuring Multi fiber (including the measurement conditions) is saved in an SOR file format that conforms to Telcordia SR-4731.
BMP*	A BMP file saved with the fiber inspection probe is saved.
CSV*	Multi-fiber measurement conditions, waveform data summary information, and optical power measurements are saved to a tab separated file.

* This cannot be selected as a data save format. It is saved automatically.
 SOR and BMP files are saved in a folder with the project name as the folder name in the folder automatically generated with the "MPJ" folder name.
 CSV files are saved in the MPJ folder above.

9.4 Saving and Loading Data

Schedule measurement

Extension	Description
—	Waveform data measured according to the specified schedule (including the measurement conditions) is saved in an SOR file format that conforms to Telcordia SR-4731. When Action is set to Save or Load, files are not displayed.
CSV	Schedule information and measured optical power values (including measurement conditions) are saved to a file in CSV format.

For file formats, see section 8.3.

Auto loss testing

Extension	Description
CSV	CSV file that contains measurement data. Measurement data (including measurement conditions such as wavelength and offset) for the specified number of fibers and tape number type is saved.
LTS	A file containing the measurement conditions of the optical power meter and the light output conditions is saved.

• CSV file format of auto loss test

Company Yokogawa Test and Measurement Corporation
Model AQ7293H
Function PowerMeter

Start No 1
Tape No Type off
Number Of Fibers 100
Loss test value Difference from Reference

Data storage
settings

Data Ver1.03									
Core No	nm	Data	Unit	Modulation	Reference(dBm)	Offset(dB)	Date	SKIP	
1	1	1310	-99.99	dBm CW	0	0	2025/1/16 13:51		
1	2	1310	-99.99	dBm CW	0	0	2025/1/16 13:52		
1	3	1310	-99.99	dBm CW	0	0	2025/1/16 13:52		
2	1							SKIP	
2	2							SKIP	
3	3							SKIP	
⋮									

Measurement

Core number Up to three sets of data can be stored for each core.
In this example, a set of data is stored in core number 1.

Example in which core number 2 has been skipped

Power meter, multi-fiber loss test

Extension	Description
CSV	CSV file that contains measurement data. Measurement data (including measurement conditions such as wavelength and offset) for the specified number of fibers and tape number type is saved.

For power meter file formats, see section 7.4.

- **CSV format of multi-fiber loss test**

Company	Yokogawa Test and Measurement Corporation									
Model	AQ7293F									
Function	Multi Fiber LossTest									
Project Name	ProjectA									
Wavelength1	1550	Measurement conditions								
Wavelength2	1310									
Wavelength3	65535									
Offset	0									
Start No	101									
Tape No Type	off									
Number Of Fibers	50									
Loss test value	Difference from Reference									
Data	Ver1.03									
Core	No	nm	Data	Unit	Modulation	Reference(dBm)	Offset(dB)	Date	SKIP	Measurement
101	1	1550	-2.908	dBm	CW	0	0	2025/1/7 17:58		
101	2	1310	-3.09	dBm	CW	0	0	2025/1/7 17:58		
101	3									
102	1	1550	-2.908	dBm	CW	0	0	2025/1/7 17:58		
102	2	1310	-2.979	dBm	CW	0	0	2025/1/7 17:58		

Loading data

The following types of files can be loaded.

OTDR features

Extension	Description
SOR	File in a format that conforms to Telcordia SR-4731 or Bellcore GR-196-CORE (must be a data file with measurement conditions that can be set on the instrument)
SOZ	Optical pulse waveform data (including the measurement conditions) for two wavelengths measured with the instrument's multi wavelength measurement feature. This file can only be loaded into this instrument.
SET	Information file that contains the measurement conditions that have been saved using the instrument

OTDR Smart Mapper

Extension	Description
SMP	Adapt Trace data measured from an optical pulse (including the measurement conditions).

Multi-fiber measurement feature

Extension	Description
MPJ	Project information file for multi-fiber measurement. For details on projects, see section 8.2.

9.4 Saving and Loading Data

Schedule measurement

Extension	Description
*.CSV	Schedule information and measured optical power values (including measurement conditions) are loaded. To load the file, the file and folder configuration of the SOR file measured with the schedule measurement feature must be the same as when the file was saved.

Save destination drive

Select the destination drive from the following.

Extension	Description
Internal Memory	Instrument internal memory
SD Card	microSD memory card (external memory) inserted into the instrument
USB Memory 1	The first USB storage device (external memory) connected to a type A USB port of the instrument
USB Memory 2	The second USB storage device (external memory) connected to a type A USB port of the instrument

File conditions

For details on the file name and comment feature, see section 3.4.

9.5 Creating Report Files

CAUTION

Do not remove a USB memory device or turn off the power when the USB memory access indicator is blinking or when data is being saved or loaded from internal memory. Doing so may damage the storage device (USB memory or internal memory) or corrupt its data.

French

ATTENTION

N'enlevez pas un dispositif de mémoire USB et ne coupez pas l'alimentation électrique lorsque l'indicateur d'accès à la mémoire USB clignote ou lorsque les données sont en train d'être enregistrées ou chargées à partir d'une mémoire interne. Vous risqueriez d'endommager le support de stockage (mémoire USB ou mémoire interne) ou les données qu'il contient.

Procedure

Exporting the waveforms on the screen to report files

1. Press **FILE**. A file list screen appears.
2. Control the screen, and display the file list of the folder that report files will be saved in.
3. Press the **REPORT** soft key.

9.5 Creating Report Files

4. Press the **Execute** soft key.


A message appears about how to create a report file from a saved SOR file. Tap anywhere or leave it for a while and it will disappear.

Set the file list display method (1 column, 2 columns).

- ☰: 1 column display
- ☷: 2 column display

Sort the file list.

Displays the contents of the next higher level folder





When “Fiber surface image” is set to Manual in the report format settings, or when there is no target image data (image data with the same file name as the serial number of the report file to be created) even if it is set to Auto, the fiber surface image selection screen is displayed. Select the fiber surface image to display in the report.

Note

- The waveform shown on the data display screen is exported to a PDF report file. To select a waveform data file in the file list and export a report file, see “Exporting File List Data to Report Files” below.
- Report files can only be saved in SOR format (waveform data).

Exporting file list data to report files

1. Press **FILE**. A file list screen appears.
2. Press the **File** soft key. A check box display icon appears at the top of the screen.
3. Tap the check box display icon. A check box is displayed for each file and folder.
4. Tap **REPORT**. A report file will be created.



REPORT icon

When “Fiber surface image” is set to Manual in the report format settings, or when there is no target image data (image data with the same file name as the serial number of the report file to be created) even if it is set to Auto, the fiber surface image selection screen is displayed. Select the fiber surface image to display in the report.


Note

The REPORT icon will not appear if a file that cannot be exported to a report file or a folder is selected.

Explanation

Example of a report file

A report file is exported in the following format.



Files that can be exported to report files

Report files can be exported in SOR, MPZ, and SMP formats. The report file of the currently displayed waveform can also be exported by selecting PDF as the save format in section 9.4.

9.6 File Operations

CAUTION

Do not remove a USB memory device or turn off the power when the USB memory access indicator is blinking or when data is being saved or loaded from internal memory. Doing so may damage the storage device (USB memory or internal memory) or corrupt its data.

French

ATTENTION

N'enlevez pas un dispositif de mémoire USB et ne coupez pas l'alimentation électrique lorsque l'indicateur d'accès à la mémoire USB clignote ou lorsque les données sont en train d'être enregistrées ou chargées à partir d'une mémoire interne. Vous risqueriez d'endommager le support de stockage (mémoire USB ou mémoire interne) ou les données qu'il contient.

Procedure

Manipulating files and folders

1. Press **FILE**. A file list screen for manipulating files appears.
2. Press the File soft key. A list of files to be manipulated is displayed.

Set the file list display method (1 column, 2 columns).

- ☰ : 1 column display
- ☷ : 2 column display

Sort the file list.

Displays check boxes
(rename, copy, delete files and folders)


Displays the contents of the next higher level folder

File path

Create a folder

A character input screen appears. A new folder is created after you enter the characters.

For information about how to enter text, see section 2.5.



List of files and folders

Renaming, copying, and deleting files and folders

3. Tap the file or folder you want to manipulate. A screen with file operation icons appears.
4. Tap the file operation you want to execute.

Closes the file operation icon display area

File operation icon display area



Loads a file

Appears when a loadable file is selected.



Opens a folder

Appears when you select a folder.

Renames a folder or file


A character input screen appears. For information about how to enter text, see section 2.5.

Copies files and folders

A screen for copying files and folders appears.

Deletes files and folders

You can delete selected files and folders.



Renaming files and folders


5. Tap the **RENAME** icon. A file name input screen appears.
6. Follow the instructions in section 2.5 to enter a new file or folder name.

Deleting files and folders

5. Tap the **DELETE** icon. A confirmation message appears.
6. To delete, tap **OK**. To not delete, tap **Cancel**. Deleting a folder will delete all files and folders in the folder.

Copying files and folders

5. Tap the **COPY** icon. A file list screen of the copy destination folder appears. Change the folder as necessary.




6. Tap the copy execute icon. The file or folder is copied.

Selecting (copying or deleting) multiple files and folders

3. Tap the check box display icon. A screen for selecting files and folders to be manipulated appears.
4. Select the check boxes of the files or folders you want to manipulate.


Check box display button



Check individually

Selects all check marks

Clears all check marks




Loading files

3. Select the file you want to load. A screen with file operation icons shows a load file icon.

Closes the file operation icon display area

File operation icon display area

Loads files
The selected files will be loaded.
Appears when a loadable file is selected.



Selected file
The background color changes when selected.

Note

Files can also be loaded using the procedure explained in section 9.4.

10.1 Displaying the System Setup Screen

Procedure

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.

You can display the system setup screen by pressing the SETUP key on screens other than the MENU screen, such as those of the OTDR feature and power meter feature. Depending on the feature, you may need to tap the System tab after displaying the setup screen with the SETUP key. The settings are applied globally regardless of which screen system setup is executed from.

Set the USB function.

Turns the beep sound on or off


Set the language.

The selectable languages are displayed according to the language suffix code.

Set the start screen.

Set the waveform color.

Set the screen color.



Explanation

Language

Set the language used on the instrument screen. The options are displayed according to the language suffix code of each product. For details on the language suffix codes, see the Getting Started Guide, IM AQ7290-02EN.

Screen color

Select the screen color from the following:

Color 1	Color scheme based on black
Color 2	Color scheme based on white

Beep

The instrument can generate a sound when an averaged measurement is finished or when an operation error message is displayed.

ON	Beep sound is on.
OFF	Beep sound is off.

Trace color

Select the trace color from yellow, cyan, magenta, green, red, blue, black (when the screen color is Color 2), or white (when the screen color is Color 1).

USB function

Set the function of the Type-C USB port.

Storage	You can access the instrument internal memory from an external device, and load and save data.
Communication	You can control the instrument remotely from external devices. For instructions on how to use remote control, see the communication interface user's manual, IM AQ7290-17EN.

Start up window

Set the first screen that appears when you start the instrument.

Top Menu	The MENU screen appears.
Start Menu to Last Function	The screen of the feature that was executed immediately before the power was turned off appears.

UTIL key assignments

You can set how the instrument operates when the UTIL key is pressed.

Function	Description	Reference
Save	Data is saved.	Section 9.4
Report	The current waveform display is exported to PDF.	Section 9.5
Utility menu	Shows or hides the Utility menu when optical pulse measurement is in progress	Section 7.1
Power meter	An optical power meter is displayed on the optical pulse measurement screen, and measurement is executed.	Sections 7.1 and 7.4
Power checker	An optical power checker is displayed on the optical pulse measurement screen, and measurement is executed.	Sections 7.1 and 7.5
Light source	A light source is displayed on the optical pulse measurement screen, and a measurement light is emitted.	Sections 7.1 and 7.2
Visible light source	A visible light source is displayed on the optical pulse measurement screen, and a visible light is emitted.	Sections 7.1 and 7.3
Fiber inspection probe*	A fiber end face image is displayed on the optical pulse measurement screen.	Sections 7.1 and 7.6
Optical switch**	Opens the optical switch control screen	
File name setup	A screen for setting the file name format when saving files is displayed.	Section 3.4


* Available when an optical switch is not connected to the instrument

** Available when an optical switch is connected to the instrument


10.2 Using the Power Save Mode

Procedure

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **Power Save**. A power save screen appears.



Power save mode screen



Set the LCD brightness for USB-AC adapter operation.

Set the sleep mode.

Set the LCD brightness for battery operation.

Explanation

LCD brightness

You can set the LCD brightness.

Bright	The screen is set bright. Use this setting in a bright environment. This setting uses a lot of power. During battery operation, pay attention to the battery level.
Normal	Normal brightness.
Power save	Slightly darker the normal brightness. This setting can be used in a dark environment. The battery lasts longer than the Normal setting.
OFF	The LCD backlight is turned off. The battery lasts longer, even longer than the Power Save setting. When you press any key, the backlight turns on for approximately 10 seconds.

Sleep

If the instrument is left on for a set period of time without any operation, it will automatically go to sleep. This does not apply during averaged measurement or real-time measurement.


After 2 hours in sleep mode, the power will automatically turn off.

OFF	Sleep is disabled.
1 min	If you do not operate the instrument for 1 minute, the power mode is set to sleep.
5 min	If you do not operate the instrument for 5 minute, the power mode is set to sleep.
10 min	If you do not operate the instrument for 10 minute, the power mode is set to sleep.
30 min	If you do not operate the instrument for 30 minute, the power mode is set to sleep.

10.3 Setting the Expiration Date


Procedure

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **Expiration Date Setup**. An Expiration Date Setup screen appears.



Expiration date setup screen

Set the expiration date (year, month, day).



Setting the expiration date

5. Tap **Expiration Date**. An Expiration Date screen appears.
Set the year, month, and day.

Setting the message to display on when the expiration date is reached


6. Tap **Message Setup**. A Message Setup screen appears.
Set the message. For information about how to enter text, see section 2.5.
You can set up to three messages.

Enabling the expiration date settings

7. Tap **Expiration Release Code**. A numeric input screen appears.
8. Enter a 4-digit release number.
9. Tap **Start Expiration Function**. A screen appears for executing the expiration function.
10. Tap **Execute**. The expiration date setting is enabled. Start Expiration Function changes to Release Expiration Function.

Releasing the expiration function

11. Continuing from step 3, tap **Expiration Release Code**. A numeric input screen appears.
12. Enter the release number that you entered to set the expiration date.
13. Tap **Release Expiration Function**. The expiration date setting is disabled.




Clears the expiration date settings

Enter the release number (the same number as when you entered the settings).

Releasing the locked state

When the expiration date is reached, a screen indicating that the instrument is locked is displayed at startup.

1. Tap **Expiration Release Code**. A numeric input screen appears.
2. Enter the release number that you entered to set the expiration date.
3. Tap **Execute**. The locked state is released.



Clears the expiration date settings

Enter the release number (the same number as when you entered the settings).


Note

If you forget the release number, you will not be able to release the expiration date settings. The release number cannot be initialized. Be sure to manage the release number carefully. If you forget the release number, contact your nearest YOKOGAWA dealer.

Extending the expiration date

If you have purchased a product with an expiration date, you can extend the expiration date by loading the expiration date extension file provided by the dealer you purchased the product from. For details on the expiration date extension file, contact your nearest YOKOGAWA dealer.

5. Load the previously obtained expiration date extension file into this instrument or save it to a USB memory device and insert it into this instrument.
6. Tap **Select Expanding File**. A file list appears.
7. Manipulate the files, select the expiration date extension file, and press the **Execute** soft key. The expiration date is extended to the date listed in the expiration date extension file.



Expiration date extension file

Explanation

This function displays a message during instrument startup or locks the instrument when the expiration date expires. You can use it to display a message that urges you to calibrate the instrument or the like when the recommended calibration period elapses.

Expiration date

Set the expiration date by entering the year, month, and day. The year is displayed in Western calendar year. The instrument supports leap years. When the number of remaining days until expiration reaches 7 days (1 week before expiration), a message that you specified in the message settings is displayed on the screen when the instrument starts.

The maximum expiration date is 180 days after the current date and time.

Action

Set the action to be taken when the expiration date has passed.

Lock	When the expiration date expires, you will need to enter a release number during instrument startup. If you do not enter the correct number, the instrument will not start. If the expiration date is reached while you are using the instrument (startup completed condition), the instrument will not be locked.
Alarm	When the expiration date expires, the set message will be displayed during instrument startup. When you close the message screen, the instrument starts normally. While the expiration date setting is enabled, the message is displayed every time the instrument starts.

Messages

You can set up to three messages to be displayed when the expiration date expires. Up to 40 alphanumeric characters can be entered.

When the number of remaining days until expiration reaches 7 days (1 week before expiration), the set message is displayed during instrument startup.

Release number

Set a 4-digit number. This is used to release the expiration date.

Extending the expiration date

An expiration date extension file is used to extend the expiration date. The expiration date extension file is binary (.bin extension). Check with the instrument provider to see if an expiration date extension file can be provided.

Note

If you know the release number, you can set the expiration date without using an expiration date extension file.

10.4 Using the Network (LAN)


Procedure

Connecting to wired LAN

Connect a LAN cable to the Ethernet port on a model with the Ethernet option (/LAN), and connect the instrument to a network.


Network setup screen

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **Network Setup**. A Network Setup screen appears.



Network setup screen

Configure the Ethernet. See the next page.



Set common parameters (user name, password). See the next page.

Configure the WLAN. See section 10.6.

Set the LTE dongle. See section 10.7.

Configuring the Ethernet

5. Tap **Ethernet Setup**. An Ethernet Setup screen appears.

Set the timeout period.
(Infinite (0), 1 to 3600)

The screenshot shows the 'Ethernet Setup' dialog box. It has a title bar with a close button (X). Below the title bar, there is a 'Valid / Invalid' dropdown menu currently set to 'Invalid'. To the right of this is a checkbox labeled 'DHCP' which is currently unchecked. Below the dropdown is a 'Time Out(s)' input field with the value '900'. Below this are two rows of numeric input fields: 'IP Address' (192, 168, 0, 2) and 'Subnet Mask' (255, 255, 255, 0). Below the IP Address row is a 'Gateway' row with values (192, 168, 0, 1). At the bottom right is a 'Set' button. Annotations with lines pointing to specific elements are as follows:

- 'Enable or disable the network feature.' points to the 'Valid / Invalid' dropdown.
- 'Turns DHCP on or off' points to the 'DHCP' checkbox.
- 'Set the TCP/IP parameters.' points to the 'IP Address' and 'Subnet Mask' input fields.
- 'Applies the network settings' points to the 'Set' button.

Setting common parameters (user name, password)

5. Tap **Common Setup**. A Common Setup screen appears.

Set the user name and password.
(For information about how to enter text, see section 2.5.)

The screenshot shows the 'Common Setup' dialog box. It has a title bar with a close button (X). Below the title bar, there are two input fields: 'User Name' with the text 'anonymous' and 'Password' which is currently empty.

Explanation

Connect a network to the Ethernet port on a model with the Ethernet option (/LAN), and connect the instrument to a network. With a network connection, you can control the instrument using communication commands.

For details on DHCP and TCP/IP, contact your network administrator.

Enabling and disabling the network feature

Set the user name, password, timeout value, and TCP/IP parameters, and then select Valid.

Applying the network settings, you can start communicating over the network. You do not have to restart the instrument.

Valid: Communication is possible using the network feature.

Invalid: Communication is not possible using the network feature.

Timeout period

If there is no access to the instrument within the specified period, the network connection between the instrument and the PC is automatically disconnected.

Selectable range: Infinite (0), 1 to 3600 s

If you set the value to 0, "Infinite" is displayed, and the timeout value is set to infinity. If the network connection is disconnected because of external factors, not a normal disconnection from the remote device, the instrument will keep the network connected unless the power is turned off. To prevent this from happening, we recommend that you set the timeout value to a finite period.

DHCP

If there is a DHCP server on the network to which the instrument is connected and you want to use DHCP, set this to ON. Consult your network administrator to verify if DHCP is available.

ON: IP address, netmask, and gateway parameters are assigned automatically.

OFF: IP address, netmask, and gateway parameters must be assigned manually.

TCP/IP

IP address

Set the IP address to assign to the instrument. The IP address is an ID number assigned to each computer connected to the Internet or an intranet network.

Obtain the IP address from your network administrator.

If DHCP is available and you set DHCP above to ON, the IP address is assigned automatically.

Netmask

Set the mask value for determining the subnet network address from the IP address. In a network such as the Internet, networks are divided and managed in small subnets. Subnet mask is a value that defines how many bits of the IP address is used for network identification.

Consult your network administrator for the netmask address.

If DHCP is available and you set DHCP above to ON, the IP address is assigned automatically.

10.4 Using the Network (LAN)

Gateway

Set the IP address of the default gateway used to communicate with other networks. The default gateway has features for controlling the communication between multiple networks so that data exchange is performed smoothly.

Consult your network administrator for the gateway setting.

If DHCP is available and you set DHCP above to ON, the IP address is assigned automatically.

User name and password

Set the user authentication user name and password for accessing the instrument from a PC.

User name

You can use up to 15 characters. The default setting is “anonymous.”

Password

You can use up to 15 characters.

Note

- If a user authentication error occurs, communication will not be possible using the network feature.
 - You do not need to enter a password when the user name is set to “anonymous.”
-

10.5 Using the Web Server

Procedure

Connecting the AQ7290 to a PC

Connect the AQ7290 to your PC through an Ethernet network.

Configuring AQ7290 settings


Enable the AQ7290 network function by following the instructions in section 10.4.

Connecting to the AQ7290 from Your PC

1. Run a Web browser on your PC.
2. In the address box, enter “http://IP address” to connect to the AQ7290.
Use the IP address that you specified on the AQ7290.

A page for selecting the connection mode appears.

Connection mode selection screen



3. Click a connection mode. An authentication dialog box appears.

Sign in to access this site

Authorization required by http://192.168.1.1
Your connection to this site is not secure

Username

Password

4. To connect in Control Mode, enter the user name and password that you specified in the AQ7290 network settings, and click OK.

If you set the user name in the network settings to “anonymous,” enter “anonymous” for the user name. You do not have to enter the password.

To connect in View Mode, enter “guest” for the user name and “yokogawa” for the password, and click OK.

User name and password are case-sensitive.

The AQ7290 screen and control panel appear on the PC screen.

Controlling from a PC


You can control the AQ7290 with a mouse or through the touch panel of your PC.

Control screen

Displays the top menu (connection mode selection)

Displays a file dialog box

Screen refresh interval (shows a setup screen)




Corresponds to the AQ7290 panel keys

Displaying the file dialog box and downloading Files

Click **File List** at the top of the screen. A directory structure of the AQ7290 internal memory, microSD memory card, and USB memory devices connected to the AQ7290 appears.

Click **download** to download the corresponding file to your PC.




Download a file

Setting the refresh interval

You can set the interval for refreshing the content displayed on the PC screen.

Click the refresh interval at the top of the screen. A drop-down list for setting the interval appears.

Click the refresh interval you want to use.



Explanation

You can control an AQ7290 connected to a network from your PC.

Connection mode

There are two connection modes: Control and View.

Control Mode: The AQ7290 screen is displayed on your PC screen. You can control the AQ7290 with a mouse or through the touch panel of your PC. You can also download files from the AQ7290.

View Mode: The AQ7290 screen is displayed on your PC screen, but you cannot control the AQ7290 from your PC. It is possible, however, to download files from the AQ7290.

Controlling the AQ7290

If you connect in Control Mode, you can control the AQ7290 from your PC.

Rotary knob operation

The operation varies depending on where on the rotary knob you click.

Upper right of the rotary knob: Equivalent to turning the rotary knob to the right by a small amount (1 point).

Lower right of the rotary knob: Equivalent to turning the rotary knob to the right by a large amount (10 points).

Upper left of the rotary knob: Equivalent to turning the rotary knob to the left by a small amount (1 point).

Lower left of the rotary knob: Equivalent to turning the rotary knob to the left by a large amount (10 points).

AQ7290 touch panel operation

The AQ7290 touch panel only supports tapping. You can perform the equivalent of tapping by clicking the mouse.

Downloading files


- Only files that are 1400 KB or less in size can be downloaded. The download button does not appear for files that cannot be downloaded.
- The download destination varies depending on your browser.
- Multiple files cannot be downloaded at once.

10.6 Using the WLAN Application

Procedure

Connecting the Wireless LAN Adapter (communication dongle)

1. Connect a wireless LAN adapter to the Type-A USB port of the instrument.




Note

Please use your own communication dongle. For the recommended communication dongles that can be used with this instrument, contact your nearest YOKOGAWA dealer.


Network setup screen

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **Network Setup**. A Network Setup screen appears.



Network setup screen

Configure the Ethernet. See section 10.4.



Set common parameters (user name, password). See the section 10.4.

Set the station mode.
Select this option when using this instrument by connecting to an access point.
See the next page.

Set the LTE dongle. See section 10.7.

Set the access point mode.

Select this option when using this instrument as an access point.
See the next page.

Setting the access point mode


5. Tap **Access Point Mode Setup**. An Access Point Mode Setup screen appears.

Set the authentication password.

A character input screen appears. For information about how to enter text, see section 2.5.

Set the ID name (SSID).

A character input screen appears. For information about how to enter text, see section 2.5.



Setting the station mode

5. Tap **Station Mode Setup**. A Station Mode Setup screen appears.

Set the ID name (SSID).


A character input screen appears. For information about how to enter text, see section 2.5.

Select to use a fixed ID name (SSID).

Select a fixed SSID.


Set the authentication password.

A character input screen appears. For information about how to enter text, see section 2.5.



Selecting an SSID from a list of detected SSIDs

6. Select an SSID from the list of detected IDs. A screen appears for selecting a fixed SSID from the detected SSIDs.




Connecting to an access point

7. Tap **Connecting to an Access Point**. An access point connection screen appears.

An icon indicating that the wireless LAN is in use

If you execute the Stop WLAN function, the wireless LAN operation ends, and the icon disappears.


If you select Back to OTDR, the wireless operation does not end, and the icon remains displayed. In addition, even if you stop accessing from the wireless terminal, the wireless LAN operation does not end, so you can access from the wireless terminal again.



When a connection is established, the IP address assigned to this instrument is displayed.

Starting the wireless LAN application

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **WLAN application**. A WLAN application screen appears.




Transferring the waveform data

Executing a waveform data transfer (access point standby state)

5. Tap **OTDR Data Transporter**. A standby screen appears for the waveform data transfer.

An icon indicating that the wireless LAN is in use

If you execute the Stop WLAN function, the wireless LAN operation ends, and the icon disappears. In addition, even if you stop accessing from the wireless terminal, the wireless LAN operation does not end, so you can access from the wireless terminal again.



Access point information

Cancels waveform data transfer

Operation on the wireless terminal

6. Search for the access point from the wireless terminal, and connect to the access point. Check that the SSID is the same as that of the instrument.
7. Start OTDR Data Transporter on the wireless terminal. For the operating procedure of the application, see the application software's help.

Note

Only a single wireless terminal can access the instrument at any given time. (Multiple wireless terminals cannot access the instrument simultaneously.)


Controlling the OTDR remotely

Executing OTDR remote control (access point standby state)

5. Continuing from step 4 on page 10-22, tap **OTDR Remote Controller**. A standby screen appears for OTDR remote control. An icon indicating that the wireless LAN is in use appears at the top of the screen.

An icon indicating that the wireless LAN is in use

If you execute the Stop WLAN function, the wireless LAN operation ends, and the icon disappears. In addition, even if you stop accessing from the wireless terminal, the wireless LAN operation does not end, so you can access from the wireless terminal again.




10.6 Using the WLAN Application

Operation on the wireless terminal (PC) (Yokogawa OTDR Remote Controller)

To use this function, our application software OTDR Remote Controller must be installed on the wireless terminal.

6. On the wireless terminal, search for and connect to the same access point as the SSID of this instrument.
7. Start Yokogawa OTDR Remote Controller on the wireless terminal.
For information on how to operate the OTDR remote controller, see the OTDR remote controller help.
8. From the **File** menu, select **Connect**.
This is an example on a PC.

Remote Controller's Connect screen



Note


Only a single wireless terminal can access the instrument at any given time. (Multiple wireless terminals cannot access the instrument simultaneously.)

Operation on the wireless terminal (PC) (Web browser)

6. On the wireless terminal, search for and connect to the same access point as the SSID of this instrument.
7. Run a Web browser on your wireless terminal.
8. In the address box, enter "http://IP address" to connect to the instrument. The IP address is that of the access point shown on the instrument.

A page for selecting the connection mode appears.

Connection mode selection screen



9. Click a connection mode. An authentication dialog box appears.

10. To connect in Control Mode, enter the user name and password that you specified in “Setting common parameters (user name, password)” in section 10.4, and click OK.


The AQ7290 screen and control panel appear on the wireless terminal screen. You can control the AQ7290 with a mouse or through the touch panel.

Control screen

Displays the top menu (connection mode selection)

Displays a file dialog box

Screen refresh interval (shows a setup screen)




Note

- If you set the user name in the network settings to “anonymous,” enter “anonymous” for the user name. You do not have to enter the password.
- To connect in View Mode, enter “guest” for the user name and “yokogawa” for the password.
- User name and password are case-sensitive.

Setting the screen refresh interval


You can set the interval for refreshing the content displayed on the wireless terminal screen. Click the refresh interval at the top of the screen. A drop-down list for setting the interval appears. Click the refresh interval you want to use.



Displaying the file dialog box

Click **File List** at the top of the screen. A folder structure of the instrument internal memory and USB memory devices connected to the instrument appears.

Click download to download the corresponding file to the wireless terminal.



Explanation

Access point

SSID (ID name)

This is the name of the access point that is displayed when access points are searched for from a wireless terminal such as a PC.

Password

This is the authentication password for connecting to the access point from the wireless terminal.

Encryption mode

This is the encryption key used in the communication with the wireless terminal.

None: An encryption key is not used.

WPA2_PSK: A WPA2-PSK encryption key is used.

Broadcast channel (beacon signal)

Specify the channel on which to receive beacon signals when access points are searched for from a wireless terminal.

AUTO: The channel is selected automatically when sending a broadcast.

1ch to 11ch: When there are wireless communication interference signals in the surrounding area, manually select a channel to avoid the interference.

TCP/IP settings

Set the address for performing a one-to-one communication between the instrument (access point) and the wireless terminal such as a PC. The address format is IPv4.

- **IP address**

Set the IP address to assign to the instrument. The IP address is an ID number assigned to each computer connected to a network.

- **Subnet mask**

Set the mask value for determining the subnet network address from the IP address. Subnet mask is a value that defines how many bits of the IP address is used for network identification.

- **DHCP setting address**

This is the IP address assigned to the wireless terminal that has accessed the access point (instrument).

Addresses are assigned in order from the specified address.

Remote control login information (Application Setup)

User name

You can use up to 15 characters. The default setting is “anonymous.”

Password

You can use up to 15 characters.

Transferring waveform data

You can transfer data saved on the instrument to a wireless terminal. To use this feature, you need to install OTDR Data Transporter (a YOKOGAWA software application) in the wireless terminal. This software application is a freeware. Visit the YOKOGAWA webpage below, and download OTDR Data Transporter.

<https://tmi.yokogawa.com/library/>

Waveform data can also be transferred by remotely controlling the instrument. See “Displaying the file dialog box” on page 10-26.

Remote controlling the OTDR

Operation on the wireless terminal (Yokogawa OTDR Remote Controller)

You can install Yokogawa OTDR Remote Controller in the wireless terminal and remotely control the instrument from the software application.

This software application is a freeware. Visit the YOKOGAWA webpage below, and download Yokogawa OTDR Remote Controller.

<https://myportal.yokogawa.com/>

Operation on the Wireless Terminal (Web Browser)

You can remotely control the instrument from a Web browser of your wireless terminal.

- **Connection mode**

There are two connection modes: Control and View.

Control Mode: The instrument screen is displayed on the wireless terminal screen. You can control the instrument with a mouse or through the touch panel of the wireless terminal. You can also download files from the instrument.

View Mode: The instrument screen is displayed on the wireless terminal screen, but you cannot control the instrument from the wireless terminal. However, you can download files from the instrument.


- **Touch Panel Remote Control**
 - The instrument's touch panel remote control only supports tap operations.
 - You can perform the equivalent of tapping by clicking the mouse.
 - Dragging and pinching are not possible.
- **Downloading files**
 - Only files that are 1400 KB or less in size can be downloaded.
The download button does not appear for files that cannot be downloaded.
 - The download destination varies depending on your browser.
 - Multiple files cannot be downloaded at once.

10.7 Using the LTE Dongle

Procedure

Connecting the mobile communication adapter (LTE dongle)

1. Connect a mobile communication adapter to the Type-A USB port of the instrument.




Note

Please use your own LTE dongle. For the recommended LTE dongles that can be used with this instrument, contact your nearest YOKOGAWA dealer.


Network Setup screen

1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. A SETUP screen appears.
3. Press the **System Setup** soft key. The system setup screen appears.
4. Tap **Network Setup**. A Network Setup screen appears.



Network setup screen

Configure the Ethernet. See section 10.4.



Set common parameters (user name, password). See the section 10.4.

Set the station mode.
Select this option when using this instrument by connecting to an access point.
See section 10.6.

Set the LTE dongle. See the next page.

Set the access point mode.

Select this option when using this instrument as an access point.
See section 10.6.

5. Tap **LTE Dongle Setup**. An LTE Dongle Setup screen appears.

Enter the user name.

Enter the destination user name.

A character input screen appears. For information about how to enter text, see section 2.5.

Set the connection destination name (APN: Access Point Name).

A character input screen appears. For information about how to enter text, see section 2.5.

The screenshot shows the 'LTE Dongle Setup' screen. It has a title bar with 'Sim & Dongle Information' and a close button. The main area contains several fields and buttons:

- APN:** A text input field with 'APN' entered. An annotation points to it with the text 'Set the connection destination name (APN: Access Point Name). A character input screen appears. For information about how to enter text, see section 2.5.'
- Authentication type:** A dropdown menu showing 'PAP'. An annotation points to it with the text 'Set the authentication method.'
- User Name:** A text input field with 'USER' entered. An annotation points to it with the text 'Enter the user name. Enter the destination user name. A character input screen appears. For information about how to enter text, see section 2.5.'
- Password:** A text input field with '*****' entered. An annotation points to it with the text 'Enter the password.'
- Connection Status:** A label above a large text area. An annotation points to it with the text 'Displayed message' and 'Connection status'.
- Global IP address:** A label above a text input field.
- Message:** A label above a text input field.
- Buttons:** 'Cancel' and 'Connection Start' buttons. Annotations point to them with the text 'Cancels the connection' and 'Starts a connection' respectively.

Explanation

You can use an LTE dongle to connect to a PC, smartphone, and other terminals via mobile communication.

If our application software “Yokogawa OTDR Remote Controller” or “OTDR Data Transporter” is installed on the terminal connected to this instrument, you can use these application software to control this instrument.

It can be used for communication over longer distances than WLAN.

APN

Set the name of the connection destination when connecting from a terminal.

Authentication type

Set the authentication type.

PAP: Unencrypted passwords are sent to the network.

CHAP: Challenge handshake method. No password is sent to the network.

PAP&CHAP: Both PAP and CHAP are supported, depending on the connected terminal.

User name

Set a user name of up to 15 characters to access this instrument.

Password

Set a password of up to 15 characters to access this instrument.

11.1 Troubleshooting

Dealing with problems

- If a message appears on the screen, see the following pages for reference.
- If servicing is necessary, or if the instrument does not operate properly even after you have attempted to deal with the problem according to the instructions in this section, contact your nearest YOKOGAWA dealer.

Symptom	Corrective action	See
Nothing appears on the screen even when the power is turned on.	If you are using an USB-AC adapter, make sure that the plug is connected firmly to the outlet, the USB cable is connected firmly to the USB-AC adapter, and the USB-AC adapter's DC plug is connected firmly to the instrument.	— ¹
	Charge the battery, and make sure that the POWER LED is illuminated.	— ¹
	The LCD turns black at high temperatures. At low temperatures, the display slows down. Make sure that the temperature of the area where you are using the instrument is within the operating temperature range.	— ¹
	Holding down the power switch for at least 2 seconds.	— ¹
	The backup file in the instrument may be corrupt due to an improper shutdown execution. Turn the power off, and restart by following the procedure below. 1. While holding down the MENU key, press the power switch. 2. Keep holding down the key until the instrument starts.	— ¹
The display disappears after some time passes.	The instrument turns off automatically when its battery level is low. Check the battery level.	— ¹
	If you have specified a time for the Power Save setting, the instrument will turn off automatically if there is no user activity for the specified time. Check the settings.	10.2
The screen is dark.	The screen will appear dark when the LCD Brightness setting is set to "Power save." Check the settings.	10.2
	The LCD may be worn out. Servicing is required.	—
	If the instrument or its battery becomes hot, the LCD brightness is reduced automatically to prevent damage. Make sure that the temperature of the area where you are using the instrument is within the operating temperature range.	— ¹
The power turns off automatically while the instrument is in use.	The instrument turns off automatically when it detects an error. A warning message will appear when this happens. Read the message. Fix the problem indicated in the message, and then turn the instrument back on. If the Auto Power OFF feature is enabled in Power Save mode, the instrument automatically turns off after a certain time elapses.	10.2 11.2 ²
The battery cannot be charged.	The battery may be too cold or too hot. Make sure that the temperature of the area where you are using the instrument is within the operating temperature range. Let the instrument sit for about an hour at room temperature.	— ¹
	The battery may be approaching the end of its service life. Contact your nearest YOKOGAWA dealer.	—
The power turns off automatically while the instrument is starting.	You may have accidentally pressed the power switch twice.	—
Touch panel operations do not work.	Touch operation is not possible with gloves. Touch the screen with bare hands.	2.3

¹ See the Getting Started Guide, IM AQ7290-02EN.

² When it is likely that the usage limitations of the instrument will be exceeded, the instrument will display a warning message and turn off automatically to prevent damage. For the conditions under which such messages appear, see section 11.2.

11.2 Error Message Display

Error messages

Messages may appear on the screen during operation. This section describes the error messages and how to respond to them. Messages are displayed according to the language setting (see section 2.4). If the corrective action states that servicing is required, contact your nearest YOKOGAWA dealer.

Error in execution

Code	Message
18	Test succeeded.
19	Success
27	The end point is different between acquired data and reference data. Please check the connected fiber cable.
28	The measurement may not be completed within the specified duration.
35	The optical plug may not be connected securely.
38	Shutting down
39	This file cannot be supported by the firmware with this product. This firmware do not support some of new functions. Please update into the latest firmware.
45	The warm-up was ended.
46	A lot of files are saved in the root folder. The file manipulation slows when saved any further. Please make a folder in the root folder, and save files in that.
48	Self test executing. Please wait...
49	MENU : Close the Touch Screen window ENTER : Clear the display
51	Need the AC power supply to measure for a long time. Please connect the AC adapter.
52	Expiration function start success.
53	Expiration function release success.
54	Please select the fiber surface image.
55	Auto save setting is required to use this function. Please turn on auto save setting.
70	The following option was installed. To activate the option, restart the AQ7290.
71	Cannot save the SOR file correctly with the current file name settings. When you select Multi-wavelength measurement, you have to include ""Wavelength"" in the file name. Please check "File Name Setup".
72	license registration is complete.
73	Connecting to the LTE network. It may take up to 60 seconds.
74	LTE network connection was successful.
75	Failed to connect to the LTE network. Please check the SIM card settings. Additionally, there might be an incompatible LTE dongle inserted in the device.
76	Expiration Date updated successfully.
77	Failed to initialize settings of measurement. Please restart the AQ7290.
221	Setting conflict.
223	Data invalid
500	The measurement condition cannot be replicated. Please modify the measurement setup where ***** is shown.
501	Not executable during measurement. Please stop the measurement and execute again.
506	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
507	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
508	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
509	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
510	PLUG CHECK Error. Please check or clean the connector.
512	ZERO SET ERROR
513	ZERO SET ERROR
514	Exceeding limit. It may cause damage of the instrument. Please disconnect the plug.
515	ZERO SET ERROR
516	Fiber In Use Alarm Error 1
517	Fiber In Use Alarm Error 2

Code	Message
521	Operation is stopped outside of operating environmental conditions.
522	Hardware error has occurred.
523	OFFSET_CALIBRATE_ERROR(AMP OFFSET3)
524	Failure to initialize the option module.
525	The Interval is too short. Please change the interval value.
526	Please set Avg Duration.
527	Need the AC power supply to measure. Please connect the AC adapter.
528	Free space is not enough. Please set the interval or the period again.
529	OFFSET_CALIBRATE_ERROR(AMP OFFSET2)
560	When the event fix is ON, the distance reference setup cannot be performed.
563	Conditions of the macro bending do not match.
564	When the launch fiber is enable, the distance reference setup cannot be performed.
565	Judgement failure. The surface of fiber is too dirty.
566	Judgement failure. Too many scratches.
567	Judgement failure. The radius of fiber is too small.
568	Judgement failure. Unfocused.
602	Can not recognize file system. -Internal memory : Contact Yokogawa's representatives. -USB memory : Try the other media or format again with FAT
605	Same file name or folder name exists.
608	Invalid file name or folder name
612	Invalid path name
614	Unknown file or folder
620	Free space is not enough
623	Folder is not empty.
629	Writing to USB memory or SD memory card is not allowed.
636	Failed to delete the folder. The hierarchy below the specified folder is too deep.
641	Failed to copy the folder. The hierarchy below the specified folder is too deep.
642	Failed to copy the folder. The path name is invalid.
645	The path name is too long.
646	USB memory or SD memory card can not be recognized
648	Can not make file or folder in this folder. (Max 550 files/folder)
649	Failed to copy the file or folder. Same path source and destination.
650	<HEADER><BODY> Please confirm the following. -Media is uncorrectly installed. -Other file or folder is saving, reading or deleting. Please wait a moment and try again.
651	Cannot copy the file or folder. The destination file path or folder path is invalid. It can be considered the following causes. -Media is uncorrectly installed. -The file path or folder path is too long. Please change file path or folder path.
652	<HEADER><BODY> Please check media is correctly installed. When using USB memory: <FOOTER>
653	<HEADER> Same file name or folder name exists. Please change the file name or folder name.
654	<HEADER> Invalid file name or folder name. <FOOTER>
655	Cannot execute direct save. Direct save path is not existd. Please select "Save Folder" in the direct save setting menu and change save destination.
656	Cannot execute auto save. Auto save path is not existd. Please change the save path in the auto save setting menu. -Mode is "Date": Please select "Drive" -Mode is "UserDefine": Please select "Save Folder" .

11.2 Error Message Display

Code	Message
657	<HEADER> The media may be uncorrectly installed. <FOOTER>
658	<HEADER> Specified media is not enough free space. Please secure enough free space. When using USB memory: Please try other USB memory.
659	The folder could not be deleted. There are files that cannot be deleted in specified folder.
660	<HEADER> Writing to USB memory is not allowed. Please change other USB memory or remove the write-protection of the USB memory.
661	Cannot copy the file or folder. Same media is selected as source and destination. Please change the destination to a different media from the source.
662	<HEADER> The path name is too long. Please change the file path or folder path.
663	<HEADER> USB memory can not be recognized. Please check the USB memory is correctly installed.
664	Cannot copy the file or folder. <BODY><FOOTER>.
700	Failed to open the file.
701	Failed to close the file.
702	Failed to read the file.
703	Irregular file format.
704	Failed to write the file.
705	Cannot be saved. No trace data.
708	Cannot be saved. This data is not taken with this instrument.
710	File cannot be retrieved. Invalid wavelength
711	File cannot be retrieved. Invalid distance range
712	File cannot be retrieved. Invalid pulse width
713	File cannot be retrieved. Invalid sampling points
714	File cannot be retrieved. Distance range exceeds 400km.
715	File cannot be retrieved. Sampling intervals exceed 64m.
716	File cannot be retrieved. Actual averaging times or duration is not set.
717	Duplicate file name.
718	File is damaged. Check the file.
719	File name too long. Maximum length is 60 letters.
720	File is now being accessed. Execute after access is released.
721	Cannot load this file. Invalid file format or this firmware version is old.
722	Recall Setup File cannot load the measurement condition which sampling interval has been changed to shorter than the standard sampling interval at Meas. Range Change function.
723	This file cannot be supported by the firmware with this product. Please update into the latest firmware to read this file.
724	The model name of the instrument and model name in the file is different. This file cannot be read with this instrument.
725	Can't use the following characters. \ / : ; * ? " < > % . ,
726	This file cannot be read with this instrument. This file that tries to be loaded includes the measurement condition that cannot be measured with this instrument.
727	This file cannot be read with this instrument. This file that tries to be loaded includes the measurement condition that cannot be measured with this instrument. - Distance Range
728	This file cannot be read with this instrument. This file that tries to be loaded includes the measurement condition that cannot be measured with this instrument. - Pulse Width
729	Project file load failed. Create new project file"
730	This project file has individual settings. Conditions cannot be changed using SETUP. Please create new project file to change setting. Select ""Revise project name"" to create new file.
731	Checked SOR file does not exist. Please check the SOR files in the folder.
732	ID No. is not selected in File Name. Please include ID No. in File Name if using direct save(Select ID).
733	Cannot read the file. Please check the media is installed correctly.
734	Cannot read the file. The file may be damaged. Check the file.
735	Cannot read the file. Irregular file format. The file format cannot be supported by AQ7290.
736	<HEADER> Please check media is installed correctly. When using USB memory: Please try other media or check the media is formatted with FAT.

Code	Message
737	<HEADER> Fail to write the file. Please check destination media is installed correctly.
738	Cannot save the PDF file. Invalid fiber surface image file format. Please check the image file format is "" .JPG"" or "" .BMP"".
739	<HEADER><BODY> Please save the file after measurement.
740	Cannot save the SOR file. The file contains invalid values."
741	<HEADER> No event data. Please save the file after event search.
742	<HEADER> There are unset items in the measurement conditions. Please confirm the measurement conditions.
743	Cannot save the SOR file. This data is not taken with this instrument.
744	<HEADER> Duplicate file name. Please change the file name.
745	<HEADER> Can't use the following characters. \ / : ; * ? " < > % . <FOOTER>
746	<HEADER> The current function cannot load the file. <FOOTER>
747	Cannot load the SOR files. <BODY><FOOTER>.
748	Cannot read the file. The measurement result may have been edited after saving on the instrument.
819	ROM Test Error occurred.
820	RAM Test Error occurred.
821	System File Test Error occurred.
822	Battery Test Error occurred.
823	Temperature Test Error occurred.
824	Power Supply Test Error occurred.
825	WLAN Test Error occurred.
854	In USB Storage mode, all keys are locked. Please disconnect the USB Cable.
902	Battery is low. Please power it off, and charge the battery or replace the battery. Or, please use the power supply.
903	Backup battery is low Please contact Yokogawa's representatives.
904	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
906	Battery is low. The instrument will be powered off in 10 sec.
909	The temperature inside the instrument is too high. The instrument may be damaged if used in this condition. The instrument will be powered off in 10 sec. Please turn off power to allow instrument to cool down.
919	Non-standard battery is connected. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please replace the battery.
922	Incorrect date and time setting. Set the correct date and time.
925	Please use AC adapter.
933	Setting conflict.
934	Communication not allowed during measurement
935	USB port over current error.
936	Invalid license key. Option was not installed.
937	The temperature inside the instrument is too high. The instrument may be damaged if used in this condition. The instrument will be powered off in 10 sec. Please turn off power to allow instrument to cool down.
938	The temperature inside the instrument is too low. The instrument may be damaged if it is used in this condition. The instrument will be powered off in 10 sec. Please turn off power until internal temperature is increased.
939	The temperature inside the instrument is too high. The instrument may be damaged if used in this condition. The instrument will be powered off in 10 sec. Please turn off power to allow instrument to cool down.
940	The temperature inside the instrument is too low. The instrument may be damaged if it is used in this condition. The instrument will be powered off in 10 sec. Please turn off power until internal temperature is increased.
941	The voltage of a module is too low. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.
942	The voltage of a module is too high. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.
943	The voltage of a module is too low. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.
944	The voltage of a module is too high. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.
945	The voltage of a module is too low. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.

11.2 Error Message Display

Code	Message
946	The voltage of a module is too high. The instrument may be damaged if it is kept using in this condition. The instrument will be powered off in 10 sec. Please make sure of using the dedicated the power adapter.
947	Battery is low. The light source cannot be turned on.
948	The operation of the battery is not confirmed normally. After stopping the measurement, turn off the power. Please check the connection of battery.
949	Hardware failed, and needs to be repaired. Please contact Yokogawa's representatives.
950	Failed to control WLAN module.
960	OSW is not correctly connected. Please confirm OSW connection.
961	Please use a PD adapter with the specified power or higher.

<HEADER>, <BODY>, <FOOTER>: The message displayed will vary depending on the operation performed and the cause of the error.

11.3 Viewing the Product Information


Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Product Information** icon. A production information screen appears.

MENU screen



Product information screen



Saves screen data

Update the firmware.
(See section 11.6.)

Add options.
(See section 11.8.)

Battery information
(see section 11.4)

Self test
(see section 11.5)

Explanation

Product information

The Product Information screen displays the information (model, serial number, suffix code) inscribed on the name plate affixed to the instrument, and measurement light wavelength.

Version information

The firmware version and update date information are displayed.

Saving a screen image

The screen image of the product information can be saved in internal memory.

Folder name: ProductInfo

File name: SystemInfo.BMP

11.4 Viewing the Battery Information


Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Product Information** icon. A production information screen appears.
3. Press the **Battery Information** soft key. The battery status is displayed.

MENU screen



Battery information screen



Explanation

Battery information

You can view information such as remaining battery level, approximate time remaining, temperature, and date of manufacture.

Saving a screen image

The screen image of the battery information can be saved in internal memory.

Folder: Selected folder

File name: BatteryInfo_year_month_day_hour_minute_second.BMP

11.5 Executing a Self-Test


Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Product Information** icon. A production information screen appears.
3. Press the **Self Test** soft key. A self test screen appears.

MENU screen




Self test screen




Touch Panel Test 1 (coordinate and tap count test)

4. Tap **Touch Panel Test1**. A touch panel test screen appears.
5. Tap anywhere on the screen. The touched position is displayed on the screen as a dot, and the coordinates of the last touched position and the number of touches are displayed in the lower right corner of the screen.




Touch Panel Test 2 (straight line test)

4. Tap **Touch Panel Test2**. A touch panel test screen appears.
5. Drag a straight line on the screen. The dragged track is displayed on the screen, and the coordinates of the last touched position and the number of touches are displayed in the lower right corner of the screen.



Touch Panel Test 3 (tap location test)

4. Tap **Touch Panel Test3**. A touch panel test screen appears.
5. Tap the location designated by the square on the screen. The color of the square changes when it is touched correctly.

**Self test**

4. Tap **Self Test**. A self test starts, and the test results are displayed.

Explanation

Touch panel test 1

Displays the touched position on the screen, the last touched coordinates and the number of touches.

A diagnosis is made on whether the appropriate position is detected by the gap between the touched position and the touch position on the screen, and whether chattering is not caused by the number of touches.

Touch panel test 2

The dragged track is displayed on the screen.

A diagnosis is made on whether the track of the drag operation is properly detected.

Touch panel test 3

A diagnosis is made on whether the specified position is detected correctly.

Self test

The following tests are executed.

- RAM test
- ROM test
- Battery voltage test
- Temperature test (CPU temperature, function board)

If the self-test result is successful, the message "Test succeeded" will appear.

If there is an error, the message "Test Error occurred" will appear.

If an error occurs during a self-test

If an error occurs, contact your nearest YOKOGAWA dealer.

11.6 Updating the Firmware


Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Product Information** icon. A production information screen appears.
3. Press the **Firmware Update** soft key. A file list screen for selecting the firmware file appears.

MENU screen



File List Screen



4. Manipulate the files, select the firmware update file, and press the **Execute** soft key. For instructions on how to use the file list, see chapter 9.

Note

Save the firmware update file in the folder of this instrument beforehand.

Explanation

Firmware update files are YMC files (e.g., AQ7290.YMC).

When updating the firmware, use a USB-AC adapter and connect to AC power.

When a firmware update completes successfully, the instrument will restart automatically.

If it fails, an error message will appear.

Check the firmware version. For the procedure, see section 11.3.


11.7 Initializing the Instrument to Its Factory Default Condition

Procedure


1. Press **MENU**. A MENU screen appears.
2. Press **SETUP**. The system setup screen appears.

You can display the system setup screen by pressing the SETUP key on screens other than the MENU screen, such as those of the OTDR feature and power meter feature. The settings are applied globally regardless of which screen system setup is executed from.

3. Press the **Factory Setting** soft key. A Factory Setting screen appears.



Factory Settings Screen



Initializes settings

The setup data will be initialized.

Initializes the settings and deletes data

The setup data will be initialized. Waveform data, image data, and the like in the Internal Memory folder in the instrument internal memory will also be deleted.

Note

- The USERS_MANUAL folder in the USER folder and the PDF user's manuals in the USERS_MANUAL folder will not be deleted.
- The time setting will not be initialized.

Explanation

Set

The setup data will be initialized. Data in the Internal Memory folder in the instrument internal memory will not be deleted.

All

The setup data will be initialized. All data (except the user's manual) in the Internal Memory folder in the instrument internal memory will not be deleted.

11.8 Adding Options


Procedure

1. Press **MENU**. A MENU screen appears.
2. Tap the **Product Information** icon. A production information screen appears.
3. Press the **Option Installation** soft key. A Option Installation screen appears.

MENU screen



Option installation screen



Enter the license key.
Manually enter the license key. For the input procedure, see section 2.5.

Select the license file from the list.

For details, see the manual included with the additional option license you purchased.

11.9 Checking the Optical Fiber End Face for Stains

By connecting an off-the-shelf fiber inspection probe (with a USB interface) to an instrument USB port, you can display the image of optical fiber cable end face on the instrument display. This image can be used to check for stains on the optical fiber end face and to determine pass/fail.

For details, see section 7.6.

11.10 Mechanical Inspection and Operation Check



WARNING

Before performing a mechanical inspection, be sure to turn off the power. Inspecting the OTDR port or light source port with the instrument turned on may cause the emitted light to accidentally enter the eye. This can cause eye damage or vision impairment.

CAUTION

- Connectors clogged with foreign objects can cause abnormal operation or malfunction.
- Loose connectors may cause the instrument to operate abnormally.

French



AVERTISSEMENT

Veiller à couper le courant avant d'effectuer une inspection mécanique. L'inspection du port OTDR ou du port de source lumineuse avec instrument sous tension peut permettre à la lumière émise de pénétrer accidentellement dans les yeux. Ceci peut provoquer des lésions oculaires ou une déficience visuelle.

ATTENTION

- Si des corps étrangers se retrouvent emprisonnés dans les différents connecteurs, un dysfonctionnement ou un endommagement risque de se produire.
- Si l'ajustement de l'un des différents types de connecteurs n'est pas parfait, l'instrument risque de ne pas fonctionner normalement.

Mechanical Inspection

Make sure that:

- The exterior of the instrument is not damaged or deformed.
- Switches, connectors, and screws are not loose.
- Switches and moving parts work smoothly.

If there are any problems, contact your nearest YOKOGAWA dealer.

Operation Check

Turn the instrument on to start it. Check the following to verify that the instrument is running normally.

- The start screen appears after power-on.
- The screen can be switched using the control keys.
- Touch panel operations work.

11.11 Routine Maintenance

Cleaning the outside of the instrument

To clean the LCD or the outside of the instrument, turn the power off, and remove the USB-AC adapter from the instrument. Use a damp, well-wrung cloth to clean the outside and then wipe it off with a dry cloth. Do not use chemicals such as thinner, benzene, or alcohol. Doing so may cause deformation and discoloring.

Cleaning the optical adapter and optical fiber end faces



WARNING

When cleaning the light emitter, turn off the instrument to prevent the light from accidentally being emitted from the light source port. Cleaning the light emitter with the instrument turned on may cause the emitted light to accidentally enter the eye. This can cause eye damage or vision impairment.

French




AVERTISSEMENT

Lors du nettoyage de l'émetteur de lumière, mettre instrument hors tension pour empêcher l'émission accidentelle de lumière provenant du port de la source lumineuse. Le nettoyage de l'émetteur de lumière avec instrument sous tension peut permettre à la lumière émise de pénétrer accidentellement dans les yeux. Ceci peut provoquer des lésions oculaires ou une déficience visuelle.

-
1. Make sure that the instrument is turned off.
 2. Open the cover of the OTDR port or light source port (option).
 3. Remove the optical adapter.
For instructions, see "Replacing the Optical Adapter" in the Getting Started Guide, IM AQ7290-02EN.
 4. Use a lens cleaner to clean the optical fiber end face.

5. Insert the lens cleaner slowly into the optical adapter's optical connector and turn the lens cleaner to clean the inner walls.

**Note**

- Use a lens cleaner that does not produce fuzz or residue to clean the optical components.
- The OTDR port or light source port can be cleaned with a stick type lens cleaner with the optical adapter attached, but we recommend that you remove the optical adapter to clean it.

11.12 Storage Precautions

Before storage

Clean the instrument before storage. For details on cleaning, see section 11.11.

Storage conditions

Store the instrument under the following conditions.

- In a place where the temperature and humidity are within their allowable ranges.
- In a place where the temperature and humidity do not change greatly over a day
- Out of direct sunlight
- In a place with little dust
- In a place without corrosive gas

Note

To avoid over discharging, if you will not use the instrument for one month or longer, charge the battery, and store the instrument away from direct sunlight in a location that has an ambient temperature of 10 to 30°C.

Reuse

When using the instrument after long-term storage, check its operation (see section 11.10).

Packing

Follow the procedure below to pack the instrument.

1. Wrap the instrument in a thick plastic sheet or the like to prevent dust from entering the inside of the instrument.
2. Apply cushioning material to the LCD to protect it.
3. Prepare a box with a 10 to 15 cm gap on each side of the instrument.
4. Place cushioning material at the bottom of the box.
5. Place cushioning material in the gaps between the instrument and the box.
6. Seal the box securely with adhesive tape or the like.

Transportation

- When transporting the instrument, avoid vibration.
- Transport in an environment that meets the storage conditions.
- This instrument contains a battery pack (lithium-ion cell). For information on transporting the instrument by air, see the requirement for each packing instruction (lithium battery packing instruction Section II) in the latest IATA Dangerous Goods Regulations. For details, contact your airline company in advance.

Appendix Using Open Source Software

Using open source software

This product includes open source software.

For the open source software licenses, see TermsAndConditions_OpenSourceSoftware.pdf in the USER\DATA\USERS_MANUAL folder of this instrument.

For instructions on how to access the USERS_MANUAL folder in the internal memory of this instrument, see “How to View the User’s Manual” in the Getting Started Guide, IM AQ7290-02EN.

Index

Numerics

	Page
2-location Marker.....	1-14, 6-11
2 Markers Method (line).....	6-9
2 Markers Method (marker).....	6-8
2 Point Markers.....	6-15
2 way trace analysis.....	1-29
2-Way Trace Analysis.....	8-63
4 Point Markers.....	6-9, 6-15
5 Point Markers.....	6-11, 6-16
6 Point Markers.....	6-10, 6-16

A

	Page
Access Point Mode Setup.....	10-20
advanced analysis.....	8-60
approximation line.....	3-27
approximation method.....	3-20
attenuation.....	3-6
attenuation dead zone.....	1-11
auto loss testing.....	1-5, 1-26, 8-41
auto save.....	3-8
auto sleep.....	1-35
auxiliary function.....	7-14
average count.....	3-7
averaged measurement.....	1-8
average duration.....	3-7
average method.....	3-7
average unit.....	3-7

B

	Page
backscatter.....	1-10
backscatter level.....	3-21
battery information.....	11-9
beacon signal.....	10-26
beep sound.....	1-36, 10-2
bending loss.....	3-18
bending loss (macro bending).....	1-17
BMP.....	1-32, 9-8
broadcast channel.....	10-26

C

	Page
CFG.....	1-32, 9-8
CHAP.....	10-31
cleaning.....	11-22
COARSE.....	6-16
comment.....	3-41
Comment Setup.....	3-39
communication dongle.....	1-3
connection check.....	1-8, 3-8
CSV (event).....	9-8
CSV (waveform).....	9-8
cumulate loss.....	3-30
Cumulate loss type.....	3-24, 3-32
cursor movement amount.....	6-16

D

	Page
dead zone.....	1-11
Delete Data (optical power meter).....	7-13
Del.Event (Event).....	6-23
DHCP (network).....	10-13
DHCP server (WLAN access point).....	10-27
differential trace.....	1-30, 8-65

Direct Save Setup.....	3-37
distance (between two points).....	1-13
distance range.....	3-5
distance unit.....	3-29
drag.....	2-6
DREF (optical power meter).....	7-11
dynamic range.....	1-11

E

	Page
encryption mode.....	10-26
end of fiber.....	3-17
end of optical fiber.....	1-17
error messages.....	11-2
event analysis.....	1-3, 1-15, 6-20
event analysis conditions.....	1-17
event dead zone.....	1-11
Event Edit/Fix.....	6-21
Event Fix.....	6-26
Event Fix Mode.....	6-32
Event MarkerEdit.....	6-24
event search.....	3-8
event type.....	6-31
expiration date.....	1-37, 10-6
expiration date extension file.....	10-8
Expiration Date Setup.....	10-6

F

	Page
Factory Setting.....	1-35, 11-17
Fail.....	1-18
Fiber Inspec Probe.....	1-5, 1-21
fiber inspection probe.....	7-24
fiber inspection probe (for wireless LAN).....	7-26
fiber-in-use alarm.....	1-8, 3-8
Fiber Surface Pass/Fail Setup.....	7-25
file name.....	3-41
File Name Setup.....	3-36
file reporting.....	1-33
File Report Setup.....	3-38
files, copying.....	9-18
files, deleting.....	9-18
files, loading.....	9-20
files, saving and loading.....	1-32
FINE.....	6-16
firmware updating.....	11-15
flick.....	2-6
Fresnel reflection.....	1-11

G

	Page
Gateway (network).....	10-14
ghost cursor.....	3-28

H

	Page
Hi-Reflection.....	3-7
Hi-Speed.....	3-7
HOLD (optical power meter).....	7-11

I

	Page
icon display.....	1-9
initialization.....	11-18
Ins. Event (Cursor).....	6-21
internal memory.....	1-33

Index

IOR	3-21
IOR/backscatter level	3-16
IP address (network)	10-13
IP address (WLAN access point)	10-26

J

	Page
JPG	1-32, 9-8

L

	Page
label	3-45
Label Setup	3-39
language	10-2
launch fiber	1-12, 1-17, 3-18
Launch Fiber Setting	3-12
LCD brightness	1-35, 10-4
light source	1-20, 7-4
line	3-26
logging	1-20, 7-13
logging measurement	7-18
loopback	1-27
loss	1-10
loss between S and E	3-30
loss test	7-17
LS	7-4
LSA	3-20
LTE Dongle Setup	10-31
LTS	9-10

M

	Page
macro bending	3-11, 3-18
MAP mode	1-2
MAP mode (display)	1-9
marker	6-7
marker analysis	1-13
marker information	3-29
markers	3-26
master and slave	1-27
Message Setup	10-7
microSD memory	1-33
microSD memory card	9-2
modulation mode	7-15
MPZ	9-9
multi fiber	1-23
multi-fiber	1-4
multi-fiber loss test	1-5, 1-27, 8-52
multi-fiber measurement	8-11
multi trace analysis	1-29, 8-61

N

	Page
near-end reflection	1-10
netmask (network)	10-13
network	1-35
Network Setup	10-11, 10-19, 10-30
New Project	8-27
number of fibers	1-24, 7-18, 8-28
number of fibers in each division	1-24

O

	Page
OPC	7-21
operation lock	1-37, 3-33
Operation Lock Setup	3-24
OPM	7-9
optical power adjustment	8-51
optical power adjustment (auto loss test, light source)	8-46
optical power adjustment (auto loss test, loopback)	8-49
optical power adjustment (multi-fiber loss test)	8-57

optical power meter	1-4, 1-20
optical pulse waveform	1-9
optical switch	7-32
option installation	1-37, 11-19
OSW	7-32
OTDR	1-1
OTDR (analysis)	1-13
OTDR Data Transporter	10-22
OTDR (display)	1-9
OTDR (measurement)	1-7
OTDR Remote Controller	10-23
OTDR Smart Mapper	8-2

P

	Page
PAP	10-31
Pass	1-18
pass fail judgment	3-12, 3-14, 3-16, 3-19
pass/fail judgment	1-18
pass/fail judgment (fiber inspection probe)	7-27
PDF	1-32
pinch in	2-6
pinch out	2-6
power checker	1-4, 1-21, 7-21
power meter	7-9
power-save mode	1-35, 10-4
Preset	6-12
product information screen	11-7
project	1-4, 1-23
Project Setup	8-14
pulse width	3-6

R

	Page
real-time measurement	1-8
Reference Level Adjust	6-14
reflection	1-10
reflection display	3-29
release number	10-8
report	1-33, 3-42
report (file list)	9-15
Report Setup	3-37
report (waveform display)	9-13
rerouting work	4-18
return loss	1-14, 1-17, 3-17

S

	Page
sample interval	3-6
save	9-4
Save Data (optical power meter)	7-12
saving directly	3-42
schedule measurement	8-33
screen brightness	10-4
screen color	1-36
section analysis	1-30, 6-13
self test	11-11, 11-14
self-test	11-11
Set End Marker	6-13
Set Start Marker	6-13
sleep	10-5
SM	1-1
Smart Mapper	1-4, 1-22
SMP	1-33, 9-9
SOR	1-32, 9-8
SOZ	1-33, 9-8
splice loss	1-13, 1-17, 3-17
splitter loss	1-17, 3-17
SSID	10-26
stabilized light source	1-3

start screen	1-36, 10-2
station mode	10-20
still image	7-28
storage conditions	11-24
system	1-6
System Setup	10-1

T	Page
tap	2-6
tape number	1-24
tapes, number of	7-18, 8-28
timeout	1-36
timeout (network)	10-13
To be set by Marker	6-14
total loss	3-30
Total return loss	3-31
TPA	3-20
trace color	10-2
TRACE mode	1-2
TRACE mode (analysis)	1-13
TRACE mode (display)	1-9
TXT	9-9

U	Page
USB features	9-3, 10-2
USB feature (TypeC)	1-37
USB memory device	1-33
utilities	1-3
Utility menu	7-1
UTIL key	10-3

V	Page
version information	11-8
version update	1-37, 11-15
visible light source	1-4, 1-20, 7-7
VLS	7-7

W	Page
waveform analysis	1-2
waveform editing	1-23
wavelength	3-5
wavelength (optical power meter)	7-14
wavelength (power checker)	7-23
WLAN application	1-36, 10-22
work completion notice	4-17
Work Completion Notice Setup	3-25

Z	Page
zero set (auto loss test, loopback)	8-49
zero set (auto loss test, optical power meter)	8-44
ZERO SET (optical power meter)	7-10
ZERO SET (power checker)	7-22