
Test&Measurement







Specifications

WT5000 Precision Power Analyzers

Precision Making

Bulletin WT5000-02EN



WT5000 Precision Power Analyzers

gnal Input Section							
ower Measurement							
Element	Plug-in input unit						
Number of elements	7						
Installable input eleme	nts Elements exclusive to the WT5000						
Input element mixing	Allowed						
Empty element	Allowed						
	However, element 1 be used.	to the element before the first empty element can					
		ter the empty element number cannot be used.					
Hot swapping	Not allowed						
otor Evaluation Funct Input connector type	ion (Option) Isolated BNC						
Input type	Unbalanced, function	nal isolation					
Input resistance	Input resistance: 1 M	IΩ ±1%, input capacitance: approx. 47 pF					
Continuous maximum	allowable input						
	±22 V						
Maximum voltage to	earth ±42 Vpeak						
Input channels		/Aux1): Analog/Pulse input					
		/Aux3): Pulse input					
		ıe2/Aux2): Analog/Pulse input d2/Aux4): Pulse input					
		3/Aux5): Analog/Pulse input					
		/Aux7): Pulse input ue4/Aux6): Analog/Pulse input					
		d4/Aux8): Pulse input					
Input type	Analog input	1/2/5/10/20 V					
	Range Setting	Fixed/Auto					
	rialige setting	Auto range					
		Range increase: When the measured value exceeds 110% of					
		the range					
		When the peak value exceeds approximately 150% Range decrease:					
		When the measured value is 30% of the range of					
		less and the peak value is less than 125% of the next lower range					
	Input range	±110%					
	Bandwidth	20 kHz (-3 dB)					
	Sample rate	Approx. 200 kS/s					
	Resolution	16 bit					
	Accuracy* Analog input	For the 6 months accuracy ±(0.03% of reading + 0.03% of range)					
	accuracy	For the 1 year accuracy, multiply the reading of the					
	guarantee conditions	accuracy at 6 months by 1.5					
	Temperature coe						
		±0.03% of range/°C					
	Line filter	Low-pass filter Filter response: Butterworth					
		fc: 100 Hz, 500 Hz, 1 kHz					
	Pulse input Range	10 V					
	Input range	±12 Vpeak					
	Detection level	H level: approx. 2 V or higher					
		L level: approx. 0.8 V or less					
	Pulse width	250 ns or more However, 50% duty ratio for detecting forward					
		rotation					
	Frequency measu						
	Rotation direction	2 Hz to 2 MHz					
		2 Hz to 1 MHz					
		When the pulse noise filter is in use: 10 kHz: 2 Hz to 3 kHz					
		100 kHz: 2 Hz to 30 kHz					
	Aggurgas	1 MHz: 2 Hz to 300 kHz					
	Accuracy	\pm (0.03 + f/10000) % of reading \pm 1 mHz The unit of f is kHz.					
	Accuracy at	However, the waveform display data accuracy is					
	one year	\pm (0.03 + f/500) % of reading \pm 1 mHz The unit of f is kHz.					
	Pulse noise filter	Low-pass filter					
	i dise rioise ilitei						
	Z pulse delay cor	fc: 10 kHz, 100 kHz, 1 MHz					

Peak over-range detection

150% of the range or more

*Analog input accuracy guarantee conditions:
Humidity: 30% RH to 75% RH
Voltage to ground: 0 V
In a wired condition after warm-up time has passed and after zero-level compensation.
For 5°C to 18°C and 28°C to 40°C, add the temperature coefficient.

Measurement Output Section

D/A Output (/DA20 option)
Output connector type Micro ribbon connector (Amphenol 57LE connector), 36-pin

Output source

The set measurement function

Normal measurement

Voltage, current, power: U/I rms, mn, dc, rmn, ac P/S/Q/λ/φ/

Pc and Σ

Peak value : U/I/P, ±pk Frequency: fU/fl/f2U/f2I/fPLLx Integration: ITime/WPx/qx/WS/WQ

Efficiency, user-defined function, user-defined event Harmonic measurement

Voltage, current, power harmonics: U/I/P/S/Q/ λ / and Σ UI, inter-harmonic, inter-element phase difference: ϕxx

Load circuit constant: Z/Rs/Xs/Rp/Xp Relative harmonic content, strain: U/I/P

Telephone harmonic factor: U/I

Telephone influence factor: U/I

K-factor

Delta computation U/I/P and ΣU, P

Motor evaluation function

Speed, Torque, SyncSp, Slip, Pm, EaM1U, EaM1I, EaM3U,

EaM3I, Aux1 to 8

**OV to +5 V when the phase angle display setting is 360° **The % output measurement function is +5 V at 100%. **Rated integrated value is range rating × set integration time *Approx. 7.5 V for setting function errors. However, U/I –pk is approx. –7.5 V. *X consists of characters and numbers.

*x consists of characters	*x consists of characters and numbers.				
D/A resolution	16 bit				
Output type	Voltage output, functional isolation				
Output voltage	Rating: ±5 V, maximum output voltage: approx. ±7.5 V				
Range mode	Fixed: ±5 V FS Manual: Maximum range value: 9.999T, minimum range value: -9.999T				
Number of channels	20				
Accuracy	±(output source measurement accuracy +0.1% of FS), accuracy at 1 year				
Output resistance	Αρρrox. 100 Ω				
Minimum load	100 kΩ				
Temperature coefficient	±0.05% of FS/°C				
Maximum voltage to e	arth ±42 Vpeak or less				
Output update interval	Same as the data update interval Synchronizes to the trigger when the measurement mode is trigger				
Remote control	See Auxiliary I/O				

Display	
Display	10.1-inch color TFT LCD with a capacitive touch screen
Resolution of the	entire screen*
	1280 × 800 dots (H × V)

Japanese/English/Chinese/German

Language Display update interval Same as the data update interval

However,

1) When the data update interval is 50 ms, 100 ms, or 200 ms and only numeric display is in use, the display is updated every 200 ms to 500 ms (depends on the number of displayed parameters). The display update interval is 1 s when the data update interval is 10 ms.

2) When the data update interval is 10 ms, 50 ms, 100 ms, 200 ms, or 500 $\,$ ms and parameters other than those of numeric display are shown, the display is updated every 1 s.

3) When the measurement mode is normal measurement trigger mode,

measurement is executed over the time interval specified by the data update interval from when a trigger is detected. The amount of time shown below is required for the instrument to compute the measured data, process it for displaying, and so on, and become ready for the next trigger.

• When the data update interval is 10 ms to 500 ms: Approx. 1 s.

• When the data update interval is 1 s to 20 s: Data update interval +500 ms

In this case, storage, communication output, and D/A output operate in sync with the triggers.

If the measurement mode display is set to normal measurement mode,

storage, communication output, and D/A output operate in sync with the data update interval.

*The 10 ms data update is available if the firmware version of WT5000 is 3.01 or

LCD adjustment

Turning off the LCD

Manual (default) Off: Panel key operation On: Key operation and panel touch

				·
	Auto-off on	Off: When the panel and keys are not accessed for a given period On: Key operation and panel touch Auto-off time: 1 min to 60 min	Key operation features	Features controlled directly with keys Direct control items: Setup menu display, display format change, range change, storage, data save, integration start/stop/reset, remote clear, key lock, touch loc
	Brightness adjustmer	nt 10 levels	Touch panel	Panel menus can be controlled using the arrow keys and SET key.
	Grid intensity	8 levels	Touch panel	Controls all features Touch lock: Stops the touch panel operation feature
	Color	Waveform, trend, and vector display colors are fixed		
	Background color	Gray	Wiring Systems	Single phase two wire (1 DOW)
Measurement display		digits ess than or equal to 60000: Six digits. greater than 60000: Five digits.	Method	Single-phase two-wire (1P2W) Single-phase three-wire (1P3W) Three-phase three-wire (3P3W, 3V3A) Three-phase four-wire (3P4W)
	Display format	All, 4, 8, 16, Matrix, Hrm List Single, Hrm List		Three phase loar wife (of 477)
		Dual, User	Measuring Mode	
	No-data display symb		Normal measurement	Measurement method Select sync source period average or digital filter average.
	Error display symbol	Error For errors that occur when the frequency Measurement or motor or AUX pulse measurement is less than the lower limit, Error or zero can be selected.	Fixed-period update	Data update interval: 10 m/50 m/100 m/200 m/500 m/1/2/5/10/20 s Display screen: Single, split screen and the measurement display of the trend
Waveform display	Peak-to-peak compre			Numeric, waveform (free run), trend, bar, vector
	Waveform display iter	m		Measurement function: Normal, harmonic
	Voltage, current	elements 1 to 7	Trigger update	Display screen:
	Torque, speed	motor 1 and 2 (/MTR1), motor 3 and 4 (/MTR2)		Single, split screen and the measurement display of the trend Numeric, waveform (triggered), trend, bar, vector
	Auxiliary Input	Aux 1 to 4 (/MTR1), Aux 5 to 8 (/MTR2)		Measurement function: Normal, harmonic
		Single, Dual, Triad, Quad, Hexa		However, the integration feature is not available.
		Auto, Manual (set the zoom and position)	IEC harmonic measurer	ment
		Time/div0.01 ms to 2 s, 1-2-5 steps		Display screen: Displays one screen of measured values Measuring function: Harmonic measurement, frequency
	Trigger Trigger type Edg	ie.	IEC flicker measuremer	
	Trigger mode Sele		iEG nicker measuremer	Display screen: Displays one screen of dedicated measured values
		ect voltage, current, or Ext Clk (external clock).		Measurement function: Flicker function
		ect rising, falling, or rising and falling. Fixed to rising	Features	
		en the trigger source is Ext Clk (external clock)	General Features	
	Trigger level Whe	en the trigger source is a voltage or current applied to	Crest factor setting	Select CF3, CF6, or CF6A.
		nput element let to a value that is within the range defined by the	Element range setting	Can be set for each input element and wiring unit
	e Ti Whe	niddle of the screen ±100% (to the top and bottom dges of the screen). Resolution: 0.1% rigger delay: Within 2 µs an the trigger source is Ext Clk (external clock) TL level	Fixed/auto range sett	ng Fixed range setting Manually set the range of your choice (except only the ranges selected by the valid measurement range selection feature). Range Σ link: ON: Set the range for each wiring unit.
	Time axis zoom featu	ire None		OFF: Set the range for each element.
	Amplitude zoom featu	ure Can be set between 0.1x to 100x		Auto range setting
	Display interpolation	Off, two-point linear interpolation		Auto range setting feature Range increase
	Grid	Selectable (frame, grid, X-Y)		When Urms or Irms exceeds 110% of the measurement range
Trend display	Display items Up	a measurement function's data updates to 8 items when the data update interval is 10 ms. to 16 items, most recent measured values		(220% for crest factor CF6A). When the peak value of the input signal exceeds approximately 310% (approximately 620% for crest factor CF6 or CF6A) of the range.
	Screen division Sing	gle, Dual, Triad, Quad		Range decrease
	Vertical axis Auto	o or Manual (set the upper and lower limits)		When the measured Urms or Irms value is less than or equal to
	Time axis Tim	e/div, 3 s to 1 day		30% of the range, Upk and Ipk are less than equal to 290% of the
Bar graph display	Graph division Sing	of the amplitude and phase of each harmonic gle, Dual, Triad		lower range (range to decrease to) (less than equal to 580% for cre factor CF6 or CF6A), and Urms and Irms are less than 105%. Changes the range directly to the appropriate range when the
		, Linear o or Manual (set the upper and lower limits)		range-decrease conditions are met. A feature for changing to the specified range when a peak over-range
		rting harmonic: 0 to 499, ending harmonic: 10 to 500		occurs
Vactor diaplay	. , , ,			*The null value is not used for peak over-range detection.
Vector display				Valid measurement range selection feature A feature for selecting the valid measurement range according to the usage conditions Only the selected ranges are used.
Custom display	The user registers up	to five screen configurations.	Element scaling	A feature that allows direct reading by setting the current sensor conversion ratio, VT ratio, CT ratio, and power coefficient SF • Auto CT ratio configuration is possible by selecting the CT series mode
	Register Name 14 o	characters		name.
		gisters the current screen configuration as a new		Source measurement function Set voltage U, current I, power (P, S, Q), maximum voltage (U+pk)/
	Over Write Reg	figuration jisters the current screen configuration by rwriting		minimum voltage (U–pk), maximum current (I+pk)/minimum current (I–pk), maximum power (P+pk)/minimum power (P-pk), and VT ratio i the following range.
	Clear Dele	etes registered contents		Selectable range: 0.0001 to 99999.9999
Other measurement so	reen display items		Averaging	Type: Exponential average, moving average
	over-range informatio	time, data update interval, data update count, peak ın, integration settings/status, storage status, crest ment settings/status, option settings/status		Source: Normal measurement function Urms, Umn, Udc, Urmn, Uac, Irms, Imn, Idc, Irmn, Iac, P, S, Q, fU, fl, f2U, f2I,
Deletine to the control of				Δ U1 to Δ PΣ,
Relative to the total number	er of pixels, 0.002% of the LC			ΔU1 to ΔP2, Torque, Speed, Pm, Aux(/MTR1/MTR2 option)
Relative to the total number				

during integration, the storage function saves the measured values that are being updated. Single measurement is periormed at the specified data update rate while a measurement is being held and the hold state is maintained. If you press SINGLE when the measurement is not being held, measurement is performed again from that point. Zero-level compensation (Cai) Measurement elements focus of several settings through a key operation or communication.	Hold	functions bel Averaging type, averag Range, crest factor, ra Scale value Line filter, frequency fil Data update interval, a Zero-level compensati Maximum harmonic or span Waveform observation Measurement hold: Suspends the measur display of each measu. However, measuremen display is held. D/A output, communic	ter sveraging method, sync source on rder, minimum harmonic order, harmonic window time ement and display operations and holds the data
while a measurement is being held and the hold state is maintained. If you press SINOLE when the measurement is not being held, measurement is performed again from that point. Measurement element's circuit diffset correction feature own compensation (Cai) Zero-level compensation (Null) Zero-level Compensation (Nul			storage function saves the measured values that
compensation (Cal) Manual: Executed under the current settings through a key operation or communication. Zero-level compensation (Null) Offset correction feature for all measurement circuits including measurement elements Executed under the current settings through a key operation or communication. Null status: Can be set separately for each function ON: Updates the null value every time a null is executed. HOLD: Holds the null value set once. OFF: Disables null correction. [Upper null limit] Analog input (PwrMotor/Aux): 10% of range rating Pulse input (Motor/Aux): Spect: 10% of [60/PulseN x 10000 Hz] [rpm] Torque: 10% of the absolute value of Rated Upper [Nm] Rated Upper: The larger of "Nm-Hz coordinates x 2 points" for determining the linear scaling value current phase relative to the voltage and current indicates the current phase relative to the voltage of each element. Select the signs to apply to the lead and lag of this phase difference. • Lead (-) /Lag (-) Lead: Positive (-) Leg: Positive (-)	Single measurement	while a measurement is I If you press SINGLE who	being held and the hold state is maintained. on the measurement is not being held,
Offset correction feature for all measurement circuits including measurement elements	compensation	Manual: Executed und or communica Auto: Automatically ex	ler the current settings through a key operation ation. ecute when the measurement range is changed
Null status: Can be set separately for each function ON: Updates the null value every time a null is executed. HOLD: Holds the null value set once. OFF: Disables null correction. [Upper null limit] Analog input (Pwr/Motor/Aux): 10% of range rating Pulse input (Motor/Aux): 10% of range rating Pulse input (Motor/Aux): 10% of the absolute value of Rated Upper [Nm] Rated Upper: The larger of "Nm-Hz coordinates × 2 points" for determining the linear scaling value Aux: 10% of the upper pulse input specification limit 2 MHz [Hz] Phase difference polarity The phase difference φ between the voltage and current indicates the current phase relative to the voltage of each element. Select the signs to apply to the lead and lag of this phase difference. • Lead (-) Lead: Negative (-) Lag: Positive (+) • Lead (+) / Lag (-) Lead: Positive (+) • Lead: Positive (+) • Lead: Positive (+) Lag: Negative (-) The following measurement functions change signs depending on the phase difference polarity. Phase difference expending to the phase difference of harmonic measurement; φ (N, φ U1-U2, φ U1-U3, φ U1-U1, φ	compensation	Offset correction feature measurement elements Executed under the cu	for all measurement circuits including
Torque: 10% of the absolute value of Rated Upper [Nm] Rated Upper: The larger of "Nm-Hz coordinates x 2 points" for determining the linear scaling value		Null status: Can be set s ON: Updates the null HOLD: Holds the null OFF: Disables null con [Upper null limit] Analog input (Pwr/Mot Pulse input (Motor/Au:	value every time a null is executed. value set once. rection. tor/Aux): 10% of range rating k):
Phase difference polarity The phase difference φ between the voltage and current indicates the current phase relative to the voltage of each element.		Torque: 10% of the	absolute value of Rated Upper [Nm] rr: The larger of "Nm-Hz coordinates × 2 points"
Lead (+) /Lag (-) Lead: Positive (+) Lag: Negative (-)		The phase difference φ to current phase relative to Select the signs to apply • Lead (-) /Lag (+) Lead: Negative (-)	between the voltage and current indicates the the voltage of each element.
Phase difference polarity. Phase difference between the fundamental components: φ fnd, Phase difference of harmonic measurement: φ (k), φ U1-U2, φ U1-U3, φ U1-I1, φ U2-I2, φ U3-I3 * Other angles, the phase angle between U(1) and U(R): φ U(k), the phase ang		• Lead (+) /Lag (-) Lead: Positive (+) Lag: Negative (-)	ent functions change signs depending on the
between (1) and I(k): φ I (k), and the electric angles: EaM1U1 to EaM117 and EaM3U1 to EaM317 are not affected by the phase difference polarity setting. Lead is positive (+), and lag is negative (-). Phase correction The phase correction feature of the current of the input element Target element 30 A High Accuracy Element (760901), 5 A High Accuracy Element (760902), Current Sensor Element (760902), Element (760902), Current Sensor Element (760902), El		Phase difference: φ, p components: φ fnd, P φ U1-U2, φ U1-U3, φ	hase difference between the fundamental hase difference of harmonic measurement: ϕ (k), U1-I1, ϕ U2-I2, ϕ U3-I3
Target element 30 A High Accuracy Element (760901), 5 A High Accuracy Element (760902), Current Sensor Element (760903) Setting accuracy 1 ns typical Storage Stores numeric data to internal memory and a USB memory device Data update interval, specified time, or specified interval Synchronization Manual, real time, integration, event Storage count 1 to 9999999 Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.		between I(1) and I(k): φ EaM3U1 to EaM3I7 are	I (k), and the electric angles: EaM1U1 to EaM1I7 and not affected by the phase difference polarity setting.
Setting accuracy 1 ns typical Storage Stores numeric data to internal memory and a USB memory device Data update interval, specified time, or specified interval Synchronization Manual, real time, integration, event Storage count 1 to 9999999 Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.	Phase correction		30 A High Accuracy Element (760901), 5 A High Accuracy Element (760902), Current
Storage Storage Stores numeric data to internal memory and a USB memory device Save Interval Data update interval, specified time, or specified interval Synchronization Manual, real time, integration, event Storage count 1 to 9999999 Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters to the internal memory, a USB memory device, or a network drive Cave setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.			
Save Interval Data update Interval, specified time, or specified interval Synchronization Manual, real time, integration, event Storage count 1 to 9999999 Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.	Ctorna-		
Storage count 1 to 9999999 Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.	otorage		Data update interval, specified time, or
Time interval 10 ms to 99 h 59 m 59 s File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.		Synchronization	
File Format Binary Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.			
Maximum data file size 1 GB Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.			
Saved data conversion Converts to CSV (CSV file size of up to 2 GB can be converted.) Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.			
Data save Save numeric data, waveform data, and screen images to the internal memory, a USB memory device, or a network drive Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.			Converts to CSV (CSV file size of up to 2 GB
Saving and loading setup parameters Save setup parameters to the internal memory, a USB memory device, or a network drive Load saved setup parameters.	Data save		eform data, and screen images to the internal
		Save setup parameters to a network drive	o the internal memory, a USB memory device,
		Load saved setup paran	ieters.

Master and slave	A feature for syl	nchronizin	g the measurement start on slave devices to		
synchronized measurement	the master devi		BNC: Same for master and slaves		
measurement	I/O level	'	TTL: Same for master and slaves		
	Output logic		Negative logic, falling edge: Applies to the master		
	Output hold tim	ie	Low level, 500 ns or more: Applies to the master		
	Input logic	: - 4 -	Negative logic, falling edge: Applies to slaves		
	Minimum pulse		Low level, 500 ns or more: Applies to slaves		
	Measurement s		Applies to the master: Within 1 µs		
			Applies to slaves: Within 2 μs		
	Maximum numb	per of con	nected units 4 unit		
	Data update int	en/al	10 ms to 20 s		
	Measuring Mod		Normal measurement		
User-Defined			computation by combining measurement		
Function	function symbo Number of com	ls			
	Maximum numb	per of ope	rands 16		
	Number of char	acters in	an expression Up to 60 characters		
	Number of unit	character	·		
	Operators		+, -, x, ÷, ABS, SQR, SQRT, LOG, LOG10,		
			EXP, NEG, SIN, COS, TAN, ASIN, ACOS, ATAN		
	Parameters		Element, Σ unit, harmonic order		
MAX hold	Can be defined	using the	user-defined function		
Efficiency equation	Efficiency comp	utation of	up to 4 systems is possible.		
User-defined events	Uses measuren Event	nent funct	ions as trigger conditions Measurement condition		
	Judgment cond	dition	<, <=, =, >, >=, !=		
	Number of ever	nts	8		
Peak over-range detection	Elements, Moto Displays over-ra		MTR2) mation on the screen when the allowable range		
	of each elemen	t and mot	or (/MTR1/MTR2) is exceeded.		
System configuration	Date and time,	message	language, menu language		
Time setting	Sets the time at	t startup u	sing the Simple Network Time Protocol (SNMP)		
Time synchronization function	ation Synchronization source: Supports IEEE1588-2008 (PTP v2) (sla Supports PTP packets of Layer3 (UDP/IPv4) and Layer2 (Eth Supports Ordinary Clock Supports E2E and P2P delay correction				
	Supports E28	and P2F	delay correction		
	Supports E28 Synchronization	and P2F	delay correction ime data		
	Supports E28 Synchronization	and P2F	delay correction		
Initialization feature	Supports E2H Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se	and P2F a target: T a accuracy tings to the e not initia , message ettings (Pref	o delay correction ime data i: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, a language, environmental settings*, Custom ierence): Indication that appears when the frequency		
Initialization feature	Supports E28 Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin	and P2F and P2	o delay correction ime data /: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values illized: date and time, communication settings, a language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv)		
	Supports E2f Synchronization Synchronization Synchronization Seturns the set Settings that an menu language display setting "Environmentals or or motor pulse fir used when savin "Starting the instruction to date and time to	and P2F target: The accuracy tings to the enot initial, message ettings (Prefequency is g to ASCII) ument with their factor	e delay correction ime data 7: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values.		
Help	Supports E2f Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin "Starting the instructed that and time to Displays explan	and P2F target: The accuracy tings to the enot initial, message ettings (Prefequency is g to ASCII) ument with their factor attions of the enot initial end of the en	eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. features		
Help Self-test	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin "Starting the instr date and time to Displays explan Memory, key te	and P2F naccuracy trings to the enot initial, message entings (Prefequency is g to ASCII) urment with their factor ations of the st (keyboast in t	elelay correction ime data r: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. features and)		
Help Self-test Upgrade	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin "Starting the instr date and time to Displays explan Memory, key te	and P2F naccuracy trings to the enot initial, message entings (Prefequency is g to ASCII) urment with their factor ations of the st (keyboast in t	elelay correction ime data r: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. features and)		
Help Self-test Upgrade elta Math Function	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin "Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys	and P2F and P2	elelay correction ime data r: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. features and)		
Help Self-test Upgrade	Supports E28 Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting Ernvironmental se or motor pulse fr used when savin Starting the instr date and time to Displays explan Memory, key te Updates the firr	E and P2F at arget: The accuracy tings to the enot initial, message entings (Prefequency is grown of the ASCII their factor ations of 1 st (keyboarmware and DIFF and DIFF enoting the AUE Differential accuracy and DIFF en	elelay correction ime data r: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values lized: date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. features and)		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting "Environmental se or motor pulse fr used when savin "Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys	E and P2F n target: T n accuracy tings to the e not initia n message ettings (Pref equency is g to ASCII ument with their factor attions of 1 st (keybos mware and	e delay correction ime data /: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values librated ate and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. reatures ard) d prompts the user to input the add-on package al voltage UE between UE+1 determined computation ured line voltage computed in a three-phase		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting *Environment's returning the instr used when savin *Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys difference	E and P2F n target: T n accuracy tings to the e not initial, message ettings (Prefequency is g to ASCII ument with their factor attions of 1 st (keybos mware and ΔUE Unfferenti through of ΔUE Unmeasu three-wir	e delay correction ime data /: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values librate date and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (.csv) the ESC key held down returns all settings except the y default values. ereatures and) d prompts the user to input the add-on package al voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element	Supports E28 Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting Ernvironmental se or motor pulse fr used when savin Starting the instradate and time to Displays explan Memory, key te Updates the firr license keys difference	E and P2F naccuracy tings to the enot initial, message ettings (Prefequency is go to ASCII urment with their factor ations of 1 st (keybos mware and DUE Differential through of Durmens through of Durmens with their factor ations of 1 st (keybos mware and Durmens with through of Durmens with through of Durmens with through of Durmens with three-wirmans dure and Durmens with the Durmens with the dure of Dure of Durmens with the dure of Durmens	eleance of the determined of the user to input the add-on package and voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, AUE+2 oltage computed in a three-wire limited and three-wire with the sound of the user to input the add-on package and voltage user to input the add-on package		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting *Environment's returning the instr used when savin *Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys difference	E and P2F n target: T n accuracy tings to the e not initia n, message settings (Prefequency) g to ASCII ument with their factor attions of 1 st (keyboa mware and AUE Unmeasu through o AUE Unmeasu three-wir AUE, AU Phase vc. (3V3A) s AUE, AU	elelay correction ime data /: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values libratic atte and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (csv) the ESC key held down returns all settings except the y default values. reatures ard) d prompts the user to input the add-on package al voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, ΔUE+2 lttage computed in a three-phase three-wire stem E+1, ΔUE+2		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting 'Environmental se or motor pulse fr used when savin 'Starring the instr date and time to Displays explan Memory, key te Updates the firr license keys difference 3P3W->3V3A DELTA->STAR	E and P2F transcription accuracy transcription accuracy transcription accuracy transcription accuracy transcription accuracy transcription accuracy is greated accuracy is greated accuracy is greated accurations of the street accuracy transcription accu	elelay correction ime data /: ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values libratic atte and time, communication settings, e language, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (csv) the ESC key held down returns all settings except the y default values. reatures ard) d prompts the user to input the add-on package al voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, ΔUE+2 lttage computed in a three-phase three-wire stem E+1, ΔUE+2		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element number.)	Supports E2f Synchronization Synchronization Returns the set Settings that an menu language display setting 'Environmental se or motor pulse fr used when savin 'Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys difference 3P3W->3V3A DELTA->STAR	E and P2F transcription accuracy transcription accuracy transcription accuracy transcription accuracy transcription accuracy transcription accuracy is greated accuracy is greated accuracy is greated accurations of the street accuracy transcription accu	elaly correction ime data it ±10 µs typical (synchronous), ±0.02% (asynchronous) ilized: date and time, communication settings, elanguage, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (csv) the ESC key held down returns all settings except the y default values. features and) diprompts the user to input the add-on package all voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, AUE+2 altage computed in a three-phase three-wire sterm E+1, AUE+2 age calculated in a three-phase four-wire system all current iE between iE+1 determined through		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element number.)	Supports E2f Synchronization Synchronization Synchronization Synchronization Settings that an menu language display setting 'Environmental se or motor pulse fr used when savin 'Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys difference 3P3W->3V3A DELTA->STAR STAR->DELTA difference	E and P2F n target: T n accuracy tings to the e not initial, message stitlings (Prefequency is g to ASCII ument with their factor ations of 1 st (keyboa mware and ΔUE Differenti threue, wir ΔUE Ummeast three-wir ΔUE, ΔU Phase vc (3V3A) sy ΔUE, ΔU Differenti computa	elaly correction ime data it ±10 µs typical (synchronous), ±0.02% (asynchronous) ilized: date and time, communication settings, elanguage, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (csv) the ESC key held down returns all settings except the y default values. features and) diprompts the user to input the add-on package all voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, AUE+2 altage computed in a three-phase three-wire system E+1, AUE+2 age calculated in a three-phase four-wire system all current iE between iE+1 determined through		
Help Self-test Upgrade elta Math Function Voltage (V) (E is the element number.)	Supports E2f Synchronization Synchronization Synchronization Returns the set Settings that an menu language display setting Ernvironmental se or motor pulse fr used when savin Starting the instr date and time to Displays explan Memory, key te Updates the firr license keys difference 3P3W->3V3A DELTA->STAR STAR->DELTA difference	E and P2F h target: T h accuracy tings to the e not initia, message ettings (Prefequency is g to ASCII ument with their factor ations of t st (keybos mware and AUE Differenti through o AUE Unmeasi three-wir AUE, AU Line volts AI Unmeasi AI Unmeasi AI Unmeasi AI Neutral li	elevation delay correction ime data ime data it ±10 µs typical (synchronous), ±0.02% (asynchronous) eir factory default values illized: date and time, communication settings, leanguage, environmental settings*, Custom erence): Indication that appears when the frequency less than the lower limit, decimal point and separator format (csv) the ESC key held down returns all settings except the y default values. features and) d prompts the user to input the add-on package al voltage UE between UE+1 determined computation ured line voltage computed in a three-phase e system E+1, ΔUE+2 litage computed in a three-phase three-wire stem E+1, ΔUE+2 age calculated in a three-phase four-wire system al current iE between iE+1 determined through tion		

				W	T5000			Specification
Power (W)	difference 3P3W->3V3A DELTA->STAR	ΔPE, ΔPE+1, ΔPE+2 Phase power computed in a system	three-phase thre	ree-wire		Frequency filter	Elements 1 to 7, for fr Can be set separately Computation rate	equency measurement and sync source for each element Maximum computation rate: 10 MS/s The computation rate is selected automatical based on the set frequency 100, 1 k, 10 k, 100 k, 1 M, 5 M, or 10 MHz.
veraging Function	STAR->DELTA Delta computatifilter average.		omputing metho	od is digital			Filter response Butterworth	Filter form: IIR Filter type: LPF, HPF, (BPF)* Filter order: 4
Sync source period a	verage Averaging performed over a specified period Set the calculation period using the set reference signal (sync source) (excluding WP and DCq) Sync source Ux, Ix, EXT CLK, Z (/MTR1/MTR2 option) The period of UE and IE is detected using a specified trigger value from the waveform sampling data (E is the element number.) Data update interval						LPF Cutoff frequency: 10 Resolution: 100 Hz HPF When the line filter adva Fixed to 0.1 Hz When the line filter adva Cutoff frequency: 0.1 100 Resolution: 100 Hz (fr	Resolution: 100 Hz HPF When the line filter advanced setting is off Fixed to 0.1 Hz When the line filter advanced setting is on Cutoff frequency: 0.1 Hz, 1 Hz, 10 Hz, 100 Hz to 100 kHz Resolution: 100 Hz (fc ≥ 100 Hz) Cutoff characteristic: –24 dB/Oct (typical)
	Averaging pe	10 ms/50 ms/100 ms/200 r 10 s/20 s eriod: Data update interval or le		2 \$/5 \$/			LPF, BPF, and HPF can Default setting: HPF, (HPF only for the second	
Digital filter average	Digital low-pas Filter form: FIR				_	ntegration Function	Default setting: Off	
	Filter	Attenuation characteristics (<-100 dB)	Computation rate	Settling time	"	Sampling frequency	5 MS/s	
	FAST MID	100 Hz 10 Hz	10 kHz 1 kHz	40 ms 400 ms		Calculation period	Integration timer range	ne, real-time control tion, real-time control repetition b: 0 h 00 m 00 s to 10000 h 00 m 00 s maximum integration time (10000 hours) is
	SLOW VSLOW	1 Hz 0.1 Hz	100 Hz 10 Hz	4 s 40 s			reached or when an ir displayable integrated MVAh, ±999999 Mvar	itegrated value reaches the maximum or minimu value (±999999 MWh, ±999999 MAh, ±999999 h), the integration time and value at that point ar
	Averaging period	od Continuous computati However, the computer		t to 0 when		Dower failure recover	held and integration is	
	a range change, line filter change, zero cal, filter response change, or data update interval change						y Resumes integration if a power failure occurs during integration. In Integration can be executed separately for each element.	
	is executed. Data update interval 10 m/50 m/100 m/200 m/500 m/1/2/5/10/20 s					External control	With the /DA20 option, start, stop, and reset are possible througe external signals.	
ter Function Line filter	For elements 1	to 7				Auto calibration	Auto offset calibration Zero-level compensati	feature ion is performed at the current range of all eleme
Eli lo lilloi	Can be set sep	arately for each element					approximately every h	our.
	Bessel	n rate Filter response Maximum Filter form: IIR	i computation ra	ate. 10 M6/8		Timer accuracy	±0.02% of reading	
	Filter type: LPF Filter order: 4 LPF Cutoff frequency: 100 Hz to 100 kHz, 1 MH Resolution: 100 Hz Cutoff characteristic: -24 dB/Oct (typical)				F	Integration accuracy Frequency Measureme Measured item	nt Function	current accuracy) + timer accuracy cy of the voltage or current applied to all input
						Measurement system	n A/D data level trigger gate generation Reciprocal method	
	Butterwork	th Filter form: IIR Filter type: LPF Filter order: 4				Display resolution	y resolution 99999 um frequency resolution	
		LPF Cutoff frequency:	100 Hz to 100 l	kHz 1 MHz*		- Iviii iii iii iii ii ii equericy ii	0.0001 Hz	
		Resolution: 100 H Cutoff characteristic r: element's internal analog filter, Be	lz b: –24 dB/Oct (ty		Measurement range	0.1 Hz ≤ 1 ≤ 2 MHz For the relationship between the data update interval and the measurement range. See specifications of each element. *Measurement frequency range is limited by the element.		
	For MOTOR (/MTR1/MTR2 option) Can be used during analog input Computation rate Maximum computation rate: 200 kS/s			S/s			(2.2 MHz).	1 times the upper limit of the measurement rang loatingpoint value: 0xFFFFFFE
	Filter respon: Butterwork					Accuracy	Depends on the eleme	
		Filter type: LPF Filter order: 4 LPF Cutoff frequer Cutoff characteristic				Condition	When the input signal level is 30% or more (60% or more when the crifactor is set to CF6 or CF6A) of the measurement range. However, I) Input condition for 50% of the range or more Twice the lower frequency limit above or less Minimum current range 500 mA range (760901) (CF3) 5 mA range (760902) (CF3) Input resistance: 1 Ω, 10 mA range (760903) (CF3) Input resistance: 1 Ω, 10 mA range (760903) (CF3)	
	for each sam Harmonic an possible.	urement is possible through th npling frequency. alysis in an area different from	_					
		e filter advanced setting is off According to the ele	ement's line filter	r				sensor range 60901, 760902) (CF3) clamp probe input range
	When the line	e filter advanced setting is on Filter exclusive to ha (independent of the					50 mV range (76 2) Frequency filter set 0.1 Hz to 100 H	60903) (CF3) up conditions
	Filter respons Bessel	Filter form: IIR Filter type: LPF				Frequency detection	100 Hz to 1 kHz 1 kHz to 100 kH signal level setting	
		Filter order: 4 LPF Cutoff frequer Resolution: 10 Cutoff characteristic	00 Hz				Selectable range HPF: ON: Auto HPF: OFF: Rectifier	· OFF: ±100% of range · ON: 0% to +100% of range
	Butterwork	th Filter form: IIR			- H	Harmonic Measuremen	t Feature	
		Filter type: LPF Filter order: 4				Measured item	All installed elements	
		LDE 0.4-# 6	00//: 100 Hz to 1	100 111		Method	PLL synchronization n	nernod
		LPF Cutoff frequer Resolution: 10		IUU KHZ		Frequency range	Fundamental frequence	

PLL source

Select the input element's voltage or current or external clock.

Input level: 50% or more of the rated measurement range when the crest factor is CF3.

100% or more of the rated measurement range when the crest factor is CF6 or CF6A.

The conditions in which frequency filters are turned on

0.1 Hz ≤ f < 100 Hz: 100 Hz

100 Hz ≤ f < 1 kHz: 1 kHz

1 kHz ≤ f < 10 kHz: 10 kHz

10 kHz ≤ f < 100 kHz: 100 kHz

Number of FFT points Select 1024 or 8192.

Window function Rectangular

Anti-Aliasing Filter Set using a line filter or harmonic filter

When the number of FFT points is 1024

1					
Fundamental	Sample	Window	Upper limit of harmonic analysis		
frequency	rate	width	U, I, P, φ, φU, φΙ	Other measured values	
			φυ, φι	values	
0.1 Hz to 3 kHz	f×1024	1 wave	100th	100th	
3 kHz to 7.5 kHz	f×512	2 waves	100th	100th	
7.5 kHz to 15 kHz	f×256	4 waves	50th	50th	
15 kHz to 30 kHz	f×128	8 waves	20th	20th	
30 kHz to 75 kHz	f×64	16 waves	10th	10th	
75 kHz to 150 kHz	f×32	32 waves	5th	5th	

Harmonic analysis is not executed (disabled) when the update interval is 10 ms.

When the number of FFT points is 8192 (at 10 MS/s)

Fundamental	Sample	Window	Upper limit of h	armonic analysis
frequency	rate	width	U, I, P, φ, φU, φΙ	Other measured values
0.5 Hz to 3 kHz	f×1024	8 waves	500th harmonic	100th
3 kHz to 7.5 kHz	f×1024	8 waves	200th	100th
7.5 kHz to 15 kHz	f×512	16 waves	100th	100th
15 kHz to 30 kHz	f×256	32 waves	50th	50th
30 kHz to 75 kHz	f×128	64 waves	20th	20th
75 kHz to 150 kHz	f×64	128 waves	10th	10th
150 kHz to 300 kHz	f×32	256 waves	5th	5th

The upper harmonic limit is 100 when the update interval is 50 ms.
Further, harmonic analysis is not executed (disabled) when the update interval is 10 ms.

When the number of FFT points is 8192 (at 5 MS/s)

Fundamental	Sample	Window	Upper limit of h	armonic analysis
frequency	rate	width	U, I, P, φ, φU, φΙ	Other measured values
0.5 Hz to 1.2 kHz	f×1024	8 waves	500th harmonic	100th
1.2 kHz to 3 kHz	f×1024	8 waves	200th	100th
3 kHz to 7.5 kHz	f×512	16 waves	100th	100th
7.5 kHz to 15 kHz	f×256	32 waves	50th	50th
15 kHz to 30 kHz	f×128	64 waves	20th	20th
30 kHz to 75 kHz	f×64	128 waves	10th	10th
75 kHz to 150 kHz	f×32	256 waves	5th	5th

The upper harmonic limit is 100 when the update interval is 50 ms. Further, harmonic analysis is not executed (disabled) when the update interval is 10 ms.

IEC Harmonic Measurement Featu	C Harmonic Measurement Feature (G7 option)				
Item Supported standards	Specifications IEC61000-4-7 Ed1.0/Ed2.0/Ed2.0 A1				
Target element	30 A High Accuracy Element (760901), 5 A High Accuracy Element (760902)				
Measured Item	Select one of the input elements or Σ wiring units.				
Method	PLL synchronization method				
Frequency range	Fundamental frequency: 45 Hz to 66 Hz Analysis frequency: 45 Hz to 10 kHz				
PLL source	Select the input element's voltage or current or external clock. Input level: 50% or more of the rated measurement range when the crest factor is CF3. 100% or more of the rated measurement range when the crest factor is CF6 or CF6A. Frequency filter: 100 Hz ON				
Number of FFT points	32768				
Window function	Rectangular				
Window spacing	No gap, no overlap				
Anti-aliasing filter	Set using a line filter (Butterworth 30 kHz: Ed2.0/E2.0A1, 20 kHz: Ed1.0)				
Interharmonic measurement	 Select the grouping function Type1, Type2, or none. (IEC 61000-4-7 Ed 2.0/Ed 2.0 A1) No grouping function. (IEC 61000-4-7 Ed 1.0) 				

IEC6100	00-4-7 Fc	12 0/Fd	2 0 A1

1E001000-4-7 Ed 2.0/Ed 2.0 A1				
	Fundamental frequency	Sample rate	Window width	Upper limit of harmonic analysis
	45 Hz to 55 Hz	f × 3276.8	10 waves	200th
	55 Hz to 66 Hz	f × 2730.67	12 waves	170th
IEC61000-4-7 Ed 1.0	Fundamental frequency	Sample rate	Window width	Upper limit of

Data update interval

Depends on the PLL source Approx. 200 ms (Ed 2.0/Ed 2.0 A1), approx. 320 ms (Ed 1.0) when the PLL source frequency is 50 Hz Approx. 200 ms (Ed 2.0/Ed 2.0 A1), approx. 267 ms (Ed 1.0) when the PLL source frequency is 60 Hz

16 waves

120th

Item Specifications		
Flicker meter class	F2	
Applicable standards	IEC 61000-4-15 Ed 1.1/Ed 2.0	

f x 2048

Normal Voltage Fluctuation/Flicker Measurement Mode

45 Hz to 66 Hz

•		
Item	Specifica	tions
Measured item	dc	Relative steady-state voltage change
	dmax	Maximum relative voltage change
	Tmax	Time during which the relative voltage change exceeds the threshold level in a single voltage change period
	Pst	Short-term flicker value
	Plt	Long-term flicker value
One observation period	30 s to	15 min
Number of observation periods	1 to 99	

"Measurement of dmax caused by manual switching" Mode

It	em Measured item	Specifica dmax	tions Maximum relative voltage change
	One observation period	1 min	
	Number of observation periods		outs 22 average values excluding the maximum imum values)

Items Common to Both Measurement Modes

Item	Specifications	
Target voltage/frequency	230 V/50 Hz, 230 V/60 Hz, 120 V/50 Hz, 120 V/60 Hz	
Measurement target input	Voltage (no current measurement function)	
Target element	30 A High Accuracy Element (760901), 5 A High Accuracy Element (760902)	
Number of measurement elements	Up to three elements	
Voltage input level	At least 50% of the range rating	
Flicker scale	0.0001-6400 P.U. (20%) divided logarithmically into 1400	
Display update	2 s (dc, dmax, Tmax) At the end of each observation period (Pst)	
Communication output	dc, dmax, Tmax, Pst, Plt, instantaneous flicker sensation (Pinst), cumulative probability function (CPF)	
External storage output	Screen image	

_			
D	Data Streaming Feature (DS option)		
Item Specifications		Specifications	
	Waveform sampling	Select from 10 kS/s to 2 MS/s (1-2-5 steps, simple decimation), 1 MS/s maximum during integration	
	Waveform data to be streamed	All inputs (U, I, Motor)	
	Numeric data to be saved	All numeric data (normal data, harmonic data)	
	Data update interval	Operates in constant-interval update mode at an update interval of 50 ms, 100 ms, 200 ms, 500 ms, or 1 s	
	Time data	IEEE1588 compatible	
	Data format	32-bit single precision floating point	

^{*}The 50 ms data update under the Data Streaming function is available if the firmware version of WT5000 is 3.01 or later.

Auxiliary I/O		
External Clock Input Se		
Input connector type	BNC	
Input level	ΠL	
Sync signal input	Normal measurement: Frequency range: Same as the frequency measurement range Harmonic measurement: Frequency range: 0.1 Hz to 300 kHz	
	*Input waveform: 50% duty ratio rectangular wave	
Trigger input	Input logic: Negative logic, falling edge	
	Minimum pulse width: 1 µs	
	Trigger delay: Within (2 µs + 12 µs + phase correction time)	
xternal Monitor		
Input connector type	D-sub 15 pin (receptacle)	
Output format	Analog RGB output	

Output resolution	WXGA output, 1280×800 dots Approx. 60 Hz Vsync (66 MHz dot clock frequency)
emote, D/A (Option) Input connector type	Micro ribbon connector (Amphenol 57LE connector), 36-pin
Control signal	Integration RESET: EXT RESET START: EXT START STOP: EXT STOP BUSY: INTEG BUSY Updating Data HOLD: EXT HOLD SINGLE: EXT SINGLE
Input	0 to 5 V
Output	0 to 5 V
eripheral Device Conn	ection
SB	
Connector type	Type A connector (receptacle)
Ports	2
Electrical and mechan	ical Complies with USB Rev. 2.0
Supported transfer mo	odes HS (High Speed) mode (480 Mbps), FS (Full Speed) mode (12 Mbps), LS (Low Speed) mode (1.5 Mbps)
Compatible devices	Mass storage devices that comply with USB Mass Storage Class Ver. 1. Usable capacity: 8 TB, partition format: MBR/GPT, format type: FAT32/FAT16/exFAT 104 or 109 keyboards that comply with USB HID Class Ver. 1.1 Mouse devices that comply with USB HID Class Ver. 1.1
Power supply	5 V, 500 mA (each port) You cannot connect devices whose maximum current consumptions exceed 100 mA to two different ports on the instrument at the same time.

Computer Interface

GP-IB Interface

Input connector type 24-pin connector

Electrical and mechanical

Complies with IEEE St'd 488-1978 (JIS C 1901-1987)

Functional specifications

SH1, AH1, T6, L4, SR1, RL1, PP0, DC1, DT1, and C0 Conforms to IEEE St'd 488.2-1992 Protocol Code ISO (ASCII) code Mode Addressable mode Address 0 to 30 Press UTILITY (LOCAL) to clear remote mode (except during Local Clear remote mode Lockout).

Ethernet interface

Connector type RJ-45 connector Ports 1 Electrical and mechanical IEEE802.3 compliant, Auto-MDIX

Transmission system Ethernet1000Base-T/100BASE-TX/10BASE-T

Communication protocol

TCP/IP

FTP server, DHCP, DNS, remote control (VXI-11, Socket), SNTP, FTP Supported services client, Modbus/TCP server, and web server

USB PC Interface Type B connector (receptacle) Connector type Ports

Electrical and mechanical

Complies with USB 3.0

Supported transfer modes

SS (SuperSpeed) mode (5 Gbps), HS (High Speed) mode (480 Mbps), FS

(Full Speed) mode (12 Mbps)

Supported protocols USBTMC-USB488 (USB Test and Measurement Class Ver. 1.0)

PC system requirements

A PC with a USB port, running Windows 7, Windows 8.1, or Windows 10. A separate device driver is required to enable the connection with the PC.

System Maintenance Processing

Alarm Generation and Operation Fan stop

Fan stop alarm indication Emergency operation stop after about 60 seconds*

Internal temperature error

Temperature error alarm indication

Emergency operation stop*

*Emergency operation stop

Stops the power supply for running the instrument Stops the power supply for elements, motor (/MTR1/MTR2), and D/A output (/DA20) Generates intermittent beeps, MENU key in the SETUP area blinks in red Continues the fan operation

General Specifications		
Warm-up time	Approx. 30 minutes	5
Operating environment	Temperature	5°C to 40°C
	Humidity	20% RH to 80% RH (no condensation)
	Operating altitude	2000 m or less
	Installation location	Indoors
Storage environment	Temperature	-25°C to 60°C (no condensation)
	Humidity	20% RH to 80% RH (no condensation)
Rated supply voltage	100 VAC to 120 VA	C, 220 VAC to 240 VAC
Permitted supply voltage		c, 198 VAC to 264 VAC
Rated supply frequency	50/60 Hz	
Permitted supply frequen	cy range 48 Hz to 63 Hz	
Maximum power consum	nption 560 VA	
Cooling method	Forced air cooling,	air vents on the left, right, and top panels
Installation orientation	Horizontal, tilted (us	ing the stand)
External dimensions		mm (W) × 496 mm (D) les and protrusions)
Weight	Approx. 12.5 kg (m	ain unit only with /M1/MTR1/DA20 installed)
Battery backup	Setup parameters a	nd the internal clock are backed up with a lithium battery.
Safety standards*1	EN 60825-1	

- Applies to products with CE marks. For information on other products, contact your nearest YOKOGAWA dealer. The overvoltage category (installation category) is a value used to define the transient overvoltage condition and includes the rated impulse withstand voltage. CAT II applies to electrical equipment that is powered through a fixed installation, such as a wall outlet wired to a distribution board.
- This instrument is a measurement category II product. Do not use it for measurement category III or IV

Measurement category O applies to measurement of other types of circuits that are not directly connected to


investigate the firecategory of applies to interest and interest of the stress of inclusions and are not unlevely connected to a main power source. Measurement Category II applies to electrical equipment that is powered through a fixed installation, such as a wall outlet wired to a distribution board, and to measurement performed on such wiring. Measurement category III applies to measurement of facility circuits, such as distribution boards and circuit

Measurement category IV applies to measurement of power source circuits, such as entrance cables to

buildings and cable systems, for low-voltage installations.

Pollution Degree applies to the degree of adhesion of a solid, liquid, or gas that deteriorates withstand voltage or surface resistivity. Pollution Degree 2 applies to normal indoor atmospheres (with only non-conductive pollution).

External Dimensions



The following information is printed on the top.

IF CLASS 1 LASER PRODUCT MODULE IS AVAILABLE クラス1レーザモジュール実装時 安装Class 1激光模块时

CLASS 1 LASER PRODUCT (EN 60825-1:2014) (IEC 60825-1:2007, GB 7247.1-2012)

Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No.50, dated June 24, 2007 4-9-8 Myojin-cho, Hachioji-shi, Tokyo 192-8566, Japan

760901 30A High Accuracy Element

Input terminal type	
**	Voltage
	Plug-in terminal (safety terminal) Current
	Direct input: Plug-in terminal (safety terminal) External current sensor input: isolated BNC
Input type	Voltage Floating input through resistive voltage divider
	Current Floating input through shunt
Measurement range	Voltage 1.5/3/6/10/15/30/60/100/150/300/600/1000 V (crest factor CF3) 0.75/1.5/3/5/7.5/15/30/50/75/150/300/500 V (crest factor CF6) 0.75/1.5/3/5/7.5/15/30/50/75/150/300/500 V (crest factor CF6A)
	Current Direct input 500 mA, 1 A, 2 A, 5 A, 10 A, 20 A, 30 A (crest factor CF3) 250 mA, 500 mA, 1 A, 2.5 A, 5 A, 10 A, 15 A (crest factor CF6) 250 mA, 500 mA, 1 A, 2.5 A, 5 A, 10 A, 15 A (crest factor CF6A)
	External current sensor input 50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V, 5 V, 10 V (crest factor CF3) 25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V (crest factor CF6)
	25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V (crest facto CF6A)
Input impedance	Voltage 10 M Ω ± 1%, input capacitance: approx. 15 pF
	Current Direct input: 6.5 m Ω ±10% + approx. 0.3 μ H
	External current sensor input: input resistance: 1 MΩ ± 1%, input capacitance: approx. 50 pF
Instantaneous maximum	n allowable input (within 1 s)
	Voltage Peak value of 2.5 kV or RMS value of 1.5 kV, whichever is less
	Current Direct input Peak value of 150 A or rms value of 50 A, whichever is less.
	External current sensor input Peak value 10 times the range or 25 V, whichever is less
Continuous maximum al	Illowable input Voltage Peak value of 1.6 kV or RMS value of 1.5 kV, whichever is less If the frequency of the input voltage exceeds 100 kHz, (1200 – f) Vrms or less. f is the frequency of the input voltage in units of kHz. Current
	Direct input Peak value of 90 A or rms value of 33 A, whichever is less.
	External current sensor input Peak value 5 times the range or 25 V, whichever is less
Maximum rated voltage	to earth (DC to 50/60 Hz) Voltage input terminal 1000 V CAT II
	Current input terminal 1000 V CAT II
	External current sensor input connector
Influence of voltage to ea	1000 V CAT II arth
	When 1000 Vrms is applied between the input terminal and the WT5000 case with the voltage input terminals shorted, current input terminals open and external current sensor input terminals shorted. 50/60 Hz: ±0.01% of range or less.
	Reference value for up to 200 kHz Voltage ±{(maximum rated range)/(rated range) × 0.001 × f% of range} or less
	Current Direct input ±((maximum rated range)/(rated range) × 0.001 × f% of range) or less
	External current sensor input ±{(maximum rated range)/(rated range) × 0.001 × f% of range} or less However, 0.01% or greater. The unit of f is kHz. The maximum range rating in the equation is for a voltage of 1000
	V, direct current input of 30 A, and external current sensor input of 10 V.
A/D converter	Simultaneous conversion of voltage and current inputs. Resolution: 18 bits

Lower limit of measurement frequency
Svnc source period average method

Cyric source per	Cyric source period average mer	
Data update interval		
10 ms	200 Hz	
50 ms	45 Hz	
100 ms	20 Hz	
200 ms	10 Hz	
500 ms	5 Hz	
1 s	2 Hz	
2 s	1 Hz	
5 s	0.5 Hz	
10 s	0.2 Hz	
20 s	0.1 Hz	

Digital filter average method		
FAST	100 Hz	
MID	10 Hz	
SLOW	1 Hz	
VSLOW	0.1 Hz	

Maximum display

140% of the rated voltage or current range (160% for the 1000 V range) 280% of the voltage and current range rating for CF6A (except 320% for the 500 V range)

Minimum display

Depending on the measurement range, the following are the minimum values that are displayed:

- Urms, Uac, Irms, and Iac: 0.3% (0.6% when the crest factor is set to CF6 or CF6A)
- Umn, Urmn, Imn, and Irmn: 2% (4% when the crest factor is set to CF6 or CF6A)

When input level is lower than above, the display shows zero if rounding to zero setting is ON, otherwise measured value will be shown. Current integration value q also depends on the current value.

Accuracy

Accuracy (6 months)

Condition

For the 1 year accuracy, multiply the reading of the accuracy at 6 months by 1.5.

Temperature: 23°C±5°C Input waveform: Sine wave λ (power factor): 1 Voltage to ground: 0 V Crest factor: CF3 Line filter: OFF

Sync source period average method

Frequency filter: Used for signal frequencies at 1 kHz or less (for sync source period average method)

Sync source signal level: Same as the frequency measurement conditions Input range: DC 0% to $\pm110\%$ of range, AC 1% to 110% of range

Defined using rms values for AC After the warm-up time has elapsed.

Wired condition after zero-level compensation or measurement range change. The unit of f in the accuracy equations is kHz.

Voltage		
DC	±(0.02% of reading + 0.05% of range)	
0.1 Hz ≤ f < 10 Hz	±(0.03% of reading + 0.05% of range)	
10 Hz ≤ f < 45 Hz	±(0.03% of reading + 0.05% of range)	
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)	
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.04% of range)	
1 kHz < f ≤ 10 kHz	±(0.1% of reading + 0.05% of range) Add 0.015 × f % of reading (10 V range or less).	
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)	
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)	
100kHz < f≤ 500kHz	±{(0.006 × f)% of reading + 0.5% of range}	
500 kHz < f ≤ 1 MHz	±{(0.022 × f - 8)% of reading + 1% of range}	
Frequency bandwith	DC to 10 MHz (Typical)	

Current	
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f < 10 Hz	±(0.03% of reading + 0.05% of range)
10 Hz ≤ f < 45 Hz	±(0.03% of reading + 0.05% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.04% of range)
1 kHz < f ≤ 10 kHz	±(0.1% of reading + 0.05% of range)
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)
100 kHz < f ≤ 200 kHz	±{(0.00725× f - 0.125)% of reading + 0.5% of range}
200 kHz < f ≤ 500 kHz	±{(0.00725× f - 0.125)%of reading + 0.5% of range}
500 kHz < f ≤ 1 MHz	$\pm \{(0.022 \times f - 8)\% \text{ of reading} + 1\% \text{ of range}\}$
Frequency bandwidth	Direct input: DC to 5 MHz (typical) External current sensor input: DC to 5MHz (typical)

Active power (power factor 1)	
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f < 10 Hz	±(0.08% of reading + 0.1% of range)
10 Hz ≤ f < 30 Hz	±(0.08% of reading + 0.1% of range)
30 Hz ≤ f < 45 Hz	±(0.05% of reading + 0.05% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.05% of reading + 0.05% of range)
1 kHz < f ≤ 10 kHz	±(0.15% of reading + 0.1% of range) Add 0.01 × f % of reading (10 V range or less).
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.7% of reading + 0.3% of range)
100 kHz < f ≤ 200 kHz	\pm {(0.008 × f)% of reading + 1% of range}
200 kHz < f ≤ 500 kHz	\pm {(0.008 × f)% of reading + 1% of range}
500 kHz < f ≤ 1 MHz	±{(0.048 × f - 20)% of reading + 1% of range}

• For the direct current input range, add the following values to the accuracies listed above DC current accuracy: 0.1~mA DC power accuracy: (0.1~mA/rated) value of the direct current input range) \times 100% of range

For the accuracies of waveform data functions Upk and lpk

Add the following values (reference values) to the accuracies listed above

The effective input range is within ±300% (±600% when the crest factor is set to CF6 or CF6A) of the range.

Voltage input: {√1.5/range + 0.5}% of range

Direct current input range

 $\sqrt{1/range} + 0.5$ % of range + 10 mA

External current sensor input range

 $\sqrt[4]{0.01/\text{range}} + 0.5$ % of range (50 mV to 200 mV range) $\sqrt[4]{0.1/\text{range}} + 0.5$ % of range (500 mV to 10 V range)

• Influence of temperature changes after zero-level compensation or range change

- Add the following values to the accuracies listed above.

 DC voltage accuracy: ±0.02% of range/°C (1.5 V to 10 V range) ±0.005% of range/°C (15 V to 1000 V range)

 Direct current input DC accuracy: ±0.1 mA/°C.

- External current sensor input DC accuracy: ±50 μV/°C (50 mV to 200 mV range) $\label{eq:controlled} 2200\ \mu\text{V/C}\ (0.5\ V\ to\ 10\ V\ range)$ For the DC power accuracy, add the voltage influence \times I and the current influence \times U.

U is the voltage reading (V). I is the current reading (A).

Influence of self-generated heat caused by current input

Add the following values to the current accuracy: For the power accuracy, add the voltage and the current influence.

AC input signal

Current, active power, apparent power: 0.00002 × I²% of reading

• DC input signal Current: 0.00002 \times l²% of reading + 3 \times l² μ A Power: 0.00002 \times l²% of reading + 3 \times l² μ A \times U

U is the voltage reading (V).

I is the current reading (A). Even if the current input decreases, the influence from self-generated heat continues until the temperature of the shunt resistor decreases

Guaranteed accuracy ranges for frequency, voltage, and current

All accuracy figures for 0.1 Hz to 10 Hz are reference va

The voltage and power accuracy figures for 30 kHz to 100 kHz when the voltage exceeds 750 V

The current and power accuracy figures for DC, 10 Hz to 45 Hz, and 400 Hz to 100 kHz when the current exceeds 20 A are reference values.

• Influence of data update interval

Add the following value for signal sync period average

10 ms: 0.03% of reading 50 ms: 0.03% of reading

100 ms: 0.02% of reading

Accuracy when the crest factor is set to CF6 or CF6A:

The same as the accuracy when the crest factor is CF3 after doubling the range.

Power factor (λ) influence When $\lambda = 0$

Apparent power reading × 0.02% in the range of 45 Hz to 66 Hz. For other frequency ranges, see below. However, note that these figures are reference values.

Apparent power reading \times (0.02 + 0.05 \times f)%

When $0 < \lambda < 1$

(Power reading) × [(power reading error %) + (power range error %) × (power range/indicated apparent power value) + $\{ \tan \phi \times (\text{influence}) + \{ \tan$ when $\lambda = 0)\%$],

where ϕ is the phase angle between the voltage and current.

The drift of First the accuracy equations is Kriz.		
Temperature coefficient ±0.01% of reading/°C (5°C to 18°C or 28°C to 40		
Influence of humidity Add to the voltage and active power accuracies:		

The unit of f in the accuracy

Add to the voltage and active power accuracies: $\pm 0.00022 \times |\text{HUM} - 50| \times \text{f}$ % of reading: f $\leq 40 \text{ kHz}$ $\pm 0.0087 \times |\text{HUM} - 50|$ % of reading: f > 40 kHz

Reference: Add to the power factor error.

When $\lambda = 0$

Apparent power reading × 0.00002 × |HUM – 50| × f%

When $0 < \lambda < 1$

(Power reading) × {(power reading error %) + (power range error %) × (power

The unit of f in the accuracy equations is kHz.

range/indicated apparent power value) + [tan ϕ × (influence when λ = 0)%]], HUM: Relative humidity [%RH]

Effective input range	Udc, Idc: 0% to ±130% of the measurement range (excluding the
Encouro inparrango	1000 V range)*
	Udc 1000 V range: 0% to ±150%*
	Urms, Irms: 1% to 130% of the measurement range*
	Umn, Imn: 10% to 130% of the measurement range*
	Urmn, Irmn: 10% to 130% of the measurement range*
	Power
	DC measurement: 0% to +150% when the voltage measurement
	range is 1000 V, 0 to +130% otherwise*
	AC measurement: 1% to 130%* of the voltage and current ranges; up to ±130%* of the power range
	*The accuracy for 110% to 130% of the measurement range (excluding the 1000 \ range) is range error x 1.5. If the input voltage exceeds 600 V, add 0.02% of reading. However, the signal level for the signal sync period average must meet the input signal level for frequency measurement. When the crest factor is set to CF6 or CF6A, double the lower limit.
Accuracy of apparent power S	Voltage accuracy + current accuracy
Accuracy of reactive power Q	Accuracy of apparent power + $(\sqrt{1.0002-\lambda^2}-\sqrt{1-\lambda^2}~)\times 100\%$ of range
Accuracy of power factor λ	$\pm[(\lambda-\lambda/1.0002)+ cos\phi-cos\{\phi+sin^{-1}((influence from the power factor when \lambda=0)\%/100)\}]]\pm1 digit$
	The voltage and current must be within their rated ranges.
Accuracy of phase difference φ	$\pm[\phi-\{\cos^{1}(\!\lambda 1.0002)\} +\sin^{1}\{(influence from the power factor when \lambda=0)\%/100\}] deg \pm 1 digit$
	The voltage and current must be within their rated ranges.
Lead and lag detection	Phase difference: ±(5° to 175°)
	Frequency: 20 Hz to 10 kHz
	Condition: Sine wave
	At least 50% of the measurement range (at least 100% for CF6 and CF6A)
Line filter	Bessel, 5th order LPF, fc: 1 MHz
	Voltage, current
	Up to 100 kHz: Add (20 × f/fc)% of reading
	Power
	Up to 100 kHz: Add (40 × f/fc)% of reading

Frequency measurement

Frequency measurement range		
Data update interval	Measurement range	
10 ms	200 Hz ≤ f ≤ 2 MH	
50 ms	45 Hz ≤ f ≤ 2 MHz	
100 ms	20 Hz ≤ f ≤ 2 MHz	
200 ms	10 Hz ≤ f ≤ 2 MHz	
500 ms	5 Hz ≤ f ≤ 2 MHz	
1 s	2 Hz ≤ f ≤ 2 MHz	
2 s	1 Hz ≤ f ≤ 2 MHz	
5 s	0.5 Hz ≤ f ≤ 2 MHz	
10 s	0.2 Hz ≤ f ≤ 2 MHz	
20 s	0.1 Hz ≤ f ≤ 2 MHz	

Accuracy: ±0.06% of reading ±0.1 mHz

Conditions:

Input signal level:

CF3: At least 30% of the measurement range

CF6/6A: At least 60% of the measurement range However, at least 50% of the range if the signal is less than or equal

to twice the lower measurement frequency

Frequency filter

0.1 Hz ≤ f < 100 Hz: 100 Hz 100 Hz ≤ f < 1 kHz: 1 kHz 1 kHz \leq f < 100 kHz: 100 kHz

Harmonic measurement PLL source input level

50% or more of the rated measurement range when the crest factor is CF3.

100% or more of the rated measurement range when the crest factor is CF6 or CF6A.

Accuracy

Add the following accuracy values to the normal measurement accuracy values.

When line filters are turned off		
Frequency	Voltage, current	
0.1 Hz ≤ f < 10 Hz	±(0.01% of reading + 0.03% of range)	
10 Hz ≤ f < 45 Hz	±(0.01% of reading + 0.03% of range)	
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.03% of range)	
66 Hz < f ≤ 440 Hz	±(0.01% of reading + 0.03% of range)	
440 Hz < f ≤ 1 kHz	±(0.01% of reading + 0.03% of range)	
1 kHz < f ≤ 10 kHz	±(0.01% of reading + 0.03% of range)	
10 kHz < f ≤ 50 kHz	±(0.05% of reading + 0.1% of range)	
50 kHz < f ≤ 100 kHz	±(0.1% of reading + 0.2% of range)	
100 kHz < f ≤ 500 kHz	±(0.1% of reading + 0.5% of range)	
500 kHz < f ≤ 1.5 MHz	±(0.5% of reading + 2% of range)	

Frequency	Power
0.1 Hz ≤ f < 10 Hz	±(0.02% of reading + 0.06% of range)
10 Hz ≤ f < 45 Hz	±(0.02% of reading + 0.06% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.02% of reading + 0.06% of range)
66 Hz < f ≤ 440 Hz	±(0.02% of reading + 0.06% of range)
440 Hz < f ≤ 1 kHz	±(0.02% of reading + 0.06% of range)
1 kHz < f ≤ 10 kHz	±(0.02% of reading + 0.06% of range)
10 kHz < f ≤ 50 kHz	±(0.1% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.2% of reading + 0.4% of range)
100 kHz < f ≤ 500 kHz	±(0.2% of reading + 1% of range)
500 kHz < f ≤ 1.5 MHz	±(1% of reading + 4% of range)

· When line filters are turned on

Add the line filter influence to the accuracy values when the line filters are turned off.

- When the crest factor is set to CF3
- When λ (the power factor) is 1 • Power figures that exceed 10 kHz are reference values.
- For the voltage range, add 25 mV to the voltage accuracy and (25 mV/ current range rating) × 100% of range to the power accuracy.
- For the direct current input range, add 20 mA to the current accuracy and (20 mA/current range rating) × 100% of range to the power accuracy.
- For the external current sensor range, add 2 mV to the current accuracy and (2 mV/rated value of the external current sensor range) x 100% of range to the power accuracy.
- When the number of FFT points is 1024, add ±0.2% to the voltage and current range errors and $\pm 0.4\%$ to the power range error.
- Add (n/500)% of reading to the nth component of the voltage and current, and add (n/250)% of reading to the nth component of the power.
- The accuracy when the crest factor is CF6 or CF6A is the same as the accuracy when the crest factor is CF3 after doubling the measurement
- The guaranteed accuracy ranges for frequency, voltage, and current,
- are the same as the guaranteed ranges for normal measurement.

 The neighboring harmonic orders may be affected by the side lobes from the input harmonic order.

When FFT points is set to 8192

When the frequency of the PLL source is 2 Hz or greater, for nth order component input, add {[n/(m + 1)]/50}% of (the nth order reading) to the n + mth order and n - mth order of the voltage and current, and add $\{[n/(m+1)]/25\}\%$ of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and n - mth order of the power.

When the frequency of the PLL source is less than 2 Hz, for $n^{\mbox{\tiny th}}$ order component input, add $\{[n/(m+1)]/20\}\%$ of (the n^{th} order reading) to the $n + m^{\text{th}}$ order and $n - m^{\text{th}}$ order of the voltage and current, and add $\{[n/(m+1)]/10\}\%$ of (the n^{th} order reading) to the $n+m^{th}$ order and $n-m^{th}$ order of the power.

When FFT points is set to 1024

When the frequency of the PLL source is 75 Hz or greater, for nth order component input, add ($\{n/(m+1)\}/50$)% of (the nth order reading) to the n + mth order and n - mth order of the voltage and current, and add ($\{n/(m+1)\}/25$)% of (the nth order reading) to the n + mth order and n – mth order of the power.

When the frequency of the PLL source is less than 75 Hz, for nth order component input, add ($\{n/(m+1)\}/5$)% of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and $n-m^{\text{th}}$ order of the voltage and current, and add $(2\times\{n/(m+1)\}/5)\%$ of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and n - mth order of the power.

IEC Harmonic measurement

PLL source input level

50% or more of the rated measurement range when the crest factor

100% or more of the rated measurement range when the crest factor

Accuracy

Frequency	Voltage, current
45 Hz ≤ f ≤ 66 Hz	±(0.2% of reading + 0.04% of range)
66 Hz < f ≤ 440 Hz	±(0.2% of reading + 0.05% of range)
440Hz < f ≤ 1 kHz	±(0.2% of reading + 0.05% of range)
1 kHz < f ≤ 2.5 kHz	±(0.3% of reading + 0.05% of range)
2.5 kHz < f ≤ 3.3 kHz	±(0.4% of reading + 0.05% of range)
3.3 kHz < f ≤ 10 kHz	±(1% of reading + 0.05% of range)

Frequency	Power
45 Hz ≤ f ≤ 66 Hz	±(0.4% of reading + 0.05% of range)
66 Hz < f ≤ 440 Hz	±(0.4% of reading + 0.1% of range)
440Hz < f ≤ 1 kHz	±(0.4% of reading + 0.1% of range)
1 kHz < f ≤ 2.5 kHz	±(0.6% of reading + 0.1% of range)
2.5 kHz < f ≤ 3.3 kHz	±(0.8% of reading + 0.1% of range)
3.3 kHz < f ≤ 10 kHz	±(2% of reading + 0.1% of range)

- When the 30 kHz Butterworth line filter is on
- When the crest factor is set to CF3
- When λ (the power factor) is 1
- When group is off
- The neighboring harmonic orders may be affected by the side lobes from the input harmonic order

For nth order component input, add {[n/(m + 1)]/50}% of (the nth order reading) to the $n+m^m$ order and $n-m^m$ order of the voltage and current, and add $\{[n/(m+1)]/25\}\%$ of (the n^m order reading) to the n+mmth order and n - mth order of the power

- The accuracy when the crest factor is CF6 or CF6A is the same as the accuracy when the crest factor is CF3 after doubling the measurement range.
- The guaranteed accuracy ranges for frequency, voltage, and current, are the same as the guaranteed ranges for normal measurement.
- The guaranteed accuracy ranges for frequency, voltage, and current, are the same as the guaranteed ranges for normal measurement.
- Influence of self-generated heat caused by current input is the same as with normal measurement.
- . The temperature coefficient is the same as with normal measurement.
- Influence of humidity is the same as with normal measurement. Accuracy at 1 year is the same as with normal measurement.
- Frequency measurements are reference values

IEC voltage fluctuation

Accuracy

dc, dmax: ±4% (at dmax = 4%)

Pst: ±5% (at Pst = 1 to 3), ±0.05 (at Pst = 0.2 to 1)

Conditions for the accuracies above

Ambient temperature: 23 to 1°C
Line filter: 10 Hz ON

• Frequency filter: 1 kHz ON

50-pin B to B connector

Frequency measurements are reference values

Dimensions

Dimensions

Connection

Approx. 145 mm (H) x 42 mm (W) x 297 mm (D)

The depth includes the slide cover (293 mm if slide cover is excluded). Weight

- 760901 30A High Accuracy Element
- 760902 5A High Accuracy Element
- 760903 Current Sensor Element

The following information is printed on the side.



Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No.50, dated June 24, 2007 4-9-8 Myojin-cho, Hachioji-shi, Tokyo 192-8566, Japan

760902 5A High Accuracy Element

Input terminal type	Voltage Plug-in terminal (safety terminal)
	Current Direct input: Plug-in terminal (safety terminal) External current sensor input: isolated BNC
Input type	Voltage Floating input through resistive voltage divider
	Current Floating input through shunt
Measurement range	Voltage 1.5/3/6/10/15/30/60/100/150/300/600/1000 V (crest factor CF3) 0.75/1.5/3/5/7.5/15/30/50/75/150/300/500 V (crest factor CF6) 0.75/1.5/3/5/7.5/15/30/50/75/150/300/500 V (crest factor CF6A)

Current

5 mA, 10 mA, 20 mA, 50 mA, 100 mA, 200 mA, 500 mA, 1 A, 2 A, 5 A (crest factor CF3)

2.5 mA, 5 mA, 10 mA, 25 mA, 50 mA, 100 mA, 250 mA, 500 mA, 1 A, 2.5 A (crest factor CF6)

2.5 mA, 5 mA, 10 mA, 25 mA, 50 mA, 100 mA, 250 mA, 500 mA,

1 A, 2.5 A (crest factor CF6A)

External current sensor input 50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V, 5 V, 10 V (crest factor

25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V (crest factor 25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V (crest factor

Input impedance

Voltage

 $10~\text{M}\Omega$ ± 1%, input capacitance: approx. 15 pF

Current

Direct input: 0.5 Ω ±10% + approx. 0.3 μH (200 mA or lower ranges) $0.11 \Omega \pm 10\% + approx. 0.3 \mu H (500 mA or higher ranges)$

External current sensor input: input resistance: 1 M Ω ± 1%, input capacitance: approx. 50 pF

Instantaneous maximum allowable input (within 1 s)

Voltage

Peak value of 2.5 kV or RMS value of 1.5 kV, whichever is less

Direct input

Peak value of 30 A or rms value of 15 A, whichever is less.

External current sensor input

Peak value 10 times the range or 25 V, whichever is less

Continuous maximum allowable input

Voltage

Peak value of 1.6 kV or RMS value of 1.5 kV, whichever is less If the frequency of the input voltage exceeds 100 kHz, (1200 – f) Vrms or less. f is the frequency of the input voltage in units

Current

Direct input

of kHz.

Peak value of 10 A or rms value of 7 A, whichever is less

External current sensor input

Peak value 5 times the range or 25 V, whichever is less

Maximum rated voltage to earth (DC to 50/60 Hz)

Voltage input terminal 1000 V CAT II

Current input terminal

1000 V CAT II

External current sensor input connector 1000 V CAT II

Influence of voltage to earth

When 1000 Vrms is applied between the input terminal and the WT5000 case with the voltage input terminals shorted, current input terminals open and external current sensor input terminals shorted.

50/60 Hz: ±0.01% of range or less. ±0.01% of range + 0.5 μA or less

Reference value for up to 200 kHz

Voltage

Current

Direct input

±{(maximum rated range)/(rated range) × 0.001 × f% of range}

External current sensor input $\pm \{(maximum\ rated\ range)/(rated\ range)\times 0.001\times f\%\ of\ range\}$

or less

However, 0.01% or greater. The unit of f is kHz.

The maximum range rating in the equation is for a voltage of 1000 V, direct current input of 5 A, and external current sensor input of 10 V.

A/D converter

Simultaneous conversion of voltage and current inputs

Resolution: 18 bits Sample rate: 10 MS/s max.

Measurement frequency bandwidth

DC, 0.1 Hz to 2 MHz

Lower limit of measurement frequency

Sync source period average method

Data update interval		
10 ms	200 Hz	
50 ms	45 Hz	
100 ms	20 Hz	
200 ms	10 Hz	
500 ms	5 Hz	
1 s	2 Hz	
2 s	1 Hz	
5 s	0.5 Hz	
10 s	0.2 Hz	
20 s	0.1 Hz	

Digital filter average method	
FAST	100 Hz
MID	10 Hz
SLOW	1 Hz
VSLOW	0.1 Hz

Maximum display

140% of the rated voltage or current range (160% for the 1000 V range) 280% of the voltage and current range rating for CF6A (except 320% for the 500 V range)

Minimum display

Depending on the measurement range, the following are the minimum values that are displayed:

- Urms, Uac, Irms, and Iac: 0.3% (0.6% when the crest factor is set to CF6 or CF6A)
- Umn, Urmn, İmn, and Irmn: 2% (4% when the crest factor is set to CF6 or CF6A)

When input level is lower than above, the display shows zero if rounding to zero setting is ON, otherwise measured value will be shown. Current integration value q also depends on the current value.

Accuracy

Accuracy (6 months)

Condition

Temperature: 23°C±5°C For the 1 year accuracy, multiply the reading of the

accuracy at 6 months by 1.5.

Input waveform: Sine wave λ (power factor): 1 Voltage to ground: 0 V Crest factor: CF3 Line filter: OFF

Sync source period average method

Frequency filter: Used for signal frequencies at 1 kHz or less (for sync

source period average method)
Sync source signal level: Same as the frequency measurement conditions Input range: DC 0% to $\pm 110\%$ of range, AC 1% to 110% of range Defined using rms values for AC

After the warm-up time has elapsed.
Wired condition after zero-level compensation or measurement range change.

The unit of thir the accuracy equations is knz.		
Voltage		
DC	±(0.02% of reading + 0.05% of range)	
0.1 Hz ≤ f < 10 Hz	±(0.03% of reading + 0.05% of range)	
10 Hz ≤ f < 45 Hz	±(0.03% of reading + 0.05% of range)	
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)	
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.04% of range)	
1 kHz < f ≤ 10 kHz	$\pm (0.1\%$ of reading + 0.05% of range) Add 0.015 \times f % of reading (10 V range or less).	
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)	
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)	
100kHz < f≤ 500kHz	\pm {(0.006 × f)% of reading + 0.5% of range}	
500 kHz < f ≤ 1 MHz	$\pm \{(0.022 \times f - 8)\% \text{ of reading} + 1\% \text{ of range}\}$	
Frequency bandwith	DC to 10 MHz (Typical)	

Current	
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f < 10 Hz	±(0.03% of reading + 0.05% of range)
10 Hz ≤ f < 45 Hz	±(0.03% of reading + 0.05% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range) ± 0.5 μA (Direct input only)
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.04% of range)
1 kHz < f ≤ 10 kHz	±(0.1% of reading + 0.05% of range)
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)
100 kHz < f ≤ 200 kHz	±{(0.00725× f - 0.125)% of reading + 0.5% of range}
200 kHz < f ≤ 500 kHz	±{(0.00725× f - 0.125)%of reading + 0.5% of range}
500 kHz < f ≤ 1 MHz	$\pm \{(0.022 \times f - 8)\% \text{ of reading } + 1\% \text{ of range}\}$
Frequency bandwidth	Direct input: DC to 5 MHz (typical) External current sensor input: DC to 5MHz (typical)

Active power (power factor 1)	
DC	±(0.02% of reading + 0.05% of range)
$0.1 \text{ Hz} \le f < 10 \text{ Hz}$	±(0.08% of reading + 0.1% of range)
10 Hz ≤ f < 30 Hz	±(0.08% of reading + 0.1% of range)
30 Hz ≤ f < 45 Hz	±(0.05% of reading + 0.05% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.05% of reading + 0.05% of range)
1 kHz < f ≤ 10 kHz	±(0.15% of reading + 0.1% of range) Add 0.01 × f % of reading (10 V range or less).
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.7% of reading + 0.3% of range)
100 kHz < f ≤ 200 kHz	\pm {(0.008 × f)% of reading + 1% of range}
200 kHz < f ≤ 500 kHz	±{(0.008 × f)% of reading + 1% of range}
500 kHz < f ≤ 1 MHz	$\pm \{(0.048 \times f - 20)\% \text{ of reading} + 1\% \text{ of range}\}$

- For the direct current input range, add the following values to the accuracies listed above DC current accuracy: 1 µA
- DC power accuracy: (1 µA/rated value of the direct current input range) × 100% of range
- For the accuracies of waveform data functions Upk and Ipk

Add the following values (reference values) to the accuracies listed above The effective input range is within ±300% (±600% when the crest factor is set to CF6 or CF6A) of

Voltage input: $\{\sqrt{1.5/\text{range}} + 0.5\}\%$ of range

Direct current input range

 $\frac{\{[\sqrt{0.01/range}+0.5]\% \text{ of range}+100 \ \mu\text{A}\}\ (200 \ \text{mA or lower ranges})}{\{[\sqrt{0.1/range}+0.5]\% \text{ of range}+100 \ \mu\text{A}\}\ (500 \ \text{mA or higher ranges})}$

External current sensor input range

{√0.01/range + 0.5}% of range (50 mV to 200 mV range)

 $\sqrt{0.1/\text{range}} + 0.5$ % of range (500 mV to 10 V range)

- Influence of temperature changes after zero-level compensation or range change
- DC voltage accuracy: ±0.02% of range/°C (1.5 V to 10 V range)

 DC voltage accuracy: ±0.02% of range/°C (1.5 V to 10 V range)

 ±0.005% of range/°C ±(15 V to 1000 V range)

 Direct current input DC accuracy: ±1 μA/°C
- External current sensor input DC accuracy: ±50 μV/°C (50 mV to 200 mV range) ±200 uV/°C (0.5 V to 10 V range)

For the DC power accuracy, add the voltage influence \times I and the current influence \times U. U is the voltage reading (V).

I is the current reading (A).

• Influence of self-generated heat caused by current input Add the following values to the current accuracy:

For the power accuracy, add the voltage and the current influence.

AC input signal

Current, active power, apparent power: $0.004 \times I^2\%$ of reading

DC input signal.

Current: $0.004 \times l^2$ % of reading + $6 \times l^2 \mu A$ Power: $0.004 \times l^2$ % of reading + $6 \times l^2 \mu A \times U$

U is the voltage reading (V).

I is the current reading (A).

Even if the current input decreases, the influence from self-generated heat continues until the temperature of the shunt resistor decreases.

· Guaranteed accuracy ranges for frequency, voltage, and current

All accuracy figures for 0.1 Hz to 10 Hz are reference values.

The voltage and power accuracy figures for 30 kHz to 100 kHz when the voltage exceeds 750 V are reference values.

Influence of data update interval
 Add the following value for signal sync period average

10 ms: 0.03% of reading 50 ms: 0.03% of reading

100 ms: 0.02% of reading

Accuracy when the crest factor is set to CF6 or CF6A:
 The same as the accuracy when the crest factor is CF3 after doubling the range.

Power factor (\(\lambda\) influence	When λ = 0 Apparent power reading × 0.02% in the range of 45 Hz to 66 Hz. For other frequency ranges, see below. However, note that these figures are reference values. Apparent power reading × (0.02 + 0.05 × f)%
	When $0<\lambda<1$ (Power reading) \times [(power reading error %) + (power range error %) \times (power range/indicated apparent power value) + {tan $\phi \times$ (influence when $\lambda = 0)$ %)], where ϕ is the phase angle between the voltage and current. The unit of f in the accuracy equations is kHz.
Temperature coefficient	±0.01% of reading/°C (5°C to 18°C or 28°C to 40°C)
Influence of humidity	Add to the voltage and active power accuracies: $\pm 0.00022 \times HUM-50 \times f \text{ for feading: } 1 \text{ s} \text{ 40 kHz} \\ \pm 0.0087 \times HUM-50 \text{ of reading: } 1 \text{ s} \text{ 40 kHz} \\ \text{ #Reference: } \text{ Add to the power factor error.} \\ \text{When } \lambda = 0 \\ \text{Apparent power reading} \times 0.00002 \times HUM-50 \times f \% \\ \text{When } 0 \times \lambda < 1 \\ \text{(Power reading)} \times (\text{(power reading error \%)} + (\text{power range error \%)} \times (\text{power range/indicated apparent power value}) + [\tan \phi \times (\text{influence when } \lambda = 0)\%], \\ \text{HUM: Relative humidity } [\%RH] \\ \text{The unit of f in the accuracy equations is kHz.} \\$
Effective input range	Udc, Idc: 0% to ±130% of the measurement range (excluding the 1000 V range)* Udc 1000 V range: 0% to ±150%* Urms, Irms: 1% to 130% of the measurement range* Urmn, Irms: 10% to 130% of the measurement range* Urmn, Irms: 10% to 130% of the measurement range* Power DC measurement: 0% to +150% when the voltage measurement range is 1000 V, 0 to +130% otherwise* AC measurement: 1% to 130%* of the voltage and current ranges; up to ±130%* of the power range
	*The accuracy for 110% to 130% of the measurement range (excluding the 1000 \ range) is range error x 1.5. If the input voltage exceeds 600 add 0.02% of reading. However, the signal level for the signal sync period average must meet the input signal level for frequency measurement. When the crest factor is set to CF6 or CF6A, double the lower limit.
Accuracy of apparent power S	Voltage accuracy + current accuracy
Accuracy of reactive power Q	Accuracy of apparent power + ($\sqrt{1.0002 - \lambda^2} - \sqrt{1 - \lambda^2}$) × 100% of range
Accuracy of power factor λ	$\pm[(\lambda-\lambda/1.0002)+ cos\phi-cos\{\phi+sin^{-1}(influence from the power factor when \lambda=0)\%/100)\}]]\pm1 digit$
	The voltage and current must be within their rated ranges.
Accuracy of phase difference $\boldsymbol{\phi}$	$\pm[\phi-\{cos^*(k/1.0002)\} +sin^*\{(influence from the power factor when \lambda=0)\%/100\}] deg \pm1 digit$
	The voltage and current must be within their rated ranges.
Lead and lag detection	Phase difference: ±(5° to 175°) Frequency: 20 Hz to 10 kHz Condition: Sine wave At least 50% of the measurement range (at least 100% for CF6 and CF6A)
Line filter	Bessel, 5th order LPF, fc: 1 MHz Voltage, current Up to 100 kHz: Add (20 × f/fc)% of reading Power Up to 100 kHz: Add (40 × f/fc)% of reading For LPFs less than or equal to 100 kHz, see "Filter Function".

Frequency measurement Frequency measurement range

it range
Measurement range
200 Hz ≤ f ≤ 2 MHz
45 Hz ≤ f ≤ 2 MHz
20 Hz ≤ f ≤ 2 MHz
10 Hz ≤ f ≤ 2 MHz
5 Hz ≤ f ≤ 2 MHz
2 Hz ≤ f ≤ 2 MHz
1 Hz ≤ f ≤ 2 MHz
0.5 Hz ≤ f ≤ 2 MHz
0.2 Hz ≤ f ≤ 2 MHz
0.1 Hz ≤ f ≤ 2 MHz

Accuracy: ±0.06% of reading ±0.1 mHz

Conditions

Input signal level:

CF3: At least 30% of the measurement range CF6/6A: At least 60% of the measurement range

However, at least 50% of the range if the signal is less than or equal to twice the lower measurement frequency

Frequency filter
0.1 Hz ≤ f < 100 Hz: 100 Hz 100 Hz ≤ f < 1 kHz: 1 kHz 1 kHz ≤ f < 100 kHz: 100 kHz

Harmonic measurement

PLL source input level

50% or more of the rated measurement range when the crest factor is CF3. 100% or more of the rated measurement range when the crest factor is CF6 or CF6A.

Accuracy
Add the following accuracy values to the normal measurement accuracy values.

• When line filters are turned off

Frequency	Voltage, current
0.1 Hz ≤ f < 10 Hz	±(0.01% of reading + 0.03% of range)
10 Hz ≤ f < 45 Hz	±(0.01% of reading + 0.03% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.03% of range)
66 Hz < f ≤ 440 Hz	±(0.01% of reading + 0.03% of range)
440 Hz < f ≤ 1 kHz	±(0.01% of reading + 0.03% of range)
1 kHz < f ≤ 10 kHz	±(0.01% of reading + 0.03% of range)
10 kHz < f ≤ 50 kHz	±(0.05% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.1% of reading + 0.2% of range)
100 kHz < f ≤ 500 kHz	±(0.1% of reading + 0.5% of range)
500 kHz < f ≤ 1.5 MHz	±(0.5% of reading + 2% of range)

Frequency	Power
0.1 Hz ≤ f < 10 Hz	±(0.02% of reading + 0.06% of range)
10 Hz ≤ f < 45 Hz	±(0.02% of reading + 0.06% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.02% of reading + 0.06% of range)
66 Hz < f ≤ 440 Hz	±(0.02% of reading + 0.06% of range)
440 Hz < f ≤ 1 kHz	±(0.02% of reading + 0.06% of range)
1 kHz < f ≤ 10 kHz	±(0.02% of reading + 0.06% of range)
10 kHz < f ≤ 50 kHz	±(0.1% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.2% of reading + 0.4% of range)
100 kHz < f ≤ 500 kHz	±(0.2% of reading + 1% of range)
500 kHz < f ≤ 1.5 MHz	±(1% of reading + 4% of range)

 When line filters are turned on Add the line filter influence to the accuracy values when the line filters are turned off.

- . When the crest factor is set to CF3
- When λ (the power factor) is 1
- Power figures that exceed 10 kHz are reference values.
 For the voltage range, add 25 mV to the voltage accuracy and (25 mV/ current range rating) x 100% of range to the power accuracy.
 • For the direct current input range, add 200 µA to the current accuracy and
- (200 µA/current range rating) × 100% of range to the power accuracy.
 For the external current sensor range, add 2 mV to the current
- accuracy and (2 mV/rated value of the external current sensor range) \times 100% of range to the power accuracy.
- When the number of FFT points is 1024, add ±0.2% to the voltage and current range errors and ±0.4% to the power range error.

 Add (n/500)% of reading to the nth component of the voltage and current, and add (n/250)% of reading to the nth component of the power.

 The accuracy when the crest factor is CF6 or CF6A is the same as the
- accuracy when the crest factor is CF3 after doubling the measurement range.
- The guaranteed accuracy ranges for frequency, voltage, and current, are the same as the guaranteed ranges for normal measurement.
- The neighboring harmonic orders may be affected by the side lobes from the input harmonic order.

When FFT points is set to 8192

When the frequency of the PLL source is 2 Hz or greater, for n^{th} order component input, add $\{[n/(m+1)]/50\}\%$ of (the n^{th} order reading) to the n + mth order and n - mth order of the voltage and current, and add $\{[n/(m+1)]/25\}\%$ of (the nth order reading) to the n + mth order and $n-m^{th}$ order of the power.

When the frequency of the PLL source is less than 2 Hz, for n^{th} order component input, add {[n/(m + 1)]/20}% of (the nth order reading) to the n + mth order and n - mth order of the voltage and current, and add {[n/(m + 1)]/10]% of (the nth order reading) to the n + mth order and n - mth order of the power.

When FFT points is set to 1024

When the frequency of the PLL source is 75 Hz or greater, for nth order component input, add ($\{n/(m+1)\}/50\}$)% of (the nth order reading) to the n + mth order and n - mth order of the voltage and current, and add ($\{n/(m+1)\}/25$)% of (the nth order reading) to the n + mth order and n - mth order of the power.

When the frequency of the PLL source is less than 75 Hz, for nth order component input, add ({n/(m + 1)}/5)% of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and $n-m^{\text{th}}$ order of the voltage and current, and add $(2\times\{n/(m+1)\}/5)\%$ of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and n – mth order of the power.

IEC Harmonic measuremen

PLL source input level

50% or more of the rated measurement range when the crest factor is CF3. 100% or more of the rated measurement range when the crest factor is CF6 or CF6A.

Frequency	Voltage, current
45 Hz ≤ f ≤ 66 Hz	±(0.2% of reading + 0.04% of range)
66 Hz < f ≤ 440 Hz	±(0.2% of reading + 0.05% of range)
440Hz < f ≤ 1 kHz	±(0.2% of reading + 0.05% of range)
1 kHz < f ≤ 2.5 kHz	±(0.3% of reading + 0.05% of range)
2.5 kHz < f ≤ 3.3 kHz	±(0.4% of reading + 0.05% of range)
3.3 kHz < f ≤ 10 kHz	±(1% of reading + 0.05% of range)

Frequency	Power
45 Hz ≤ f ≤ 66 Hz	±(0.4% of reading + 0.05% of range)
66 Hz < f ≤ 440 Hz	±(0.4% of reading + 0.1% of range)
440Hz < f ≤ 1 kHz	±(0.4% of reading + 0.1% of range)
1 kHz < f ≤ 2.5 kHz	±(0.6% of reading + 0.1% of range)
2.5 kHz < f ≤ 3.3 kHz	±(0.8% of reading + 0.1% of range)
3.3 kHz < f ≤ 10 kHz	±(2% of reading + 0.1% of range)

- When the 30 kHz Butterworth line filter is on
- . When the crest factor is set to CF3
- When λ (the power factor) is 1
- When group is off
- The neighboring harmonic orders may be affected by the side lobes from the input harmonic order.

For nth order component input, add {[n/(m + 1)]/50}% of (the nth order reading) to the $n+m^{th}$ order and $n-m^{th}$ order of the voltage and current, and add $\{[n/(m+1)]/25\}\%$ of (the n^{th} order reading) to the $n+m^{th}$ mth order and n - mth order of the power

- The accuracy when the crest factor is CF6 or CF6A is the same as the accuracy when the crest factor is CF3 after doubling the measurement range.
- The guaranteed accuracy ranges for frequency, voltage, and current,
- are the same as the guaranteed ranges for normal measurement.

 Influence of self-generated heat caused by current input is the same as with normal measurement.
- The temperature coefficient is the same as with normal measurement.
- Influence of humidity is the same as with normal measurement.
 Accuracy at 1 year is the same as with normal measurement.
- Frequency measurements are reference values

IEC voltage fluctuation and flicker measurement

dc. dmax: ±4% (at dmax = 4%)

Pst: ±5% (at Pst = 1 to 3), ±0.05 (at Pst = 0.2 to 1)

Conditions for the accuracies above

- Ambient temperature: 23 to 1°C
- Line filter: 10 Hz ON
- · Frequency filter: 1 kHz ON

Frequency measurements are reference values.

Dir	Dimensions		
	Dimensions	Approx. 145 mm (H) x 42 mm (W) x 297 mm (D)	
		*The depth includes the slide cover (293 mm if slide cover is excluded).	
	Weight	Approx. 720 g	
	Connection	50-pin B to B connector	

- 760901 30A High Accuracy Element
- 760902 5A High Accuracy Element
 760903 Current Sensor Element

The following information is printed on the side.




Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No.50, dated June 24, 2007 4-9-8 Myojin-cho, Hachioji-shi, Tokvo 192-8566, Japan

760903 Current Sensor Element* Specifications

* The 760903 Current Sensor Element is available if the firmware version of WT5000 is 3.01 or later.

Output terminal type	Sensor power: D-sub 9-pin socket Probe power: Dedicated connector
Output voltage	Sensor power: ±15 V Probe power: ±12 V, but output is off when Terminal is set to Sensor
Output current	Sensor power: 1.8 A Probe power: 0.8 A, but output is off when Terminal is set to Sensor Total output when multiple elements are used • Sensor power: 8 A • Probe power supply: The total absolute value of the positive and negative currents of the power supply is included in the positive sensor power supply current.
Input terminal type	Voltage Plug-in terminal (safety terminal)
	Current Sensor input: D-sub 9-pin socket Probe input: BNC connector
Input type	Voltage Floating input through resistive voltage divider
	Current Sensor input: Input through shunt Probe input: Input through resistive voltage divider

D-sub 9 pin specifications The pinout and signal names of the current sensor (CT series) compatible with the current sensor connection terminal are shown below



760903		CT1000A	example
Pin No.	Signal	Pin No.	Signal
1	RETURN	1	OUTPUT RETURN
2	N.C.	2	(DON'T USE)
3	GND (ST)	3	GND STATUS
4	GND	4	0 V
5	V-	5	-15 V DC
6	INPUT	6	OUTPUT
7	CT-ID	7	(DON'T USE)
8	ST	8	NORMAL OP STATUS
9	V+	9	+15 V DC

The connector shell of the current sensor connection terminal is connected to the WT5000 case. GND (pin 4) and GND (ST) (pin 3) of the current sensor connection

terminal are connected to the WT5000 case inside the 760903. For the detailed specifications of the current sensor (CT series), see the

relevant IM. The sensor cable (sold separately) is a straight cable

Measurement range

1.5/3/6/10/15/30/60/100/150/300/600/1000 V (crest factor CF3) 0.75/1.5/3/5/7.5/15/30/50/75/150/300/500 V (crest factor CF6/CF6A)

Sensor input

• Input resistance: 1 Ω

. 10 mA, 25 mA, 50 mA, 100 mA, 250 mA, 500 mA, 1 A (crest factor

5 mA, 12.5 mA, 25 mA, 50 mA, 125 mA, 250 mA, 500 mA (crest

Input resistance: 1.5 Ω

6.67 mA, 16.7 mA, 33.3 mA, 66.7 mA, 167 mA, 333 mA, 667 mA (crest factor CE3)

3.33 mA, 8.33 mA, 16.7 mA, 33.3 mA, 83.3 mA, 167 mA, 333 mA (crest factor CF6/CF6A)

Input resistance: 5 Ω

5 mA, 10 mA, 20 mA, 50 mA, 100 mA, 200 mA (crest factor CF3)

2.5 mA, 5 mA, 10 mA, 25 mA, 50 mA, 100 mA (crest factor CF6/ CF6A) Input resistance: 10 Ω 5 mA, 10 mA, 25 mA, 50 mA, 100 mA (crest factor CF3) 2.5 mA, 5 mA, 12.5 mA, 25 mA, 50 mA (crest factor CF6/CF6A) 50 mV, 100 mV, 200 mV, 500 mV, 1 V, 2 V, 5 V, 10 V (crest factor 25 mV, 50 mV, 100 mV, 250 mV, 500 mV, 1 V, 2.5 V, 5 V (crest factor Instrument loss Input resistance: 10 M Ω ± 1%, input capacitance: approx. 15 pF Input impedance Sensor input: Input resistance: 1 Ω Approx.1 Ω + approx. 0.2 μ H Input resistance: 1.5 Ω Approx. 1.5 Ω + approx. 0.2 μH Input resistance: 5 Ω Approx. 5 Ω + approx. 0.2 μH Approx. 10 Ω + approx. 0.2 μH Input resistance: 10 Ω Probe input: Input resistance: 1 M Ω ± 1%, input capacitance: approx. 50 pF Instantaneous maximum Voltage allowable input Peak value of 2.5 kV or rms value of 1.5 kV, whichever is less (within 1 s) Sensor input: Input resistance: 1 Ω Peak value of 1.8 A or rms value of 1.2 A, whichever is less Input resistance: 1.5 Ω Peak value of 1.2 A or rms value of 0.84 A, whichever is less. Input resistance: 5 Ω Peak value of 0.36 A or rms value of 0.25 A, whichever is less. Input resistance: 10 Ω Peak value of 0.18 A or rms value of 0.12 A, whichever is less. (with in 0.1 s) Peak value at 10 times the range or 25 V, whichever is less (with in 0.1 s) Continuous maximum Peak value of 1.6 kV or rms value of 1.5 kV, whichever is less allowable input If the frequency of the input voltage exceeds 100 kHz, (1200–f) Vrms or less. f is the frequency of the input voltage in units of kHz. Sensor input: Input resistance: 1 Ω Peak value of 1.5 A or rms value of 1.1 A, whichever is less. Input resistance: 1.5 Ω Peak value of 1.0 A or rms value of 0.73 A, whichever is less. Input resistance: 5 Ω Peak value of 0.3 A or rms value of 0.22 A, whichever is less. Input resistance: 10 Ω Peak value of 0.15 A or rms value of 0.11 A, whichever is less. Probe input: Peak value at 5 times the range or rms value of 25 V, whichever is less Maximum rated voltage Voltage input terminal to earth (DC to 50/60 Hz) 1000 V CAT II Influence of voltage to 1000 Vrms is applied between an input terminal and WT5000 with the voltage input terminals shorted. earth 50/60 Hz: +0.01% of range or less. Reference values up to 200 kHz: Voltage: ±{(maximum rated range)/(rated range) × 0.001 × f% of range} or less However, 0.01% or greater. The maximum range rating in the equation is 1000 V. The unit of f in the equations is kHz. A/D converter Simultaneous conversion of voltage and current inputs. Resolution: 18 bits Sample rate: 10 MS/s max Measurement frequency DC, 0.1 Hz to 2 MHz bandwidth Lower limit of Sync source period average method Digital filter average method Data update interval 10 ms 200 Hz FAST 100 Hz 50 ms 45 Hz MID 10 Hz 100 ms 20 Hz SLOW 1 Hz VSLOW 200 ms 10 Hz 0.1 Hz 500 ms 5 Hz 1 s 2 Hz 2 s 1 Hz

0.5 Hz

0.2 Hz

0.1 Hz

280% of the voltage and current range rating for CF6A

210% only for the maximum sensor input range

105% only for the maximum rated range of the current sensor input

140% of the rated voltage or current range 160% only for the 1000 V range

320% only for the 500 V range

5 s

10 s

20 s

Maximum display

Minimum display

Depending on the measurement range, the following are the minimum values that are displayed:
• Urms, Uac, Irms, and Iac: 0.3% (0.6% when the crest factor is set to 6)

• Umn, Umn, Imn, and Irmn: 2% (4% when the crest factor is set to 6) When input level is lower than above, the display shows zero if rounding to zero setting is ON, otherwise measured value will be shown. Current integration value g also depends on the current value.

Accuracy

Accuracy (6 months)

Conditions Temperature: 23°C ± 5°C Humidity: 30 to 75%RH Input waveform: Sine wave λ (power factor): 1 Voltage to ground: 0 V Crest factor: CF3 Line filter: OFF

Sync source period average method

Frequency filter: Used for signal frequencies at 1 kHz or less Sync source signal level: Same as the frequency measurement conditions

Input range: DC 0% to \pm 110% of range, AC 1% to 110% of range

Defined using rms values for AC After the warm-up time has elapsed.

Wired condition after zero-level compensation or measurement range change.

The unit of f in the accuracy equations is kHz.

Voltage	
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f <10 Hz	±(0.03% of reading + 0.05% of range)
10 Hz ≤ f <45 Hz	±(0.03% of reading + 0.03% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.03% of range)
1 kHz < f ≤ 10 kHz	$\pm (0.1\%$ of reading + 0.05% of range) Add 0.015 \times f % of reading (10 V range or less).
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)
100 kHz< f≤ 500 kHz	\pm {(0.006 × f)% of reading + 0.5% of range}
500 kHz < f ≤ 1 MHz	±{(0.022 × f-8)% of reading + 1% of range}
Frequency bandwidth	DC to 10 MHz (Typical)
Current	
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f <10 Hz	±(0.03% of reading + 0.05% of range)
10 Hz ≤ f <45 Hz	±(0.03% of reading + 0.03% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.03% of reading + 0.03% of range)
1 kHz < f ≤ 10 kHz	±(0.1% of reading + 0.05% of range)
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.6% of reading + 0.2% of range)
100 kHz< f≤ 500 kHz	$\pm \{(0.00725 \times f - 0.125)\% \text{ of reading} + 0.5\% $ of range}
200 kHz <f≤500khz< td=""><td>$\pm \{(0.00725 \times f - 0.125)\% \text{ of reading} + 0.5\%$ of range}</td></f≤500khz<>	$\pm \{(0.00725 \times f - 0.125)\% \text{ of reading} + 0.5\% $ of range}
500 kHz < f ≤ 1 MHz	±{(0.022 × f - 8)% of reading + 1% of range}
Frequency bandwidth	Sensor input: DC to 5 MHz (typical) Probe input: DC to 5 MHz (typical)
Active power (power fa	actor 1)
DC	±(0.02% of reading + 0.05% of range)
0.1 Hz ≤ f < 10 Hz	±(0.08% of reading + 0.1% of range)
10 Hz ≤ f < 30 Hz	±(0.04% of reading + 0.04% of range)
30 Hz ≤ f < 45 Hz	±(0.04% of reading + 0.04% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.02% of range)
66 Hz < f ≤ 1 kHz	±(0.04% of reading + 0.04% of range)
1 kHz < f ≤ 10 kHz	±(0.15% of reading + 0.1% of range) Add 0.01 × f % of reading (10 V range or less).
10 kHz < f ≤ 50 kHz	±(0.3% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.7% of reading + 0.3% of range)
100 kHz < f ≤ 200 kHz	$\pm \{(0.008 \times f)\% \text{ of reading } + 1\% \text{ of range}\}$
200 kHz < f ≤ 500 kHz	±{(0.008 × f)% of reading + 1% of range}
500 kHz < f ≤ 1 MHz	±{(0.048 × f - 20)% of reading + 1% of range}
Accuracy for when used in	conjunction with AC/DC current sensor or current clamp

probe: Add the accuracy of the power analyzer and that of the AC/DC current sensor or current clamp probe

 \bullet For the current sensor input range, add the following values to the accuracies listed above Input resistance: 1 Ω

DC current accuracy: 24 µA

DC power accuracy: (24 μ A/rated value of the sensor input range) \times 100% of range Input resistance: 1.5 Ω

DC current accuracy: 15 µA

DC power accuracy: (15 μ A/rated value of the sensor input range) \times 100% of range Current and power accuracies (45 Hz ≤ f ≤ 66 Hz, 6.67 mA/16.7 mA/33.3 mA range): 0.01% of reading

```
Input resistance: 5 Ω
    DC current accuracy: 4 \muA DC power accuracy: (4 \muA/rated value of the sensor input range) \times 100% of range
     Current and power accuracies (45 Hz ≤ f ≤ 66 Hz, 5 mA/10 mA range): 0.01% of reading
  Input resistance: 10 Ω
     DC current accuracy: 1 µA
     DC power accuracy: (1 \muA/rated value of the sensor input range) \times 100% of range
  Current and power accuracies (45 Hz ≤ f ≤ 66 Hz, 5 mA/10 mA range): 0.01% of reading
The rated value of the sensor input range is a range rated value selected with a Input resistance
   setting, with scaling set to off.

    For the probe input range, add the following values to the accuracies listed above:

 Current and power accuracies (45 Hz \leq f \leq 66 Hz, 50 mV range): 0.01% of reading Current and power accuracies (45 Hz \leq f \leq 66 Hz, 100 mV range): 0.005% of reading
• For the accuracies of waveform data functions Upk and lpk:
  Add the following values (reference values) to the accuracies listed above. The effective input range is within \pm 300\% (\pm 600\% when the crest factor is set to CF6 or CF6A) of
       Voltage input: {√1.5/range + 0.5}% of range
      Sensor input:
          Input resistance: 1 Ω
             \sqrt{0.06/range} + 0.5% of range (100 mA range or less) \sqrt{0.3/range} + 0.5% of range (250 mA range or more)
          Input resistance: 1.5~\Omega {\sqrt{0.06/range} + 0.5}% of range (66.7 mA range or less) {\sqrt{0.3/range} + 0.5}% of range (167 mA range or more)
          Input resistance: 5 Ω
             \sqrt{0.06/\text{range}} + 0.5% of range (20 mA range or less)
             {√0.3/range + 0.5}% of range (50 mA range or more)
          Input resistance: 10 Ω
             \{\sqrt{0.06/\text{range}} + 0.5\}\% of range (10 mA range or less) \{\sqrt{0.3/\text{range}} + 0.5\}\% of range (25 mA range or more)
      Probe input:
                 01/range + 0.5}% of range (50 mV to 200 mV range)
           \sqrt{0.1/\text{range}} + 0.5% of range (500 mV to 10 V range)

    Influence of temperature changes after zero-level compensation or range change

  Add the following values to the accuracies listed above.
  \bullet DC voltage accuracy: \pm 0.02\% of range/°C (1.5 V to 10 V range)
     ±0.005% of range/°C (15 V to 1000 V range)
  • Sensor input DC accuracy: Input resistance: 1 \Omega
      ±0.06% of range/°C (10 mA to 50 mA range)
±0.02% of range/°C (100 mA to 1A range)
    Input resistance: 1.5 \Omega ±0.06% of range/°C (6.67 mA to 33.3 mA range)
    \pm 0.02\% of range/°C (66.7 mA to 667 mA range) Input resistance: 5 \Omega
      ±0.04% of range/°C (5 mA to 20 mA range)
±0.02% of range/°C (50 mA to 200 mA range)
     Input resistance: 10 Ω
       ±0.03% of range/°C (5 mA to 10 mA range)
  ±0.03% of range/°C (20 mA to 100 mA range)
±0.02% of range/°C (20 mA to 100 mA range)
• Probe input DC accuracy: ±50 µV/°C (50 mV to 200 mV range)
     ±200 μV/°C(0.5 V to 10 V range)
  For the DC power accuracy, add the voltage influence \times I and the current influence \times U. U is the voltage reading (V). I is the current reading (A).
• Influence of self-generated heat caused by current input
 Add the following values to the current and power accuracies: Input resistance 1 \Omega: \pm 0.1 \times I^2 [% of reading]
    \begin{array}{ll} \text{dd the following values to the current and power aclinput resistance 1 } \Omega: & \pm 0.1 \times I^2 \text{ [\% of reading]} \\ \text{Input resistance 1.5 } \Omega: & \pm 0.15 \times I^2 \text{ [\% of reading]} \\ \text{Input resistance 5 } \Omega: & \pm 0.5 \times I^2 \text{ [\% of reading]} \\ \text{Input resistance 10 } \Omega: & \pm 1.0 \times I^2 \text{ [\% of reading]} \\ \end{array}
     I is the CT's secondary current reading (A).
  Even if the current input decreases, the influence from self-generated heat continues until the
  temperature of the shunt resistor decreases

    Guaranteed accuracy ranges for frequency, voltage, and current
All accuracy figures for 0.1 Hz to 10 Hz are reference values.

  The voltage and power accuracy figures for 30 kHz to 100 kHz when the voltage exceeds 750 V
  are reference values.

    Influence of data update interval
    Add the following value for signal sync period average

     10 ms: 0.03% of reading
     50 ms: 0.03% of reading
     100 ms: 0.02% of reading

    Accuracy when the crest factor is set to CF6 or CF6A
    The same as the accuracy when the crest factor is CF3 after doubling the range.

 Power factor (\lambda) influence When \lambda = 0
                                             Apparent power reading × 0.02% in the range of 45 Hz to 66 Hz. For other frequency ranges, see below. However, note that these
                                             figures are reference values.
                                             \pmApparent power reading \times (0.02 + 0.05 \times f)%
                                         When 0 < \lambda < 1
                                             (Power reading) \times [(power reading error %) + (power range error %)
```

 \times (power range/indicated apparent power value) + $\{\tan \phi \times (\text{influence when } \lambda = 0)\%\}$ where ω is the phase angle between the voltage and current.

The unit of f in the accuracy equations is kHz.

1.5 times the accuracy at 6 months

Accuracy at 1 year

Temperature coefficient	At 5° C to 18° C or 28° C to 40° C, add the following value to the voltage measurement accuracy. $\pm 0.01\%$ of reading/°C At 5° C to 18° C or 28° C to 40° C, add the following value to the current and power measurement accuracy. When the input resistance is $10~\Omega$ or $5~\Omega$ $\pm 0.01\%$ of reading/°C $\pm 0.3~\mu$ A/°C (for DC measurement values) When the input resistance is $1.5~\Omega$ or $1~\Omega$ $\pm 0.01\%$ of reading/°C $\pm 3~\mu$ A/°C (for DC measurement values)
Influence of humidity	Add to the voltage and active power accuracies: $\pm 0.00022 \times \text{HUM} - 50 \times 1\% \text{ of reading: } f \le 40 \text{ kHz} \\ \pm 0.0087 \times \text{HUM} - 50 \% \text{ of reading: } f \le 40 \text{ kHz} \\ \text{Reference: Add to the power factor error.} \\ \text{When } \lambda = 0 \\ \text{Apparent power reading} \times 0.00002 \times \text{HUM} - 50 \times 1\% \\ \text{When } 0 < \lambda < 1 \\ \text{(Power reading)} \times (\text{(power reading error \%)} + (\text{(power range error \%)} \times ((power range er$
Effective input range	Udc, Idc: 0% to ±130% of the measurement range (excluding the 1000 V range) Udc 1000 V range: 0% to ±150%* Ums, Irms: 1% to 130% of the measurement range* Umn, Imn: 10% to 130% of the measurement range* Umn, Irmn: 10% to 130% of the measurement range* Umn, Irmn: 10% to 130% of the measurement range* Power DC measurement: 0% to ±150% when the voltage measurement range is 1000 V; 0 to ±130% of therwise* AC measurement: 1% to 130%* of the voltage and current ranges; up to ±130%* of the power range *The accuracy for 110% to 130% of the measurement range (excluding the 1000 V range) is range error × 1.5. If the input voltage exceeds 600 V, add 0.02% of reading. However, the signal level for the sync source period average method must meet the input signal level for frequency measurement. When the crest factor is set to CF6 or CF6A, double the lower limit.
Accuracy of apparent power S	Voltage accuracy + current accuracy
Accuracy of reactive power Q	Accuracy of apparent power + $(\sqrt{1.0002-\lambda^2}-\sqrt{1-\lambda^2}\)\times 100\%$ of range
Accuracy of power factor λ	$\pm[(\lambda-\lambda'1.0002)+ cos\phi-cos\{\phi+sin^{-1}((influence from the power factor when \lambda=0)\%/100)\}[]\pm1 digit$
	The voltage and current must be within their rated ranges.
Accuracy of phase difference φ	$\pm [\phi-\cos^*(\lambda/1.0002) + \sin^{-1}\{(influence from the power factor when \lambda=0)\%/100]] deg \pm 1 digit$
Lead and lag detection	The voltage and current must be within their rated ranges. Phase difference: ±(5° to 175°) Frequency: 20 Hz to 10 kHz Condition: Sine wave At least 50% of the measurement range (at least 100% for CF6 and CF6A)
Line filter	Bessel, 5th order LPF, cutoff frequency fc: 1 MHz
Let No. 188001	 When the advanced line filter setting is off When the line filter is on, add the following to the voltage, current, and active power accuracies. Voltage, current f≤ (fc/10): ± (20 × f/fc) % of reading Active power f≤ (fc/10): ± (40 × f/fc) % of reading For the filter specifications for fc less than or equal to 100 kHz, see "Filter Function".
	 When the advanced line filter setting is on When the anti-aliasing filter function (AAF) is on, add the following to the voltage, current, active power accuracies. Voltage, current f ≤ (fc/10): ± (20 × f/fc) % of reading Active power f ≤ (fc/10): ± (40 × f/fc) % of reading For the filter specifications for fc less than or equal to 100 kHz, see "Filter Function".
	When the high frequency rejection function (HFR) is on, add the following to the voltage, current, active power accuracies. However, if the AAF is set to ON simultaneously, the accuracy addition of the AAF takes precedence.
	Current $50 \text{ kHz} \le f \le 100 \text{ kHz} \colon (0.006 \times f - 0.1) \% \text{ of reading} \\ 100 \text{ kHz} < f \le 300 \text{ kHz} \colon (0.035 \times f - 2.0) \% \text{ of reading} \\ 300 \text{ kHz} < 500 \text{ kHz} \colon (0.040 \times f + 2.0) \% \text{ of reading} \\ \text{Active power (power factor 1)} \\ 10 \text{ kHz} \le f \le 50 \text{ kHz} \colon \pm (0.005 \times f - 0.05) \% \text{ of reading} \\ 50 \text{ kHz} \le f \le 100 \text{ kHz} \colon \pm (0.005 \times f - 0.3) \% \text{ of reading} \\ 100 \text{ kHz} < f \le 500 \text{ kHz} \colon \pm (0.050 \times f - 3.0) \% \text{ of reading} \\ 100 \text{ kHz} < f \le 500 \text{ kHz} \colon \pm (0.050 \times f - 3.0) \% \text{ of reading} \\ \text{Influence of power factor (\lambda)} \\ \lambda = 0 \colon \pm (0.01 \times f) \% \text{ of apparent power reading} \\ \text{However, be aware that these figures are reference values.} \\ \text{The unit of fc and f in the accuracy equations is kHz}. $

Frequency measurement Frequency measurement range

Data update interval	Measurement range
10 ms	200 Hz ≤ f ≤ 2 MHz
50 ms	45 Hz ≤ f ≤ 2 MHz
100 ms	20 Hz ≤ f ≤ 2 MHz
200 ms	10 Hz ≤ f ≤ 2 MHz
500 ms	5 Hz ≤ f ≤ 2 MHz
1 s	2 Hz ≤ f ≤ 2 MHz
2 s	1 Hz ≤ f ≤ 2 MHz
5 s	0.5 Hz ≤ f ≤ 2 MHz
10 s	0.2 Hz ≤ f ≤ 2 MHz
20 s	0.1 Hz ≤ f ≤ 2 MHz

Accuracy: ±0.06% of reading ± 0.1 mHz

Input signal level:

Crest factor CF3: At least 30% of the measurement range Crest factor CF6/CF6A: At least 60% of the measurement range However, at least 50% of the range if the signal is less than or equal to twice the lower measurement frequency

Frequency filter

0.1 Hz \leq f < 100 Hz: 100 Hz 100 Hz \leq f < 1 kHz: 1 kHz 1 kHz \leq f < 100 kHz: 100 kHz

Harmonic measurement PLL source input level

50% or more of the rated measurement range when the crest factor is CF3.

100% or more of the rated measurement range when the crest factor is CF6 or CF6A.

Accuracy

Add the following accuracy values to the normal measurement accuracy values

• When line filters are turned off

Frequency	Voltage, current
0.1 Hz ≤ f < 10 Hz	±(0.01% of reading + 0.03% of range)
10 Hz ≤ f < 45 Hz	±(0.01% of reading + 0.03% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.01% of reading + 0.03% of range)
66 Hz < f ≤ 440 Hz	±(0.01% of reading + 0.03% of range)
440 Hz < f ≤ 1 kHz	±(0.01% of reading + 0.03% of range)
1 kHz < f ≤ 10 kHz	±(0.01% of reading + 0.03% of range)
10 kHz < f ≤ 50 kHz	±(0.05% of reading + 0.1% of range)
50 kHz < f ≤ 100 kHz	±(0.1% of reading + 0.2% of range)
100 kHz < f ≤ 500 kHz	±(0.1% of reading + 0.5% of range)
500 kHz < f ≤ 1.5 MHz	±(0.5% of reading + 2% of range)

Frequency	Power
0.1 Hz ≤ f < 10 Hz	±(0.02% of reading + 0.06% of range)
10 Hz ≤ f < 45 Hz	±(0.02% of reading + 0.06% of range)
45 Hz ≤ f ≤ 66 Hz	±(0.02% of reading + 0.06% of range)
66 Hz < f ≤ 440 Hz	±(0.02% of reading + 0.06% of range)
440 Hz < f ≤ 1 kHz	±(0.02% of reading + 0.06% of range)
1 kHz < f ≤ 10 kHz	±(0.02% of reading + 0.06% of range)
10 kHz < f ≤ 50 kHz	±(0.1% of reading + 0.2% of range)
50 kHz < f ≤ 100 kHz	±(0.2% of reading + 0.4% of range)
100 kHz < f ≤ 500 kHz	±(0.2% of reading + 1% of range)
500 kHz < f ≤ 1.5 MHz	±(1% of reading + 4% of range)

· When line filters are turned on

Add the line filter influence to the accuracy values when the line filters are turned off.

- When the crest factor is set to CF3
- When λ (the power factor) is 1
- Power figures that exceed 10 kHz are reference values.
- For the voltage range, add 25 mV to the voltage accuracy and (25 mV/current range rating) × 100% of range to the power accuracy.
- For the current sensor input range, add 200 µA to the current accuracy and (200 µA/current range rating) x 100% of range to the power accuracy.
 • For the probe input range, add 2 mV to the current accuracy and
- (2 mV/rated value of the probe input range)×100% of range to the power accuracy.
- When the number of FFT points is 1024, add ±0.2% to the voltage and current range errors and ±0.4% to the power range error.
- Add (n/500)% of reading to the nth component of the voltage and current, and add (n/250)% of reading to the nth component of the
- The accuracy when the crest factor is CF6 or CF6A is the same as the accuracy when the crest factor is CF3 after doubling the measurement range.
- The guaranteed accuracy ranges for frequency, voltage, and current, are the same as the guaranteed ranges for normal measurement.
- The neighboring harmonic orders may be affected by the side lobes from the input harmonic order.

When FFT points is set to 8192

When the frequency of the PLL source is 2 Hz or greater, for n^{th} order component input, add $\{[n/(m+1)]/50\}\%$ of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and $n-m^{\text{th}}$ order of the voltage and current, and add $[\![n/(m+1)\!]/25]\!\%$ of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and n – mth order of the power.

When the frequency of the PLL source is less than 2 Hz, for nth order component input, add {[n/(m + 1)]/20}% of (the nth order reading) to the n + mth order and n - mth order of the voltage and current, and add $\{[n/(m+1)]/10\}\%$ of (the nth order reading) to the n + mth order and n - mth order of the power.

When FFT points is set to 1024

When the frequency of the PLL source is 75 Hz or greater, for nth order component input, add ({n/(m + 1)}/50)% of (the nth order order components injust, and $\{|r|(n+1)|r|/20\}$ to the $n+m^n$ order and $n-m^n$ order of the voltage and current, and add $(\{n/(m+1)\}/25)\%$ of (the n^n order reading) to the $n+m^n$ order reading) to the $n+m^n$ order reading). mth order and n - mth order of the power

When the frequency of the PLL source is less than 75 Hz, for n^{th} order component input, add ((n/(m + 1))/5)% of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and $n-m^{\text{th}}$ order of the voltage and current, and add (2{n/(m+1)}/5)% of (the n^{th} order reading) to the $n+m^{\text{th}}$ order and n – mth order of the power.

Notes

Limitations when used in combination with the CT1000 Use within the following ambient temperature derating.

CT ambient temperature 45°C or more: Primary current 900 Apk

CT ambient temperature 45°C or less: Follows the CT1000 specifications

Restrictions when used in combination with the 10 m sensor cable 761956

CT2000A primary current: 2100 Apk or less

Dimensions

Approx. 145 mm (H) × 42 mm (W) × 298 mm (D) Dimensions The depth includes the slide cover (295 mm if slide cover is excluded).

Weight Approx. 740 g Connection 50-pin B to B connector

- 760901 30A High Accuracy Element • 760902 5A High Accuracy Element
- 760903 Current Sensor Element

The following information is printed on the side.

CLASS 1 LASER PRODUCT (IEC 60825-1:2007, GB 7247.1-2012)

Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No.50, dated June 24, 2007 4-9-8 Myojin-cho, Hachioji-shi, Tokyo 192-8566, Japan

Model and suffix code

Model	Suffix Code		Descriptions
WT5000			Precision Power Analyzer
Language	-HC		Chinese/English Menu
Menu	-HE		English Menu
	-HG		German/English Menu
	-HJ		Japanese/English Menu
Power Cord	-B		Indian Standard
	-D		UL/CSA Standard, PSE Compliant
	-F		VDE/Korean Standard
	-H		Chinese Standard
	-N		Brazilian Standard
	-Q		BS Standard
	-R		Australian Standard
	-T		Taiwanese Standard
	-U		IEC Plug Type B
Option	/M1		32 GB Built-in Memory
	/MTR1		Motor Evaluation 1
	/DA2	0*	20 CH D/A Output
	/MTF	R2*	Motor Evaluation 2
	/D	S	Data Streaming
		/G7	IEC Harmonic/Flicker Measurement

^{*}Select only one of these options. /MTR2 option requires installation of /MTR1 option.

Model	Suffix Code	Descriptions	
760901	Guilla Gode	30 A High Accuracy Element	
760902		5 A High Accuracy Element	
760903		Current Sensor Element	

Standard accessories

Power cord, rubber feet, cover panel B8216JA 7 sets, user's manual, expanded user's manual, communication interface user's manual, connector (provided only with/DA20)

Safety terminal adapter B9317WB/B9317WC (provided two adapters in a set times input element number)**, safety terminal adapter A1650JZ/A1651JZ (provided black/red two adapters in a set, times of 30 A input element number)**, safety terminal adapter B8213YA/ B8213YB (provided black/red two adapters in a set, times of 5 A input element number)*

760903*4

Safety terminal adapter B9317WB/B9317WC (provided black/red two adapters in a set times input element number)*

User's manuals: Start guide (booklet), function/operation, communication manuals (electric file)

- *1: When additional standard accessories are needed, order accessory products, 758931.
- *2: When additional standard accessories are needed, order accessory products, 761951.
- *3: When additional standard accessories are needed, order accessory products, 761953.
- *4: Cable for current sensor is sold separately.

Yokogawa's Approach to Preserving the Global Environment

- Yokogawa's electrical products are developed and produced in facilities that have received ISO14001 approval.
- In order to protect the global environment, Yokogawa's electrical products are designed in accordance with Yokogawa's Environmentally Friendy Product Design Guidelines and Product Design Assessment Criteria.

This is a Class A instrument based on Emission standards EN61326-1 and EN55011 and is designed for an industrial environment.

Operation of this equipment in a residential area may cause radio interference, in which case users will be responsible for any interference which they cause.

Any company's names and product names mentioned in this document are trade names. trademarks or registered trademarks of their respective companies.

 \bullet Before operating the product, read the user's manual thoroughly for proper and safe operation

Accessories (sold separately)

Model Product name Descriptions 366924 ⚠*¹ BNC-BNC Cable 1 m 366925 ⚠*¹ BNC-BNC Cable 2 m 701901 1:1 Safety BNC Adapter Lead 1000 V CAT II, 1 for /MTR1, /MTR2 701902 Safety BNC-BNC Cable 1000 V CAT II, 1 m for /MTR1, /MTR2 701903 Safety BNC-BNC Cable 1000 V CAT II, 2 m for /MTR1, /MTR2 720930 Current Clamp Probe 40 Hz to 3.5 kHz, AC50 A 720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 ⚠ Small Alligator-clip Rated at 300 V CAT II two in a set 758924 Conversion Adapter Two adapters to a set (spring-hold type) 758929 ⚠ Large Alligator-clip Rated at 1000 V CAT II and used in a particular p	
366925	
701901 1:1 Safety BNC Adapter Lead 1000 V CAT II for /MTR1, /MTR2 701902 Safety BNC-BNC Cable 1000 V CAT II, 1 m for /MTR1, /MTR2 701903 Safety BNC-BNC Cable 1000 V CAT II, 2 m for /MTR1, /MTR2 720930 Current Clamp Probe 40 Hz to 3.5 kHz, AC50 A 720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 ★ Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 ★ Large Alligator-clip Rated at 1000 V CAT II and used in a par 758931 Safety Terminal Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par 758931 Two adapters to a set (Screw-fastened in 1000 V CAT II and used in a par	
Adapter Lead 701902 Safety BNC-BNC Cable 1000 V CAT II, 1 m for /MTR1, /MTR2 701903 Safety BNC-BNC Cable 1000 V CAT II, 2 m for /MTR1, /MTR2 720930 Current Clamp Probe 40 Hz to 3.5 kHz, AC50 A 720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a part 758931 Safety Terminal Two adapters to a set (Screw-fastened in Two adapters t	
701903 Safety BNC-BNC Cable 1000 V CAT II, 2 m for /MTR1, /MTR2 720930 Current Clamp Probe 40 Hz to 3.5 kHz, AC50 A 720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 ⚠ Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 ⚠ Large Alligator-clip Rated at 1000 V CAT II and used in a pa	
720930 Current Clamp Probe 40 Hz to 3.5 kHz, AC50 A 720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa	
720931 Current Clamp Probe 40 Hz to 3.5 kHz, AC200 A 751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa	
751542-E4 Rack Mounting Kit For EIA 751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922 Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa	
751542-J4 Rack Mounting Kit For JIS 758917 Test Lead Set A set of 0.75 m long, red and black test 758922	
758917 Test Lead Set A set of 0.75 m long, red and black test 758922 Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa 758931 Safety Terminal Two adapters to a set (Screw-fastened to	
758922 A Small Alligator-clip Rated at 300 V CAT II two in a set 758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 A Large Alligator-clip Rated at 1000 V CAT II and used in a pa 758931 Safety Terminal Two adapters to a set (Screw-fastened to	
758923 Safety Terminal Adapter Two adapters to a set (spring-hold type) 758924 Conversion Adapter BNC-banana-Jack (female) adapter 758929 A Large Alligator-clip Rated at 1000 V CAT II and used in a pa 758931 Safety Terminal Two adapters to a set (Screw-fastened to	leads
758924 Conversion Adapter 758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa 758931 Safety Terminal Two adapters to a set (Screw-fastened to	
758929 Large Alligator-clip Rated at 1000 V CAT II and used in a pa 758931 Safety Terminal Two adapters to a set (Screw-fastened to)
758931 Safety Terminal Two adapters to a set (Screw-fastened to	
/58931	ir
Adapter Set 1.5 min nex Wiench is attached.	type),
761941 WTViewerE Application Software for WT Series	
761951 Safety Terminal Two adapters to a set for 30 A current (6 mm screw-fastened type)	
761952 Safety Terminal Two adapters to a set for 5 A current Conversion Adapter Set (female-female type)	
761953 Safety Terminal Two adapters to a set for 5 A current (screw-fastened type using B9317WD)	
761954 Cable for Current Dedicated cable for current sensor elem Sensor Element (3 m) total length 3 m	nent,
761955 Cable for Current Dedicated cable for current sensor elem Sensor Element (5 m) total length 5 m	nent,
761956 Cable for Current Dedicated cable for current sensor elem Sensor Element (10 m) total length 10 m	nent,
751552 Clamp-on probe 30 Hz to 5 kHz, 1400 Apeak (1000 Arms	5)
CT2000A AC/DC CurrentSensor DC to 40 kHz, 3000 Apeak (2000 Arms)	
CT1000A AC/DC CurrentSensor DC to 300 kHz, 1500 Apeak (1000 Arms	s)
CT1000 AC/DC Current Sensor DC to 300 kHz, 1000 Apeak	
CT200 AC/DC Current Sensor DC to 500 kHz, 200 Apeak	
CT60 AC/DC Current Sensor DC to 800 kHz, 60 Apeak	
Parts number Product Description Orde	
B9284LK External Sensor Cable Current sensor input connector, Length 0.5	r Q'tv
B9317WD Wrench For 761953	r Q'ty m 1

⚠ Due to the nature of this product, it is possible to touch its metal parts. There is a risk of electric shock - use this product with caution

*1 Use these products with low-voltage circuits (42 V or less).

The is registered trademark of Yokogawa Electric Corporation.

Additional option license*

Model	Suffix Code	Descriptions
760991	-DS	Data Streaming
	-G7	IEC Harmonic/Flicker Measurement

*Separately sold license product (customer-installable).

https://tmi.yokogawa.com/

YMI-KS-MI-SF08

[Ed: 02/b]

YOKOGAWA -

YOKOGAWA TEST & MEASUREMENT CORPORATION

Global Sales Dept. /Phone: +81-42-690-8810 E-mail: tm@cs.jp.yokogawa.com

Facsimile: +81-42-690-8826

YOKOGAWA CORPORATION OF AMERICA YOKOGAWA EUROPE B.V.

YOKOGAWA ELECTRIC KOREA CO., LTD. YOKOGAWA ENGINEERING ASIA PTE. LTD.

YOKOGAWA INDIA LTD.

YOKOGAWA ELECTRIC CIS LTD. YOKOGAWA AMERICA DO SUL LTDA.

YOKOGAWA MIDDLE EAST & AFRICA B.S.C(c)

The contents are as of April 2021. Subject to change without notice. Copyright © 2018, Yokogawa Test & Measurement Corporation

Phone: +65-6241-9933

Phone: +1-800-888-6400 E-mail: tmi@us.yokogawa.com Phone: +31-88-4641429 E-mail: tmi@nl.yokogawa.com YOKOGAWA TEST & MEASUREMENT (SHANGHAI) CO., LTD. Phone: +86-21-6239-6363 E-mail: tmi@cs.cn.yokogawa.com

Phone: +82-2-2628-3810 E-mail: TMI@kr.yokogawa.com E-mail: TMI@sg.yokogawa.com Phone: +91-80-4158-6396 E-mail: tmi@in.yokogawa.com Phone: +7-495-737-7868 E-mail: info@ru.yokogawa.com

Phone: +55-11-3513-1300 E-mail: eproc@br.yokogawa.com

Facsimile: +86-21-6880-4987 Facsimile: +82-2-2628-3899 Facsimile: +65-6241-9919 Facsimile: +91-80-2852-1442 Facsimile: +7-495-737-7869

19 WT5000

> 40 Jahre ...

Wir, als **nbn Austria GmbH** schätzen den Einsatz und das Know-How unserer Mitarbeiter ebenso wie eine nachhaltige und gute Zusammenarbeit mit unseren Kunden.

Das Team der nbn Austria überzeugt seit **mehr als 40 Jahren** durch Kompetenz und individuelle Kundenbetreuung und verfügt, aufgrund unserer engen Kooperation mit weltmarktführenden **Messtechnik- und Technologie-Unternehmen**, über ein umfassendes Wissen und Erfahrung in den Schwerpunkten:

- Leistungsmesstechnik
- Automatisierung und Instandhaltung
- Schwingungsmesstechnik
- Maschinenüberwachung
- Thermografie und Infrarotmesstechnik
- Temperaturmessung und -überwachung
- Druckmesstechnik und
- Kommunikationsmesstechnik

Unsere langjährigen Lieferantenkontakte auf exklusiver Basis stellen sicher, dass wir immer am aktuellsten Stand der Technik sind und unsere Kunden ohne lange Wartezeiten optimal versorgen können.

Die über die Jahre verkauften Geräte sichern uns eine führende Position am Messtechnikmarkt in Österreich.

upu

v11 06 21